

POWERTRAIN LIFTS



5285
1,650-LB POWERTRAIN LIFT

- Air/hydraulic operation with foot control pump
- Scissor design to access all 4 sides of powertrain



1595A
2,500-LB POWERTRAIN LIFT

- Air/hydraulic operation with foot control pump
- Scissor design to access all 4 sides of powertrain



5295
1,760-LB SPLIT TOP POWERTRAIN LIFT

- Sliding split-top helps separate powertrains, differentials, axles and more
- High ground clearance for floor crane access when collapsed
- Air/hydraulic lifting mechanism smoothly lifts and lowers components
- Large, tilting tabletop to access all sides of components
- Air/hydraulic operation with foot control pump



5130
1,000 LB DRIVELINE LIFT

- Includes 553516 differential adapter
- Pivoting pump handle to raise/lower from multiple positions
- For removal of differentials, light-duty transmissions, auxiliary boxes, drive shafts and more



1585A
1,250 LB POWERTRAIN LIFT

- Ideal for engine and transaxle service
- Moves easily around the shop with compact design and swivel casters
- Air/hydraulic operation

Lift Spec.	Capacity (lbs)	Table size	Tilt side/side	Tilt front/back	Min height	Max height	Caster size
5285	1,650	20" x 32"	15°	15°	31.5"	74.5"	8"
1595A	2,500	20" x 32"	15°	15°	29"	80"	8"
5295	1,760	36" x 42"	N/A	N/A	21.5"	70"	8"
5130	1,000	N/A	15°	15°	7"	30"	4"
1585A	1,250	20.5" x 30.5"	17°	22°	29.5"	68.5"	4"



TRANSMISSION JACKS



5019A 2,200 LB TRANSMISSION JACK

- Includes 540231 adapter for Eaton Fuller RoadRanger transmissions
- Pivoting pump handle to raise/lower from multiple positions



5078 2,000 LB HIGH-LIFT TRANSMISSION JACK

- Air/hydraulic operation with foot control pump
- Includes adapter for Allison 500 and 600-series transmissions



1522A 2,000 LB LOW-LIFT TRANSMISSION JACK

- Includes 220492 adapter for Eaton Fuller RoadRanger transmissions
- Pump handle rotates 360° to raise/lower from multiple positions



1521A 1,000 LB LOW LIFT TRANSMISSION JACK

- Universal mounting head and adjustable brackets for easy transmission alignment
- Pump handle rotates 360° to raise/lower from multiple positions

Lift Spec.	Capacity (lbs)	Min height	Max height	Tilt, forward	Tilt, backward	Tilt, side/side
5019A	2,200	8.25"	36.5"	15°	20°	12°
5078	2,000	41.5"	65"	50°	38°	14°
1522A	2,000	6.875"	35.25"	24°	18°	11°
1521A	1,000	7.5"	29.75"	67°	17°	30°
TJH10	1,000	35"	71-5/8"	24°	19°	20°
TJHP10	1,000	37-5/8"	76-1/2"	50°	38°	14°
TJHP15	1,500	41-1/2"	65"	50°	38°	14°

TRANSMISSION JACKS



✓ GOOD

TJH10 1,000-LB CAPACITY HIGH-LIFT TRANSMISSION JACKS

- Head tilts front to back and side to side to make removal and installation of transmission and driveline components easier
- Hydraulic system features flash-chromed rams to prevent rust from entering the system, prolonging jack life
- A foot-operated pump and lowering pedal allow for ease of control when positioning or removing a transmission



✓ BETTER

TJHP10 AIR/HYDRAULIC 1,000-LB CAPACITY HIGH-LIFT TRANSMISSION JACK







- Foot pedals control the air operation, which lifts the head quickly
- A hand pump secondary hydraulic stage allows for precise operator control
- Specially designed with a wide leg base and oversize 5" polyurethane swivel wheels for smooth maneuvering over rough surfaces and small debris, while providing stability and easy placement during jobs



✓ BEST

TJHP15 AIR-ASSISTED 1,500-LB CAPACITY HIGH-LIFT TRANSMISSION JACK

- Rugged wall tubing and oversized base add strength and stability for any transmission job
- Foot-operated air pump controls the air-powered hydraulic operation, which lifts the head quickly and effortlessly to the work location
- Big, easy-to-grip knobs make mounting head adjustments simple, and the included safety chains securely hold components during removal, transport and installation

COMPATIBILITY ADAPTER	POWERTRAIN LIFTS				DRIVELINE	LOW-LIFT TRANS JACKS				HIGH-LIFT TRANS JACKS		
Adapters	5285	1595A	5295	1585A	5130	5019A	1522A	1521A	5078	TJH10	TJHP10	TJHP15
 <p>558382 Auxiliary box adapter</p>					Yes	Yes	Yes		Yes			
 <p>561949 Light duty transmission adapters</p>					Yes	Yes	Yes		Yes			
 <p>528150 Eaton lightning adapter</p>						Yes						
 <p>543284 Roadranger transmission</p>						Yes						
 <p>49611 Eaton Fuller Roadranger auxiliary housing</p>						yes						
 <p>553516 Differential mounting adapter</p>					Yes, included with lift purchase	Yes	Yes		Yes			

COMPATIBILITY ADAPTER	POWERTRAIN LIFTS				DRIVELINE	LOW-LIFT TRANS JACKS			HIGH-LIFT TRANS JACKS			
Adapters	5285	1595A	5295	1585A	5130	5019A	1522A	1521A	5078	TJH10	TJHP10	TJHP15
 <p>314729 Allison 5/0600 series adapter</p>									Yes, included with lift purchase			
 <p>540231 Eaton Fuller Roadranger transmission adapter</p>						Yes, included with lift purchase						
 <p>540232 Mack transmission mounting brackets</p>						yes						
 <p>5091 HD spindle adapter</p>					Yes	Yes	Yes					
 <p>1870 Universal transmission adapter</p>									Yes	Yes	Yes	
 <p>5295-DA Powertrain Lift Differential adapter set</p>			Yes									
 <p>1797 splined shaft adapter</p>									Yes	Yes	Yes	
 <p>1758 Fuel tank handler</p>	Yes	Yes	Yes	Yes					Yes	Yes	Yes	