

SPX Corporation 655 Eisenhower Drive

Owatonna, MN 55060-0995 USA Phone: (507) 455-7000 Tech. Serv.: (800) 533-6127

Fax: (800) 955-8329 Order Entry: (800) 533-6127 Fax: (800) 283-8665

International Sales: (507) 455-7223

Fax: (507) 455-7063


Parts List & **Assembly Instructions** for:

5100

Wheel Mate™ Assembly Instructions

Use the following steps to assemble the Wheel Mate:

1. Connect the lower main frame to the main rear upright support using two 3/8" x 3-1/4" bolts, four 3/8" flat washers, and two 3/8" lock nuts.



Note: The number of parts included in the Wheel Mate assembly kit are identified in parenthesis on the illustrations. Parts not identified with a number are single units.




CAUTION: To prevent personal injury, wear eye protection that meets ANSI Z87.1 and OSHA standards.


Sheet No. 1 of 2

Rev. B, June 15, 2006 Issue Date:

2. Connect the main tire support ring to the lower tire support using two 5/16" x 1-3/4" bolts, four 5/16" flat washers, and two 5/16" lock nuts.




3. Connect the main tire support ring / lower tire support assembly to the horizontal slider plate using three 5/16" x 1-3/4" bolts, six 5/16" flat washers, and four 5/16" lock nuts.



4. Secure the main tire support ring / lower tire support assembly to the horizontal slider plate using a 3/8" x 3-1/4" bolt, two 3/8" flat washers, and a 3/8" lock nut.


5. Install three 4-1/2" upper rollers to the main tire support ring using three 1/2" x 6-1/2" roller studs with preinstalled crown acorn nuts, and three 11/16" stainless steel bushings. Do not overtighten studs; roller will not spin freely if studs are too tight.



Sheet No. 2 of 2

Issue Date: Rev. B, June 15, 2006

Assembled Unit and Repair Parts:



Replacement Parts

		-
	Item No.	Description
	514020	Tire Support Assembly
	514021	Ratchet Lever Hoist
	514022	Floor Lock
	514023	Swivel Casters
	514024	1.9" O.D. x 8.75" Lower Roller
	514025	2.375" O.D. x 4.5" Upper Roller