

Make	Year	Carline	Repair Info	System	Live Data	DTCs	Tests
Acura	2013	ILX		ABS/TCS/VSA	X	X	X
				AIRBAG	X	X	X
				AUTO AIR CONDITIONING	X	X	
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
			Acura	2013	MDX		ABS/TCS/VSA
	AIRBAG	X				X	X
	AUTO AIR CONDITIONING	X				X	
	CENTER PANEL MODULE	X				X	
	ELECTRIC POWER STEERING	X				X	X
	ENGINE	X				X	X
	FOUR WHEEL DRIVE	X				X	
	GLOBAL OBDII	X				X	X
	INSTRUMENT PANEL	X				X	X
	MULTIPLEXED ICU	X				X	X
	MULTIPLEXED ICU DR	X				X	X
	MULTIPLEXED ICU PSG	X				X	X
	REAR JUNCTION UNIT	X				X	X
	RELAY MODULE	X				X	X
	SEAT WEIGHT SENSOR	X				X	X
	TIRE PRESSURE MONITOR	X				X	X
	TRANSMISSION	X				X	X
Acura	2013	RDX		ABS/TCS/VSA	X	X	X
				AIRBAG	X	X	X
				AUTO AIR CONDITIONING	X	X	
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2013	TL		ABS/TCS/VSA	X	X	X
				AIRBAG	X	X	X
				AUTO AIR CONDITIONING	X	X	
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2013	TSX		ABS/TCS/VSA	X	X	X

				AIRBAG	X	X	X
				AUTO AIR CONDITIONING	X	X	
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2013	ZDX					
				ABS/TCS/VSA	X	X	X
				AIRBAG	X	X	X
				AUTO AIR CONDITIONING	X	X	
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2012	MDX	X				
				ABS/TCS/VSA	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2012	RDX	X				
				ABS/TCS/VSA	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2012	RL	X				
				ABS/TCS/VSA	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	

				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2012	TL	X				
				ABS/TCS/VSA	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2012	TSX	X				
				ABS/TCS/VSA	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2012	ZDX	X				
				ABS/TCS/VSA	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2011	MDX	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X

				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2011	RDX	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2011	RL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2011	TL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2011	TSX	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2011	ZDX	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	

				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2010	MDX	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2010	RDX	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2010	RL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2010	TL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X

				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2010	TSX	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2010	ZDX	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2009	MDX	X				
				ABS (BOSCH)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2009	RDX	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2009	RL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X

				MULTIPLEXED ICU	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2009	TL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2009	TSX	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2008	MDX	X				
				ABS (BOSCH)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2008	RDX	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2008	RL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2008	TL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X

				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2008	TSX	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2007	MDX	X				
				ABS (BOSCH)	X	X	X
				AIRBAG	X	X	X
				AUTO LIGHT ECU	X	X	
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				POWER WINDOW	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2007	RDX	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				POWER WINDOW	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2007	RL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				AUTO LIGHT ECU	X	X	
				CENTER PANEL MODULE	X	X	
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MEMORY SEAT CONTROL	X	X	
				MULTIPLEXED ICU	X	X	X
				POWER WINDOW	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2007	TL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				POWER WINDOW	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2007	TSX	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X

				INSTRUMENT PANEL	X	X	X
				MEMORY SEAT CONTROL	X	X	
				MULTIPLEXED ICU	X	X	X
				POWER WINDOW	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2006	3.5RL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				AUTO LIGHT ECU	X	X	
				CENTER PANEL MODULE	X	X	
				COMBINATION SWITCH	X	X	
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				HANDS FREE PHONE	X	X	
				INSTRUMENT PANEL	X	X	X
				MEMORY SEAT CONTROL	X	X	
				MULTIPLEXED ICU	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2006	MDX	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	X
				GLOBAL OBDII	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2006	RSX	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2006	TL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2006	TSX	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				COMBINATION SWITCH	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2005	3.5RL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				AUTO LIGHT ECU	X	X	
				COMBINATION SWITCH	X	X	
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	
				GLOBAL OBDII	X	X	X
				HANDS FREE PHONE	X	X	
				INSTRUMENT PANEL	X	X	X
				MEMORY SEAT CONTROL	X	X	
				MULTIPLEXED ICU	X	X	X
				SEAT WEIGHT SENSOR	X	X	
				TIRE PRESSURE MONITOR	X	X	X

				TRANSMISSION	X	X	X
Acura	2005	MDX	X	ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	X
				GLOBAL OBDII	X	X	X
				SEAT WEIGHT SENSOR	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2005	RSX	X	ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				SEAT WEIGHT SENSOR	X	X	
				TRANSMISSION	X	X	X
Acura	2005	TL	X	ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				SEAT WEIGHT SENSOR	X	X	
				TRANSMISSION	X	X	X
Acura	2005	TSX	X	ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				COMBINATION SWITCH	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	
				TRANSMISSION	X	X	X
Acura	2004	3.5RL	X	ABS (HONDA)	X	X	X
				ABS/VSA	X	X	
				AIRBAG	X	X	
				AUTO LIGHT ECU	X	X	
				COMBINATION SWITCH	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				SEAT WEIGHT SENSOR	X	X	
Acura	2004	MDX	X	ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				SEAT WEIGHT SENSOR	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Acura	2004	RSX	X	ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				SEAT WEIGHT SENSOR	X	X	
				TRANSMISSION	X	X	X
Acura	2004	TL	X	ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				SEAT WEIGHT SENSOR	X	X	
				TRANSMISSION	X	X	X
Acura	2004	TSX	X	ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				COMBINATION SWITCH	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X

				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	
Acura	2003	3.2CL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				SEAT WEIGHT SENSOR	X	X	
				TRANSMISSION	X	X	X
Acura	2003	3.2TL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				SEAT WEIGHT SENSOR	X	X	
				TRANSMISSION	X	X	X
Acura	2003	3.5RL	X				
				ABS (HONDA)	X	X	X
				ABS/VSA	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				SEAT WEIGHT SENSOR	X	X	
Acura	2003	MDX	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	X
				GLOBAL OBDII	X	X	X
				SEAT WEIGHT SENSOR	X	X	
				TRANSMISSION	X	X	X
Acura	2003	RSX	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				SEAT WEIGHT SENSOR	X	X	
				TRANSMISSION	X	X	X
Acura	2002	3.2CL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Acura	2002	3.2TL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Acura	2002	3.5RL	X				
				ABS (HONDA)	X	X	X
				ABS/VSA	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Acura	2002	MDX	X				
				ABS (BOSCH)	X	X	X
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Acura	2002	RSX	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Acura	2001	3.2CL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X

				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Acura	2001	3.2TL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Acura	2001	3.5RL	X				
				ABS (HONDA)	X	X	X
				ABS/VSA	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Acura	2001	Integra	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Acura	2001	MDX	X				
				ABS (BOSCH)	X	X	X
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Acura	2000	3.2TL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Acura	2000	3.5RL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Acura	2000	Integra	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Acura	1999	2.3CL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Acura	1999	2.5TL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Acura	1999	3.0CL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Acura	1999	3.2TL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Acura	1999	3.5RL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Acura	1999	Integra	X				
				ABS (HONDA)	X	X	X

				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Acura	1999	SLX	X				
				ABS (HONDA)	X	X	X
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Acura	1998	2.3CL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Acura	1998	2.5TL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Acura	1998	3.0CL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Acura	1998	3.2TL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Acura	1998	3.5RL	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Acura	1998	Integra	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Acura	1998	SLX	X				
				ABS (HONDA)	X	X	X
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Acura	1997	2.2CL	X				
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Acura	1997	2.5TL	X				
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Acura	1997	3.0CL	X				
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Acura	1997	3.2TL	X				
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Acura	1997	3.5RL	X				
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Acura	1997	Integra	X				
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Acura	1997	SLX	X				
				ENGINE	X	X	

				GLOBAL OBDII	X	X	X
Acura	1996	2.5TL	X	AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Acura	1996	3.2TL	X	AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Acura	1996	3.5RL	X	AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Acura	1996	Integra	X	AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Acura	1996	SLX	X	ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Acura	1995	Integra	X	ENGINE/TRANS	X	X	
Acura	1994	Integra	X	ENGINE/TRANS	X	X	
Acura	1993	Integra	X	ENGINE/TRANS	X	X	
Acura	1992	Integra	X	ENGINE/TRANS	X	X	
Audi	2009	A8 Quattro	X	ALL WHEEL DRIVE (22)	X	X	X
Audi	2008	A4 Quattro	X	ALL WHEEL DRIVE (22)	X	X	X
Audi	2008	A8 Quattro	X	ALL WHEEL DRIVE (22)	X	X	X
Daewoo	2002	Lanos		GLOBAL OBDII	X	X	X
Daewoo	2002	Leganza	X	GLOBAL OBDII	X	X	X
Daewoo	2002	Nubira	X	GLOBAL OBDII	X	X	X
Daewoo	2001	Lanos	X	GLOBAL OBDII	X	X	X
Daewoo	2001	Leganza	X	GLOBAL OBDII	X	X	X
Daewoo	2001	Nubira	X	GLOBAL OBDII	X	X	X
Daewoo	2000	Lanos	X	GLOBAL OBDII	X	X	X
Daewoo	2000	Leganza	X	GLOBAL OBDII	X	X	X
Daewoo	2000	Nubira	X	GLOBAL OBDII	X	X	X
Daewoo	1999	Lanos	X	GLOBAL OBDII	X	X	X
Daewoo	1999	Leganza	X	GLOBAL OBDII	X	X	X
Daewoo	1999	Nubira	X	GLOBAL OBDII	X	X	X
Honda	2013	Accord		ABS/TCS/VSA	X	X	X
				AIRBAG	X	X	
				AUTO AIR CONDITIONING	X	X	
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	

				TRANSMISSION	X	X	X
Honda	2013	Civic	X	ABS/TCS/VSA	X	X	X
				AIRBAG	X	X	
				AUTO AIR CONDITIONING	X	X	
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HYDRAULIC BOOSTER	X	X	
				IMA BATTERY	X	X	X
				IMA MOTOR	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2013	Crosstour		ABS/TCS/VSA	X	X	X
				AIRBAG	X	X	X
				AUTO AIR CONDITIONING	X	X	
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2013	CR-V		ABS/TCS/VSA	X	X	X
				AIRBAG	X	X	
				AUTO AIR CONDITIONING	X	X	
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAL TIME AWD	X	X	
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2013	CR-Z		ABS/TCS/VSA	X	X	X
				AIRBAG	X	X	X
				AUTO AIR CONDITIONING	X	X	
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HYDRAULIC BOOSTER	X	X	
				IMA BATTERY	X	X	X
				IMA MOTOR	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X

			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X
Honda	2013	Fit				
			ABS/TCS/VSA	X	X	X
			AIRBAG	X	X	X
			AUTO AIR CONDITIONING	X	X	
			CENTER PANEL MODULE	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			INSTRUMENT PANEL	X	X	X
			MULTIPLEXED ICU	X	X	X
			MULTIPLEXED ICU DR	X	X	X
			MULTIPLEXED ICU PSG	X	X	X
			REAR JUNCTION UNIT	X	X	X
			RELAY MODULE	X	X	X
			SEAT WEIGHT SENSOR	X	X	X
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X
Honda	2013	Insight				
			ABS/TCS/VSA	X	X	X
			AIRBAG	X	X	X
			AUTO AIR CONDITIONING	X	X	
			CENTER PANEL MODULE	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			HYDRAULIC BOOSTER	X	X	
			IMA BATTERY	X	X	X
			IMA MOTOR	X	X	X
			INSTRUMENT PANEL	X	X	X
			MULTIPLEXED ICU	X	X	X
			MULTIPLEXED ICU DR	X	X	X
			MULTIPLEXED ICU PSG	X	X	X
			REAR JUNCTION UNIT	X	X	X
			RELAY MODULE	X	X	X
			SEAT WEIGHT SENSOR	X	X	X
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X
Honda	2013	Odyssey				
			ABS/TCS/VSA	X	X	X
			AIRBAG	X	X	X
			AUTO AIR CONDITIONING	X	X	
			CENTER PANEL MODULE	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			INSTRUMENT PANEL	X	X	X
			MULTIPLEXED ICU	X	X	X
			MULTIPLEXED ICU DR	X	X	X
			MULTIPLEXED ICU PSG	X	X	X
			REAR JUNCTION UNIT	X	X	X
			RELAY MODULE	X	X	X
			SEAT WEIGHT SENSOR	X	X	X
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X
Honda	2013	Pilot				
			ABS/TCS/VSA	X	X	X
			AIRBAG	X	X	X
			AUTO AIR CONDITIONING	X	X	
			CENTER PANEL MODULE	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			FOUR WHEEL DRIVE	X	X	X
			GLOBAL OBDII	X	X	X
			INSTRUMENT PANEL	X	X	X
			MULTIPLEXED ICU	X	X	X
			MULTIPLEXED ICU DR	X	X	X
			MULTIPLEXED ICU PSG	X	X	X
			REAR JUNCTION UNIT	X	X	X
			RELAY MODULE	X	X	X
			SEAT WEIGHT SENSOR	X	X	X
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X

Honda	2013	Ridgeline		ABS/TCS/VSA	X	X	X			
			AIRBAG	X	X	X				
			AUTO AIR CONDITIONING	X	X					
			CENTER PANEL MODULE	X	X					
			ELECTRIC POWER STEERING	X	X	X				
			ENGINE	X	X	X				
			FOUR WHEEL DRIVE	X	X	X				
			GLOBAL OBDII	X	X	X				
			INSTRUMENT PANEL	X	X	X				
			MULTIPLEXED ICU	X	X	X				
			MULTIPLEXED ICU DR	X	X	X				
			MULTIPLEXED ICU PSG	X	X	X				
			REAR JUNCTION UNIT	X	X	X				
			RELAY MODULE	X	X	X				
			SEAT WEIGHT SENSOR	X	X	X				
			TIRE PRESSURE MONITOR	X	X	X				
			TRANSMISSION	X	X	X				
Honda	2012	Accord	X	ABS/TCS/VSA	X	X	X			
			AIRBAG	X	X	X				
			CENTER PANEL MODULE	X	X					
			ELECTRIC POWER STEERING	X	X	X				
			ENGINE	X	X	X				
			GLOBAL OBDII	X	X	X				
			INSTRUMENT PANEL	X	X	X				
			MULTIPLEXED ICU	X	X	X				
			MULTIPLEXED ICU DR	X	X	X				
			MULTIPLEXED ICU PSG	X	X	X				
			REAR JUNCTION UNIT	X	X	X				
			RELAY MODULE	X	X	X				
			SEAT WEIGHT SENSOR	X	X	X				
			TIRE PRESSURE MONITOR	X	X	X				
			TRANSMISSION	X	X	X				
			Honda	2012	Civic	X	ABS/TCS/VSA	X	X	X
						AIRBAG	X	X	X	
CENTER PANEL MODULE	X	X								
ELECTRIC POWER STEERING	X	X				X				
ENGINE	X	X				X				
GLOBAL OBDII	X	X				X				
HYDRAULIC BOOSTER	X	X								
IMA BATTERY	X	X				X				
IMA MOTOR	X	X				X				
INSTRUMENT PANEL	X	X				X				
MULTIPLEXED ICU	X	X				X				
MULTIPLEXED ICU DR	X	X				X				
MULTIPLEXED ICU PSG	X	X				X				
REAR JUNCTION UNIT	X	X				X				
RELAY MODULE	X	X				X				
SEAT WEIGHT SENSOR	X	X				X				
TIRE PRESSURE MONITOR	X	X				X				
TRANSMISSION	X	X	X							
Honda	2012	Crosstour	X	ABS/TCS/VSA	X	X	X			
			AIRBAG	X	X	X				
			CENTER PANEL MODULE	X	X					
			ELECTRIC POWER STEERING	X	X	X				
			ENGINE	X	X	X				
			GLOBAL OBDII	X	X	X				
			INSTRUMENT PANEL	X	X	X				
			MULTIPLEXED ICU	X	X	X				
			MULTIPLEXED ICU DR	X	X	X				
			MULTIPLEXED ICU PSG	X	X	X				
			REAR JUNCTION UNIT	X	X	X				
			RELAY MODULE	X	X	X				
			SEAT WEIGHT SENSOR	X	X	X				
			TIRE PRESSURE MONITOR	X	X	X				
			TRANSMISSION	X	X	X				
			Honda	2012	CR-V	X	ABS/TCS/VSA	X	X	X
						AIRBAG	X	X		
ELECTRIC POWER STEERING	X	X				X				
ENGINE	X	X				X				
TRANSMISSION	X	X				X				

				GLOBAL OBDII	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAL TIME AWD	X	X	
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2012	CR-Z	X				
				ABS/TCS/VSA	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HYDRAULIC BOOSTER	X	X	
				IMA BATTERY	X	X	X
				IMA MOTOR	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2012	Fit	X				
				ABS/TCS/VSA	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2012	Insight	X				
				ABS/TCS/VSA	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HYDRAULIC BOOSTER	X	X	
				IMA BATTERY	X	X	X
				IMA MOTOR	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2012	Odyssey	X				
				ABS/TCS/VSA	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X

				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2012	Pilot	X				
				ABS/TCS/VSA	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2012	Ridgeline	X				
				ABS/TCS/VSA	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2011	Accord	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2011	Accord Crosstour	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2011	Civic	X				
				ABS (HONDA)	X	X	X

				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HYDRAULIC BOOSTER	X	X	
				IMA BATTERY	X	X	X
				IMA MOTOR	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2011	CR-V	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2011	CR-Z	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HYDRAULIC BOOSTER	X	X	
				IMA BATTERY	X	X	X
				IMA MOTOR	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2011	Element	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2011	Fit	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X

				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2011	Insight	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HYDRAULIC BOOSTER	X	X	
				IMA BATTERY	X	X	X
				IMA MOTOR	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2011	Odyssey	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2011	Pilot	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2011	Ridgeline	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X

				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2010	Accord	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2010	Accord Crosstour	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2010	Civic	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HYDRAULIC BOOSTER	X	X	
				IMA BATTERY	X	X	X
				IMA MOTOR	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2010	CR-V	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2010	Element	X				
				ABS (HONDA)	X	X	X

				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2010	Fit	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2010	Insight	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HYDRAULIC BOOSTER	X	X	
				IMA BATTERY	X	X	X
				IMA MOTOR	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2010	Odyssey	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2010	Pilot	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X

				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2010	Ridgeline	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				CENTER PANEL MODULE	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				MULTIPLEXED ICU PSG	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2009	Accord	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2009	Civic	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HYDRAULIC BOOSTER	X	X	
				IMA BATTERY	X	X	X
				IMA MOTOR	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2009	CR-V	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2009	Element	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2009	Fit	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X

				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2009	Odyssey	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2009	Pilot	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2009	Ridgeline	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2009	S2000	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Honda	2008	Accord	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU DR	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2008	Civic	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HYDRAULIC BOOSTER	X	X	
				IMA BATTERY	X	X	X
				IMA MOTOR	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2008	CR-V	X				
				ABS (HONDA)	X	X	X

				AIRBAG	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2008	Element	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2008	Fit	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2008	Odyssey	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2008	Pilot	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2008	Ridgeline	X				
				ABS (BOSCH)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2008	S2000	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Honda	2007	Accord	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ELECTRIC POWER STEERING	X	X	X

				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				INTEGRATED MOTOR ASSIST	X	X	
				MULTIPLEXED ICU	X	X	X
				POWER WINDOW	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2007	Civic	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMA BATTERY	X	X	
				IMA MOTOR	X	X	
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				POWER WINDOW	X	X	X
				RELAY MODULE	X	X	X
				TRANSMISSION	X	X	X
Honda	2007	CR-V	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2007	Element	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	
				POWER WINDOW	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2007	Fit	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	
				POWER WINDOW	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2007	Odyssey	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				AUTO LIGHT ECU	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MEMORY SEAT CONTROL	X	X	
				MULTIPLEXED ICU	X	X	X
				POWER SLIDE DOOR LEFT	X	X	
				POWER SLIDE DOOR RIGHT	X	X	
				POWER TAILGATE	X	X	
				POWER WINDOW	X	X	X
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X

				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED MOTOR ASSIST	X	X	
				SEAT WEIGHT SENSOR	X	X	X
				TRANSMISSION	X	X	
Honda	2006	Odyssey	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				AUTO LIGHT ECU	X	X	
				COMBINATION SWITCH	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MEMORY SEAT CONTROL	X	X	
				MULTIPLEXED ICU	X	X	X
				POWER SLIDE DOOR LEFT	X	X	
				POWER SLIDE DOOR RIGHT	X	X	
				POWER TAILGATE	X	X	
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2006	Pilot	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	
				SEAT WEIGHT SENSOR	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2006	Ridgeline	X				
				ABS (BOSCH)	X	X	X
				AIRBAG	X	X	X
				COMBINATION SWITCH	X	X	
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	X
				GLOBAL OBDII	X	X	X
				MULTIPLEXED ICU	X	X	X
				POWER WINDOW	X	X	X
				RELAY MODULE	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2006	S2000	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	
				SEAT WEIGHT SENSOR	X	X	X
Honda	2005	Accord	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				COMBINATION SWITCH	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				INTEGRATED MOTOR ASSIST	X	X	
				MULTIPLEXED ICU	X	X	X
				POWER WINDOW	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	
				TRANSMISSION	X	X	X
Honda	2005	Civic	X				
				ABS (BOSCH)	X	X	X
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X

				INTEGRATED MOTOR ASSIST	X	X	
				SEAT WEIGHT SENSOR	X	X	
				TRANSMISSION	X	X	X
Honda	2005	CR-V	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	2005	Element	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	2005	Insight	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED MOTOR ASSIST	X	X	
				SEAT WEIGHT SENSOR	X	X	
				TRANSMISSION	X	X	
Honda	2005	Odyssey	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				AUTO LIGHT ECU	X	X	
				COMBINATION SWITCH	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MEMORY SEAT CONTROL	X	X	
				MULTIPLEXED ICU	X	X	X
				POWER SLIDE DOOR LEFT	X	X	
				POWER SLIDE DOOR RIGHT	X	X	
				POWER TAILGATE	X	X	
				REAR JUNCTION UNIT	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2005	Pilot	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	X
				GLOBAL OBDII	X	X	X
				SEAT WEIGHT SENSOR	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Honda	2005	S2000	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				SEAT WEIGHT SENSOR	X	X	
Honda	2004	Accord	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				COMBINATION SWITCH	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				POWER WINDOW	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	
				TRANSMISSION	X	X	X
Honda	2004	Civic	X				
				ABS (BOSCH)	X	X	X
				ABS (HONDA)	X	X	X

				AIRBAG	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED MOTOR ASSIST	X	X	
				SEAT WEIGHT SENSOR	X	X	
				TRANSMISSION	X	X	X
Honda	2004	CR-V	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	2004	Element	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	2004	Insight	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED MOTOR ASSIST	X	X	
				SEAT WEIGHT SENSOR	X	X	
				TRANSMISSION	X	X	
Honda	2004	Odyssey	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				SEAT WEIGHT SENSOR	X	X	
				TRANSMISSION	X	X	X
Honda	2004	Pilot	X				
				ABS (BOSCH)	X	X	X
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	X
				GLOBAL OBDII	X	X	X
				SEAT WEIGHT SENSOR	X	X	
				TRANSMISSION	X	X	X
Honda	2004	S2000	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				SEAT WEIGHT SENSOR	X	X	
Honda	2003	Accord	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				COMBINATION SWITCH	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X	X	X
				MULTIPLEXED ICU	X	X	X
				POWER WINDOW	X	X	X
				RELAY MODULE	X	X	X
				SEAT WEIGHT SENSOR	X	X	
				TRANSMISSION	X	X	X
Honda	2003	Civic	X				
				ABS (BOSCH)	X	X	X
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED MOTOR ASSIST	X	X	
				SEAT WEIGHT SENSOR	X	X	
				TRANSMISSION	X	X	X
Honda	2003	CR-V	X				

				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	2003	Element	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	2003	Insight	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED MOTOR ASSIST	X	X	
				SEAT WEIGHT SENSOR	X	X	
				TRANSMISSION	X	X	
Honda	2003	Odyssey	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				SEAT WEIGHT SENSOR	X	X	
				TRANSMISSION	X	X	X
Honda	2003	Pilot	X				
				ABS (BOSCH)	X	X	X
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				FOUR WHEEL DRIVE	X	X	X
				GLOBAL OBDII	X	X	X
				SEAT WEIGHT SENSOR	X	X	
				TRANSMISSION	X	X	X
Honda	2003	S2000	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				SEAT WEIGHT SENSOR	X	X	
Honda	2002	Accord	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	2002	Civic	X				
				ABS (BOSCH)	X	X	X
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	2002	CR-V	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	2002	Insight	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED MOTOR ASSIST	X	X	
				TRANSMISSION	X	X	
Honda	2002	Odyssey	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X

				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	2002	Passport	X	ABS (4WAL)	X	X	X
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Honda	2002	S2000	X	ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Honda	2001	Accord	X	ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	2001	Civic	X	ABS (BOSCH)	X	X	X
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	2001	CR-V	X	ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	2001	Insight	X	ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED MOTOR ASSIST	X	X	
				TRANSMISSION	X	X	
Honda	2001	Odyssey	X	ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	2001	Passport	X	ABS (4WAL)	X	X	X
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Honda	2001	Prelude	X	ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	2001	S2000	X	ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Honda	2000	Accord	X	ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	2000	Civic	X	ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	2000	CR-V	X				

				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	2000	Insight	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED MOTOR ASSIST	X	X	
				TRANSMISSION	X	X	
Honda	2000	Odyssey	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	2000	Passport 2WD	X				
				ABS (4WAL)	X	X	X
				ABS (HONDA)	X	X	X
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Honda	2000	Passport 4WD	X				
				ABS (4WAL)	X	X	X
				ABS (HONDA)	X	X	X
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Honda	2000	Prelude	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	2000	S2000	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Honda	1999	Accord	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	1999	Civic	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	1999	CR-V	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	1999	Odyssey	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	1999	Passport 2WD	X				
				ABS (4WAL)	X	X	X
				ABS (HONDA)	X	X	X
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Honda	1999	Passport 4WD	X				
				ABS (4WAL)	X	X	X
				ABS (HONDA)	X	X	X
				ENGINE	X	X	

				GLOBAL OBDII	X	X	X
Honda	1999	Prelude	X	ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	1998	Accord	X	ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	1998	Civic	X	ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	1998	CR-V	X	ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	1998	Odyssey	X	ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	1998	Passport 2WD	X	ABS (4WAL)	X	X	X
				ABS (HONDA)	X	X	X
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Honda	1998	Passport 4WD	X	ABS (4WAL)	X	X	X
				ABS (HONDA)	X	X	X
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Honda	1998	Prelude	X	ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	1997	Accord	X	AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	1997	Civic	X	ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	1997	CR-V	X	ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	1997	Odyssey	X	ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	1997	Passport 2WD	X	ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Honda	1997	Passport 4WD	X				

				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Honda	1997	Prelude	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	1996	Accord	X				
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	1996	Civic	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	1996	Odyssey	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	1996	Passport 2WD	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Honda	1996	Passport 4WD	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Honda	1996	Prelude	X				
				ABS (HONDA)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Honda	1995	Accord	X				
				AIRBAG	X	X	
				ENGINE/TRANS	X	X	
Honda	1995	Civic	X				
				AIRBAG	X	X	
				ENGINE/TRANS	X	X	
Honda	1995	Del Sol	X				
				AIRBAG	X	X	
				ENGINE/TRANS	X	X	
Honda	1995	Odyssey	X				
				AIRBAG	X	X	
				ENGINE/TRANS	X	X	
Honda	1995	Prelude	X				
				AIRBAG	X	X	
				ENGINE/TRANS	X	X	
Honda	1994	Accord	X				
				ENGINE/TRANS	X	X	
Honda	1994	Civic	X				
				AIRBAG	X	X	
				ENGINE/TRANS	X	X	
Honda	1994	Del Sol	X				
				AIRBAG	X	X	
				ENGINE/TRANS	X	X	
Honda	1994	Prelude	X				
				AIRBAG	X	X	
				ENGINE/TRANS	X	X	
Honda	1993	Civic	X				
				ENGINE/TRANS	X	X	
Honda	1993	Del Sol	X				
				ENGINE/TRANS	X	X	
Honda	1993	Prelude	X				
				ENGINE/TRANS	X	X	
Honda	1992	Civic	X				
				ENGINE/TRANS	X	X	
Honda	1992	Prelude	X				
				ENGINE/TRANS	X	X	
Hyundai	2013	Accent					

			ABS/ESC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	
			BODY CONTROL MODULE	X		
			ELECTRONIC POWER STEERING	X	X	
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			IMMOBILIZER	X		
			TPMS	X	X	X
			TRANSMISSION	X	X	X
Hyundai	2013	Azera				
			ABS/ESC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	
			BODY CONTROL MODULE	X	X	
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			IMMOBILIZER	X	X	
			SMART KEY UNIT	X	X	X
			TPMS	X	X	X
			TRANSMISSION	X	X	X
Hyundai	2013	Elantra				
			ABS/ESC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	
			AUTO HEADLAMP LEVELING SYSTEM	X	X	
			BODY CONTROL MODULE	X	X	X
			ELECTRONIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			SMART KEY UNIT	X	X	X
			TPMS	X	X	X
			TRANSMISSION	X	X	X
			WEIGHT CLASS MODULE	X	X	
Hyundai	2013	Elantra Coupe				
			ABS/ESC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	
			AUTO HEADLAMP LEVELING SYSTEM	X	X	
			BODY CONTROL MODULE	X	X	X
			ELECTRONIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			SMART KEY UNIT	X	X	X
			TPMS	X	X	X
			TRANSMISSION	X	X	X
			WEIGHT CLASS MODULE	X	X	
Hyundai	2013	Elantra GT				
			ABS/ESC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	
			AUTO HEADLAMP LEVELING SYSTEM	X	X	
			BODY CONTROL MODULE	X	X	X
			ELECTRONIC POWER STEERING	X	X	X
			ELECTRONIC STABILITY CONTROL	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			SMART KEY UNIT	X	X	X
			TPMS	X	X	X
			TRANSMISSION	X	X	X
			WEIGHT CLASS MODULE	X	X	
Hyundai	2013	Equus				
			ABS/ESC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	
			ELECTRIC HYDRAULIC POWER STEER	X	X	
			ELECTRIC PARKING BRAKE	X	X	
			ELECTRONIC CONTROL SUSPENSION	X	X	
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			INSTRUMENT PANEL MODULE	X	X	X
			TPMS	X	X	X
			TRANSMISSION	X	X	X
Hyundai	2013	Genesis				

			ABS/ESC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	
			AUTO HEADLAMP LEVELING SYSTEM	X	X	
			ELECTRIC PARKING BRAKE	X	X	
			ELECTRONIC POWER STEERING	X	X	
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			INSTRUMENT PANEL MODULE(PIC-)	X	X	X
			INSTRUMENT PANEL MODULE(PIC+)	X	X	X
			LANE DEPARTURE WARNING SYSTEM	X		
			TPMS	X	X	X
			TRANSMISSION	X	X	X
Hyundai	2013	Genesis Coupe				
			ABS/ESC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	
			AUTO HEADLAMP LEVELING SYSTEM	X	X	
			BODY CONTROL MODULE	X		X
			ELECTRONIC STABILITY CONTROL	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			SMART KEY UNIT	X	X	
			TPMS	X	X	X
			TRANSMISSION	X	X	X
Hyundai	2013	Santa Fe				
			4WD	X	X	
			ABS/ESC	X	X	X
			AHLS	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	
			BODY CONTROL MODULE	X	X	X
			ELECTRIC PARKING BRAKE	X	X	
			ELECTRONIC POWER STEERING	X	X	
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			POWER TAIL GATE	X	X	
			SMART KEY UNIT	X	X	
			TPMS	X	X	X
			TRANSMISSION	X	X	X
Hyundai	2013	Sonata				
			ABS/ESC	X	X	X
			ACTIVE AIR FLAP	X	X	
			ACTIVE HYDRAULIC BOOSTER	X	X	
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	
			AUTO HEADLAMP LEVELING SYSTEM	X	X	
			BODY CONTROL MODULE	X	X	X
			ELECTRONIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			HEV BATTERY SYSTEM	X	X	X
			HEV CONTROL SYSTEM	X	X	
			HEV MOTOR SYSTEM	X	X	
			LOW DC DC CONVERTER	X	X	
			MOTOR DRIVEN POWER STEERING	X	X	X
			POWER DISTRIBUTION MODULE	X		
			SMART KEY UNIT	X	X	
			TPMS	X	X	X
			TRANSMISSION	X	X	X
			WEIGHT CLASS MODULE	X	X	
Hyundai	2013	Tucson				
			4WD	X	X	
			ABS/ESC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	
			BODY CONTROL MODULE	X	X	X
			ELECTRONIC POWER STEERING	X	X	
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			POWER DISTRIBUTION MODULE	X		
			SMART KEY UNIT	X	X	
			TPMS	X	X	X
			TRANSMISSION	X	X	X

Hyundai	2013	Veloster		ABS/ESC	X	X	X			
				AIR CONDITIONING	X	X	X			
				AIRBAG	X	X				
				BODY CONTROL MODULE	X	X	X			
				ELECTRONIC POWER STEERING	X	X	X			
				ENGINE	X	X	X			
				GLOBAL OBDII	X	X	X			
				IMMOBILIZER	X	X				
				SMART KEY UNIT	X	X	X			
				TPMS	X	X	X			
				TRANSMISSION	X	X	X			
			Hyundai	2012	Accent	X	ABS/ESC	X	X	X
	AIR CONDITIONING	X				X	X			
	AIRBAG	X				X				
	BODY CONTROL MODULE	X								
	ELECTRONIC POWER STEERING	X				X				
	ENGINE	X				X	X			
	GLOBAL OBDII	X				X	X			
	IMMOBILIZER	X								
	TPMS	X				X	X			
	TRANSMISSION	X				X	X			
Hyundai	2012	Azera					ABS/ESC	X	X	X
							GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X				
				TRANSMISSION	X	X	X			
Hyundai	2012	Elantra	X	ABS/ESC	X	X	X			
				AIR CONDITIONING	X	X	X			
				AIRBAG	X	X				
				AUTO HEADLAMP LEVELING SYSTEM	X	X				
				BODY CONTROL MODULE	X	X	X			
				ELECTRONIC POWER STEERING	X	X	X			
				ENGINE	X	X	X			
				GLOBAL OBDII	X	X	X			
				SMART KEY UNIT	X	X	X			
				TPMS	X	X	X			
				TRANSMISSION	X	X	X			
				WEIGHT CLASS MODULE	X	X				
			Hyundai	2012	Equus	X	ABS/ESC	X	X	X
							AIR CONDITIONING	X	X	X
	AIRBAG	X				X				
	ELECTRIC HYDRAULIC POWER STEER	X				X				
	ELECTRIC PARKING BRAKE	X				X				
	ELECTRONIC CONTROL SUSPENSION	X				X				
	ENGINE	X				X	X			
	GLOBAL OBDII	X				X	X			
	INSTRUMENT PANEL MODULE	X				X	X			
	TPMS	X				X	X			
	TRANSMISSION	X				X	X			
Hyundai	2012	Genesis				X	ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X			
				AIRBAG	X	X				
				AUTO HEADLAMP LEVELING SYSTEM	X	X				
				ELECTRIC PARKING BRAKE	X	X				
				ELECTRIC POWER STEERING	X	X				
				ENGINE	X	X	X			
				GLOBAL OBDII	X	X	X			
				INSTRUMENT PANEL MODULE(PIC-)	X	X	X			
				INSTRUMENT PANEL MODULE(PIC+)	X	X	X			
				LANE DEPARTURE WARNING SYSTEM	X					
				TPMS	X	X	X			
				TRANSMISSION	X	X	X			
			Hyundai	2012	Genesis Coupe	X	ABS/ESC	X	X	X
	AIR CONDITIONING	X				X	X			
	AIRBAG	X				X				
	AUTO HEADLAMP LEVELING SYSTEM	X				X				
	BODY CONTROL MODULE	X					X			
	ENGINE	X				X	X			

				GLOBAL OBDII	X	X	X
				POWER DISTRIBUTION MODULE	X		
				SMART KEY UNIT	X	X	
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2012	Santa Fe	X				
				4WD	X	X	
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2012	Sonata	X				
				ABS/ESC	X	X	X
				ACTIVE AIR FLAP	X	X	
				ACTIVE HYDRAULIC BOOSTER	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				AUTO HEADLAMP LEVELING SYSTEM	X	X	
				BODY CONTROL MODULE	X	X	X
				ELECTRONIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HEV BATTERY SYSTEM	X	X	X
				HEV CONTROL SYSTEM	X	X	
				HEV MOTOR SYSTEM	X	X	
				LOW DC DC CONVERTER	X	X	
				MOTOR DRIVEN POWER STEERING	X	X	X
				POWER DISTRIBUTION MODULE	X		
				SMART KEY UNIT	X	X	
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Hyundai	2012	Tucson	X				
				4WD	X	X	
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				POWER DISTRIBUTION MODULE	X		
				SMART KEY UNIT	X	X	
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2012	Veloster					
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ELECTRONIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				SMART KEY UNIT	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2012	Veracruz	X				
				4WD	X	X	X
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				POWER TAIL GATE	X	X	
				SMART KEY UNIT	X	X	
				TPMS	X	X	X
				TRANSMISSION	X	X	X

Hyundai	2011	Accent	X				
				ABS	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2011	Azera	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				AUTO HEADLAMP LEVELING SYSTEM	X	X	
				BODY CONTROL MODULE	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
Hyundai	2011	Elantra	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				AUTO HEADLAMP LEVELING SYSTEM	X	X	
				BODY CONTROL MODULE	X	X	X
				ELECTRONIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				SMART KEY UNIT	X	X	X
Hyundai	2011	Equus	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				ELECTRIC HYDRAULIC POWER STEER	X	X	
				ELECTRIC PARKING BRAKE	X	X	
				ELECTRONIC CONTROL SUSPENSION	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL MODULE	X	X	X
Hyundai	2011	Genesis	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				AUTO HEADLAMP LEVELING SYSTEM	X	X	
				ELECTRIC PARKING BRAKE	X	X	
				ELECTRIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL MODULE(PIC-)	X	X	X
Hyundai	2011	Genesis Coupe	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				AUTO HEADLAMP LEVELING SYSTEM	X	X	
				BODY CONTROL MODULE	X		X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				POWER DISTRIBUTION MODULE	X		
				SMART KEY UNIT	X	X	
Hyundai	2011	Santa Fe	X				
				4WD	X	X	
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X

				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2011	Sonata	X				
				ABS/ESC	X	X	X
				ACTIVE AIR FLAP	X	X	
				ACTIVE HYDRAULIC BOOSTER	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				AUTO HEADLAMP LEVELING SYSTEM	X	X	
				BODY CONTROL MODULE	X	X	X
				ELECTRONIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HEV BATTERY SYSTEM	X	X	X
				HEV CONTROL SYSTEM	X	X	
				HEV MOTOR SYSTEM	X	X	
				LOW DC DC CONVERTER	X	X	
				MOTOR DRIVEN POWER STEERING	X	X	X
				POWER DISTRIBUTION MODULE	X		
				SMART KEY UNIT	X	X	
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Hyundai	2011	Tucson	X				
				4WD	X	X	
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				POWER DISTRIBUTION MODULE	X		
				SMART KEY UNIT	X	X	
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2011	Veracruz	X				
				4WD	X	X	X
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				POWER TAIL GATE	X	X	
				SMART KEY UNIT	X	X	
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2010	Accent	X				
				ABS	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2010	Azera	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2010	Elantra	X				
				ABS/ESC	X	X	X

				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Hyundai	2010	Genesis	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2010	Genesis Coupe	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2010	Santa Fe	X				
				4WD	X	X	
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2010	Sonata	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Hyundai	2010	Tucson	X				
				4WD	X	X	
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				POWER DISTRIBUTION MODULE	X		
				SMART KEY UNIT	X	X	
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2010	Veracruz	X				
				4WD	X	X	X
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				SMART KEY UNIT	X	X	
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Hyundai	2009	Accent	X				
				ABS	X	X	

				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2009	Azera	X				
				ABS/ESC	X	X	X
				AHLS	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2009	Elantra	X				
				ABS/ESC	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Hyundai	2009	Genesis	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2009	Santa Fe	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2009	Sonata	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Hyundai	2009	Tucson	X				
				ABS/ESC	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ELECTRONIC TIME ALARM CONTROL	X		X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2009	Veracruz	X				
				4WD	X	X	
				ABS/ESC	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	
				ENGINE	X	X	X

				GLOBAL OBDII	X	X	X
				SMART KEY UNIT	X	X	
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Hyundai	2008	Accent (MC)	X				
				ABS	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2008	Azera (TG)	X				
				ABS/ESC	X	X	X
				AHLS	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2008	Elantra (HD)	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Hyundai	2008	Entourage (EP)	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				PST	X	X	
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Hyundai	2008	SantaFe (CM)	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2008	Sonata (NF)	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Hyundai	2008	Tiburon (GK)	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X

Hyundai	2008	Tucson (JM)	X				
				ABS/ESC	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ELECTRONIC TIME ALARM CONTROL	X		X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2008	VeraCruz (EN)	X				
				4WD	X	X	
				ABS/ESC	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				SMART KEY UNIT	X	X	
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Hyundai	2007	Accent (MC)	X				
				ABS	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				EPS	X	X	
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2007	Azera (TG)	X				
				ABS/ESC	X	X	X
				AHLS	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				Hyundai	2007	Elantra (HD)	X
ABS/ESC	X	X	X				
AIR CONDITIONING	X	X					
AIRBAG	X	X					
BODY CONTROL MODULE	X						
ELECTRONIC POWER STEERING	X	X					
ENGINE	X	X	X				
GLOBAL OBDII	X	X	X				
TPMS	X	X	X				
TRANSMISSION	X	X	X				
WEIGHT CLASS MODULE	X	X					
Hyundai	2007	Entourage (EP)	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				PST	X	X	
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
				Hyundai	2007	SantaFe (CM)	X
ABS/ESC	X	X	X				
AIR CONDITIONING	X	X					
AIRBAG	X	X					
BODY CONTROL MODULE	X		X				
ENGINE	X	X	X				
GLOBAL OBDII	X	X	X				
TPMS	X	X	X				
TRANSMISSION	X	X	X				
Hyundai	2007	Sonata (NF)	X				
				ABS/ESC	X	X	X

				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2007	Tiburon (GK)	X				
				ABS	X	X	X
				AHLS	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2007	Tucson (JM)	X				
				ABS/ESC	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ELECTRONIC TIME ALARM CONTROL	X		X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2007	VeraCruz (EN)	X				
				4WD	X	X	
				ABS/ESC	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				SMART KEY UNIT	X	X	
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Hyundai	2006	Accent (LC)	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2006	Accent (MC)	X				
				ABS	X	X	
				AIR CONDITIONING	X	X	
				ENGINE	X	X	X
				EPS	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2006	Azera (TG)	X				
				ABS/ESC	X	X	X
				AHLS	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2006	Elantra (XD)	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TCS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2006	SantaFe (SM)	X				
				ABS/ESC	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TCS	X	X	X
				TRANSMISSION	X	X	X

Hyundai	2006	Sonata (NF)	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2006	Tiburon (GK)	X				
				ABS	X	X	X
				AHLS	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2006	Tucson (JM)	X				
				ABS/ESC	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ELECTRONIC TIME ALARM CONTROL	X		X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2005	Accent (LC)	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2005	Elantra (XD)	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TCS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2005	SantaFe (SM)	X				
				ABS	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TCS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2005	Sonata (EF)	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TCS	X	X	
				TRANSMISSION	X	X	X
Hyundai	2005	Tiburon (GK)	X				
				ABS	X	X	X
				AHLS	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2005	Tucson (JM)	X				
				ABS/ESC	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ELECTRONIC TIME ALARM CONTROL	X		X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2005	XG350 (XG)	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TCS	X	X	X
				TRANSMISSION	X	X	X

Hyundai	2004	Accent (LC)	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2004	Elantra (XD)	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TCS	X	X	X
Hyundai	2004	SantaFe (SM)	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TCS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2004	Sonata (EF)	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TCS	X	X	
Hyundai	2004	Tiburon (GK)	X				
				ABS	X	X	X
				AHLS	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2004	XG350 (XG)	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TCS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2003	Accent (LC)	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2003	Elantra (XD)	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TCS	X	X	X
Hyundai	2003	SantaFe (SM)	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TCS	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2003	Sonata (EF)	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TCS	X	X	
Hyundai	2003	Tiburon (GK)	X				
				ABS	X	X	X
				AHLS	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2003	XG350 (XG)	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TCS	X	X	X
				TRANSMISSION	X	X	X

Hyundai	2002	Accent (LC)	X				
				ABS	X	X	X
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2002	Elantra (XD)	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TCS	X	X	X
TRANSMISSION	X	X	X				
Hyundai	2002	SantaFe (SM)	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TCS	X	X	X
TRANSMISSION	X	X	X				
Hyundai	2002	Sonata (EF)	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
TCS	X	X					
Hyundai	2002	XG350 (XG)	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TCS	X	X	X
TRANSMISSION	X	X	X				
Hyundai	2001	Accent (LC)	X				
				ABS	X	X	X
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2001	Elantra (XD)	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TCS	X	X	X
TRANSMISSION	X	X	X				
Hyundai	2001	SantaFe (SM)	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TCS	X	X	X
TRANSMISSION	X	X	X				
Hyundai	2001	Sonata (EF)	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Hyundai	2001	Tiburon (RC)	X				
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2001	XG300 (XG)	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TCS	X	X	X
TRANSMISSION	X	X	X				
Hyundai	2000	Accent (LC)	X				
				ABS	X	X	X
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2000	Elantra (RD)	X				
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Hyundai	2000	Sonata (EF)	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Hyundai	2000	Tiburon (RC)	X				
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X

Hyundai	1999	Accent	X				
				GLOBAL OBDII	X	X	X
Hyundai	1999	Elantra (RD)	X				
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Hyundai	1999	Sonata (EF)	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Hyundai	1999	Tiburon (RC)	X				
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Hyundai	1998	Accent	X				
				GLOBAL OBDII	X	X	X
Hyundai	1998	Elantra (RD)	X				
				GLOBAL OBDII	X	X	X
Hyundai	1998	Sonata (Y3)	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Hyundai	1998	Tiburon (RC)	X				
				GLOBAL OBDII	X	X	X
Hyundai	1997	Accent	X				
				GLOBAL OBDII	X	X	X
Hyundai	1997	Elantra (RD)	X				
				GLOBAL OBDII	X	X	X
Hyundai	1997	Sonata (Y3)	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Hyundai	1997	Tiburon (RC)	X				
				GLOBAL OBDII	X	X	X
Hyundai	1996	Accent	X				
				GLOBAL OBDII	X	X	X
Hyundai	1996	Elantra (RD)	X				
				GLOBAL OBDII	X	X	X
Hyundai	1996	Sonata	X				
				GLOBAL OBDII	X	X	X
Hyundai	1994	Sonata	X				
				ENGINE	X	X	
Hyundai	1993	Elantra	X				
				ENGINE	X	X	
Hyundai	1993	Sonata	X				
				ENGINE	X	X	
Hyundai	1992	Elantra	X				
				ENGINE	X	X	
Hyundai	1992	Excel	X				
				ENGINE	X	X	
Hyundai	1992	Scoupe	X				
				ENGINE	X	X	
Hyundai	1992	Sonata	X				
				ENGINE	X	X	
Hyundai	1991	Excel	X				
				ENGINE	X	X	
Hyundai	1991	Scoupe	X				
				ENGINE	X	X	
Hyundai	1991	Sonata	X				
				ENGINE	X	X	
Infiniti	2013	EX37					
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Infiniti	2013	FX37					
				4WD	X	X	X
				4-Wheel Active Steer	X	X	
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Infiniti	2013	FX50					

			4WD	X	X	X
			4-Wheel Active Steer	X	X	
			ABS	X	X	X
			BODY CONTROL (TPMS)	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			HICAS	X	X	
			INTEGRATED POWER DIST MOD	X	X	X
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	
Infiniti	2013	G37				
			4WD	X	X	X
			4-Wheel Active Steer	X	X	
			ABS	X	X	X
			BODY CONTROL (TPMS)	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			HICAS	X	X	
			INTEGRATED POWER DIST MOD	X	X	X
			TRANSMISSION	X	X	
Infiniti	2013	JX35				
			4WD	X	X	X
			ABS	X	X	X
			BODY CONTROL (TPMS)	X	X	X
			ELECTRONIC POWER STEERING	X	X	
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			HVAC	X	X	X
			INTEGRATED POWER DIST MOD	X	X	X
			METER	X	X	
			TRANSMISSION	X	X	
Infiniti	2013	M35h				
			4-Wheel Active Steer	X	X	
			ABS	X	X	X
			BODY CONTROL (TPMS)	X	X	X
			ELECTRONIC POWER STEERING	X	X	
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			HVAC	X	X	X
			HYBRID CONTROL MODULE	X	X	
			INTEGRATED POWER DIST MOD	X	X	X
			Li-ION BATTERY CONTROL	X	X	
			METER	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	
Infiniti	2013	M37				
			4WD	X	X	X
			4-Wheel Active Steer	X	X	
			ABS	X	X	X
			BODY CONTROL (TPMS)	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			HICAS	X	X	
			HVAC	X	X	X
			INTEGRATED POWER DIST MOD	X	X	X
			METER	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	
Infiniti	2013	M56				
			4WD	X	X	X
			4-Wheel Active Steer	X	X	
			ABS	X	X	X
			BODY CONTROL (TPMS)	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			HICAS	X	X	
			HVAC	X	X	X
			INTEGRATED POWER DIST MOD	X	X	X
			METER	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	
Infiniti	2013	QX56				
			4WD	X	X	X
			ABS	X	X	X

				Air Level Suspension	X	X	
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2012	EX35	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Infiniti	2012	FX35	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2012	FX50	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2012	G25	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Infiniti	2012	G37	X				
				4WD	X	X	X
				4-Wheel Active Steer	X	X	
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Infiniti	2012	M35h					
				4-Wheel Active Steer	X	X	
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRIC BRAKE CONTROL	X	X	
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				HYBRID CONTROL MODULE	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				Li-ION BATTERY CONTROL	X	X	
				METER	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2012	M37	X				
				4WD	X	X	X
				4-Wheel Active Steer	X	X	
				ABS	X	X	X

				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2012	M56	X				
				4WD	X	X	X
				4-Wheel Active Steer	X	X	
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2012	QX56	X				
				4WD	X	X	X
				ABS	X	X	X
				Air Level Suspension	X	X	
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2011	EX35	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Infiniti	2011	FX35	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				S-ABS	X	X	
				TRANSMISSION	X	X	
Infiniti	2011	FX50	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				S-ABS	X	X	
				TRANSMISSION	X	X	
Infiniti	2011	G25	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
Infiniti	2011	G37	X				
				4WD	X	X	X
				4-Wheel Active Steer	X	X	
				ABS	X	X	X

				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Infiniti	2011	M37	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2011	M56	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2011	QX56	X				
				ABS	X	X	X
				Air Level Suspension	X	X	
				ALL MODE 4WD	X	X	
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2010	EX35	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Infiniti	2010	FX35	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				S-ABS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2010	FX50	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				S-ABS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2010	G37	X				
				4WD	X	X	X
				4-Wheel Active Steer	X	X	
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X

				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Infiniti	2010	M35	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Infiniti	2010	M45	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Infiniti	2010	QX56	X				
				4WD	X	X	X
				ABS	X	X	X
				ALL MODE 4WD	X	X	
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Infiniti	2009	EX35	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Infiniti	2009	FX35	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				S-ABS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2009	FX50	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				S-ABS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2009	G37	X				
				4WD	X	X	X
				4-Wheel Active Steer	X	X	
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Infiniti	2009	M35	X				

				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2009	M45	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2009	QX56	X				
				ABS	X	X	X
				ALL MODE 4WD	X	X	
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Infiniti	2008	EX35	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Infiniti	2008	FX35	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2008	FX45	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2008	G35 Sedan	X				
				4WD	X	X	X
				4-Wheel Active Steer	X	X	
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Infiniti	2008	G37	X				
				4WD	X	X	X
				4-Wheel Active Steer	X	X	
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X

				TRANSMISSION	X	X	
Infiniti	2008	M35	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2008	M45	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2008	QX56	X				
				4WD	X	X	X
				ABS	X	X	X
				Air Level Suspension	X	X	X
				ALL MODE 4WD	X	X	
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Infiniti	2007	FX35	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2007	FX45	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2007	G35 Coupe	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	2007	G35 Sedan	X				
				4WD	X	X	X
				4-Wheel Active Steer	X	X	
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Infiniti	2007	M35	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				TIRE PRESSURE MONITOR	X	X	X

				TRANSMISSION	X	X	
Infiniti	2007	M45	X	4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2007	QX56	X	4WD	X	X	X
				ABS	X	X	X
				Air Level Suspension	X	X	X
				ALL MODE 4WD	X	X	
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Infiniti	2006	FX35	X	4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2006	FX45	X	4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2006	G35	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2006	M35	X	4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2006	M45	X	4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HICAS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2006	Q45	X	ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2006	QX56	X	4WD	X	X	X
				ABS	X	X	X
				Air Level Suspension	X	X	X
				ALL MODE 4WD	X	X	
				BODY CONTROL (TPMS)	X	X	X

				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	2005	FX35	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2005	FX45	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2005	G35	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2005	M45	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2005	Q45	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	
Infiniti	2005	QX56	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2004	FX35	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2004	FX45	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2004	G35	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2004	I35	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	2004	M45	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	

Infiniti	2004	Q45	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	
Infiniti	2004	QX56	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2003	FX35					
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Infiniti	2003	FX45	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Infiniti	2003	G35					
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2003	I35	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2003	M45	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	
Infiniti	2003	Q45	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	
Infiniti	2003	QX4					
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Infiniti	2002	G20	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	
Infiniti	2002	I35					
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Infiniti	2002	Q45	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	
				ABS	X	X	X
Infiniti	2002	QX4					
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X

				TRANSMISSION	X	X	
Infiniti	2001	G20	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	2001	G20t	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	2001	I30	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	2001	I30t	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	2001	Q45	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	2001	Q45t	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	2001	QX4	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	2000	G20	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	2000	G20t	X	ENGINE	X	X	X
				TRANSMISSION	X	X	
Infiniti	2000	I30	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	2000	I30t	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	2000	Q45	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	2000	Q45t	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	2000	QX4	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	1999	G20	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	

Infiniti	1999	I30	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	1999	I30t	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	1999	Q45	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	1999	Q45t	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	1999	QX4	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	1998	I30	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	1998	I30t	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	1998	Q45	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	1998	Q45t	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	1998	QX4	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	1997	I30	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	1997	J30	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	1997	Q45	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	1997	QX4	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	1996	G20	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X

				TRANSMISSION	X	X	
Infiniti	1996	I30	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	1996	J30	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	1996	Q45	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Infiniti	1995	G20	X	ABS	X	X	X
				ENGINE	X	X	X
				TRANSMISSION	X	X	
Infiniti	1995	J30	X	ABS	X	X	X
				ENGINE	X	X	X
				TRANSMISSION	X	X	
Infiniti	1995	Q45	X	ABS	X	X	X
				ENGINE	X	X	X
				TRANSMISSION	X	X	
Infiniti	1994	G20	X	ABS	X	X	X
				ENGINE	X	X	X
				TRANSMISSION	X	X	
Infiniti	1994	J30	X	ABS	X	X	X
				ENGINE	X	X	X
				TRANSMISSION	X	X	
Infiniti	1994	Q45	X	ABS	X	X	X
				ENGINE	X	X	X
				TRANSMISSION	X	X	
Infiniti	1993	G20	X	ENGINE	X	X	X
				TRANSMISSION	X	X	
Infiniti	1993	J30	X	ENGINE	X	X	X
				TRANSMISSION	X	X	
Infiniti	1993	Q45	X	ENGINE	X	X	X
				TRANSMISSION	X	X	
Infiniti	1992	G20	X	ENGINE	X	X	X
Infiniti	1992	M30	X	ENGINE	X	X	X
				TRANSMISSION	X	X	
Infiniti	1992	Q45	X	ENGINE	X	X	X
				TRANSMISSION	X	X	
Infiniti	1991	G20	X	ENGINE	X	X	X
Infiniti	1991	M30	X	ENGINE	X	X	X
				TRANSMISSION	X	X	
Infiniti	1991	Q45	X	ENGINE	X	X	X
				TRANSMISSION	X	X	
Infiniti	1990	M30	X	ENGINE	X	X	X
				TRANSMISSION	X	X	
Infiniti	1990	Q45	X	ENGINE	X	X	X
				TRANSMISSION	X	X	
Isuzu	2008	Ascender	X	ABS/TCS/VSES	X	X	X
				AIRBAG	X	X	

				BODY CONTROL	X	X	
				DIGITAL RADIO RECEIVER	X	X	
				DRIVER SEAT MODULE	X	X	
				DRIVERS DOOR MODULE	X	X	
				ENGINE	X	X	X
				GEN BATT CONTROL MODULE	X	X	
				GLOBAL OBDII	X	X	X
				HEAT VENT A/C	X	X	X
				INST PANEL CLUSTER	X	X	X
				LIFTGATE MODULE	X	X	X
				NAVIGATION RADIO	X	X	
				PSG DOOR MOD	X	X	
				REAR SEAT AUDIO	X	X	
				THEFT DETERRENT MODULE	X	X	
				TRANSFER CASE	X	X	X
				TRANSMISSION	X	X	X
				UPELVEL RADIO	X	X	
				VEH COMM INTERFACE MOD	X	X	
Isuzu	2008	I-290		AIRBAG	X	X	
				BASE RADIO	X	X	
				BODY CONTROL	X	X	X
				DIGITAL RADIO RECEIVER	X	X	
				ELEC BRAKE CTRL MOD	X	X	X
				ENGINE	X	X	X
				GEN BATT CONTROL MODULE	X	X	
				GLOBAL OBDII	X	X	X
				INST PANEL CLUSTER	X	X	X
				TRANSMISSION	X	X	X
				UPELVEL RADIO	X	X	
				VEH COMM INTERFACE MOD	X	X	
Isuzu	2008	I-370		AIRBAG	X	X	
				BASE RADIO	X	X	
				BODY CONTROL	X	X	X
				DIGITAL RADIO RECEIVER	X	X	
				ELEC BRAKE CTRL MOD	X	X	X
				ENGINE	X	X	X
				GEN BATT CONTROL MODULE	X	X	
				GLOBAL OBDII	X	X	X
				INST PANEL CLUSTER	X	X	X
				TRANSMISSION	X	X	X
				UPELVEL RADIO	X	X	
				VEH COMM INTERFACE MOD	X	X	
Isuzu	2007	Ascender	X	AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	
				CLIMATE (HVAC)	X	X	X
				DIGITAL RADIO	X	X	
				DRIVER SEAT MODULE	X	X	
				DRIVERS DOOR MODULE	X	X	
				ELECTRONIC BRAKE CONTROL	X	X	X
				ENGINE	X	X	X
				GEN BATT CONTROL MODULE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL CLUSTER	X	X	X
				LIFTGATE MODULE (TPMS)	X	X	X
				NAVIGATION RADIO	X	X	
				PASSENGER DOOR MODULE	X	X	
				REAR SEAT AUDIO	X	X	
				THEFT DETERRENT MODULE	X	X	
				TRANSFER CASE	X	X	X
				TRANSMISSION	X	X	X
				UPELVEL RADIO	X	X	
				VEHICLE COMM INTERFACE MODULE	X	X	
Isuzu	2007	I-290	X	AIRBAG	X	X	
				BASE RADIO	X	X	
				BODY CONTROL (TPMS)	X	X	X
				DIGITAL RADIO	X	X	
				ELECTRONIC BRAKE CONTROL	X	X	X
				ENGINE	X	X	X
				GEN BATT CONTROL MODULE	X	X	
				GLOBAL OBDII	X	X	X

				INSTRUMENT PANEL CLUSTER	X	X	X
				TRANSMISSION	X	X	X
				UPELVEL RADIO	X	X	
				VEHICLE COMM INTERFACE MODULE	X	X	
Isuzu	2007	I-370	X	AIRBAG	X	X	
				BASE RADIO	X	X	
				BODY CONTROL (TPMS)	X	X	X
				BODY CONTROL MODULE	X	X	X
				DIGITAL RADIO	X	X	
				ELECTRONIC BRAKE CONTROL	X	X	X
				ENGINE	X	X	X
				GEN BATT CONTROL MODULE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL CLUSTER	X	X	X
				TRANSMISSION	X	X	X
				UPELVEL RADIO	X	X	
				VEHICLE COMM INTERFACE MODULE	X	X	
Isuzu	2006	Ascender	X	ABS/TCS/VSES	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	
				BODY/ENTERTAINMENT	X	X	
				CLIMATE (HVAC)	X	X	X
				DIGITAL RADIO	X	X	
				DRIVER SEAT MODULE	X	X	
				DRIVERS DOOR MODULE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL CLUSTER	X	X	X
				LIFTGATE MODULE	X	X	
				PASSENGER DOOR MODULE	X	X	
				PCM	X	X	X
				REAR SEAT AUDIO	X	X	
				THEFT DETERRENT MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSFER CASE	X	X	X
				TRANSMISSION	X	X	X
				UPELVEL RADIO	X	X	
				VEHICLE COMM INTERFACE MODULE	X	X	
Isuzu	2006	I-280	X	ABS	X	X	X
				AIRBAG	X	X	
				BASE RADIO	X	X	
				BODY CONTROL MODULE	X	X	
				DIGITAL RADIO	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL CLUSTER	X	X	X
				PCM	X	X	X
				UPELVEL RADIO	X	X	
				VEHICLE COMM INTERFACE MODULE	X	X	
Isuzu	2006	I-350	X	ABS	X	X	X
				AIRBAG	X	X	
				BASE RADIO	X	X	
				BODY CONTROL MODULE	X	X	
				DIGITAL RADIO	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL CLUSTER	X	X	X
				PCM	X	X	X
				UPELVEL RADIO	X	X	
				VEHICLE COMM INTERFACE MODULE	X	X	
Isuzu	2005	Ascender	X	ABS	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	
				CLIMATE (HVAC)	X	X	X
				DIGITAL RADIO	X	X	
				DRIVERS DOOR MODULE	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL CLUSTER	X	X	X
				LIFTGATE MODULE	X	X	
				NAVIGATION RADIO	X	X	
				PASSENGER DOOR MODULE	X	X	

				PCM	X	X	X
				REAR SEAT AUDIO	X	X	
				THEFT DETERRENT MODULE	X	X	
				TRACTION ASSIST	X	X	
				TRANSFER CASE	X	X	X
				TRANSMISSION	X	X	X
				UPELVEL RADIO	X	X	
				VEHICLE COMM INTERFACE MODULE	X	X	
Isuzu	2004	Ascender	X				
				ABS	X	X	X
				AIRBAG	X	X	
				AMPLIFIER	X	X	
				BODY CONTROL MODULE	X	X	
				CLIMATE (HVAC)	X	X	X
				DRIVER SEAT MODULE	X	X	
				DRIVERS DOOR MODULE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL CLUSTER	X	X	X
				LIFTGATE MODULE	X	X	
				NAVIGATION RADIO	X	X	
				ONSTAR	X	X	
				PASSENGER DOOR MODULE	X	X	
				PCM	X	X	X
				REAR SEAT AUDIO	X	X	
				THEFT DETERRENT MODULE	X	X	
				TRACTION ASSIST	X	X	
				TRANSFER CASE	X	X	X
				UPELVEL RADIO	X	X	
				VEHICLE COMM INTERFACE MODULE	X	X	
Isuzu	2004	Axiom	X				
				GLOBAL OBDII	X	X	X
Isuzu	2004	Rodeo	X				
				GLOBAL OBDII	X	X	X
Isuzu	2003	Ascender	X				
				ABS	X	X	X
				BASE RADIO	X	X	
				BODY CONTROL MODULE	X	X	
				CLIMATE (HVAC)	X	X	X
				DRIVERS DOOR MODULE	X	X	
				DRV SEAT MOD/MEM SEAT MOD	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL CLUSTER 1	X	X	X
				LIFTGATE MODULE	X	X	
				ONSTAR	X	X	
				PASSENGER DOOR MODULE	X	X	
				PASSENGER SEAT	X	X	
				PCM	X	X	X
				REAR HVAC	X	X	
				THEFT DETERRENT MODULE	X	X	
				TRACTION ASSIST	X	X	
Isuzu	2003	Axiom	X				
				GLOBAL OBDII	X	X	X
Isuzu	2003	Rodeo	X				
				GLOBAL OBDII	X	X	X
Isuzu	2003	Rodeo Sport	X				
				GLOBAL OBDII	X	X	X
Isuzu	2002	Axiom	X				
				GLOBAL OBDII	X	X	X
Isuzu	2002	Rodeo	X				
				GLOBAL OBDII	X	X	X
Isuzu	2002	Rodeo Sport	X				
				GLOBAL OBDII	X	X	X
Isuzu	2002	Trooper	X				
				GLOBAL OBDII	X	X	X
Isuzu	2001	Rodeo	X				
				GLOBAL OBDII	X	X	X
Isuzu	2001	Rodeo Sport	X				
				GLOBAL OBDII	X	X	X
Isuzu	2001	Trooper	X				
				GLOBAL OBDII	X	X	X
Isuzu	2001	VehiCross	X				
				GLOBAL OBDII	X	X	X
Isuzu	2000	Amigo	X				
				ENGINE	X	X	

				GLOBAL OBDII	X	X	X
Isuzu	2000	Hombre	X				
				ABS	X	X	X
				BODY CONTROL MODULE	X	X	X
				CLIMATE (HVAC)	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL CLUSTER	X	X	X
				PCM	X	X	X
Isuzu	2000	Rodeo	X				
				ABS (4WAL)	X	X	X
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Isuzu	2000	Trooper	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Isuzu	2000	VehiCross	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Isuzu	1999	Amigo	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Isuzu	1999	Hombre	X				
				ABS (4WAL)	X	X	X
				AIRBAG	X	X	
				GLOBAL OBDII	X	X	X
				PCM	X	X	X
Isuzu	1999	Oasis	X				
				GLOBAL OBDII	X	X	X
Isuzu	1999	Rodeo	X				
				ABS (4WAL)	X	X	X
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Isuzu	1999	Trooper	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Isuzu	1999	VehiCross	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Isuzu	1998	Amigo	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Isuzu	1998	Hombre	X				
				ABS (4WAL)	X	X	X
				AIRBAG	X	X	
				GLOBAL OBDII	X	X	X
				PCM	X	X	X
Isuzu	1998	Oasis	X				
				GLOBAL OBDII	X	X	X
Isuzu	1998	Rodeo	X				
				ABS (4WAL)	X	X	X
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Isuzu	1998	Trooper	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Isuzu	1997	Hombre	X				
				AIRBAG	X	X	
				GLOBAL OBDII	X	X	X
				PCM	X	X	X
Isuzu	1997	Oasis	X				
				GLOBAL OBDII	X	X	X
Isuzu	1997	Rodeo	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Isuzu	1997	Trooper	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Isuzu	1996	Hombre	X				
				AIRBAG	X	X	
				GLOBAL OBDII	X	X	X
				PCM	X	X	X
Isuzu	1996	Oasis	X				
				GLOBAL OBDII	X	X	X
Isuzu	1996	Rodeo	X				

				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Isuzu	1996	Trooper	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Isuzu	1995	Pickup 2WD	X				
				ENGINE	X	X	
Isuzu	1995	Pickup 4WD	X				
				ENGINE	X	X	
Isuzu	1995	Rodeo 2WD	X				
				ENGINE	X	X	
Isuzu	1995	Rodeo 4WD	X				
				ENGINE	X	X	
Isuzu	1994	Amigo	X				
				ENGINE	X	X	
Isuzu	1994	Pickup 2WD	X				
				ENGINE	X	X	
Isuzu	1994	Pickup 4WD	X				
				ENGINE	X	X	
Isuzu	1993	Amigo	X				
				ENGINE	X	X	
Isuzu	1993	Pickup	X				
				ENGINE	X	X	
Isuzu	1993	Rodeo	X				
				ENGINE	X	X	
Isuzu	1993	Stylus	X				
				ENGINE	X	X	
Isuzu	1992	Amigo	X				
				ENGINE	X	X	
Isuzu	1992	Impulse	X				
				ENGINE	X	X	
Isuzu	1992	Pickup	X				
				ENGINE	X	X	
Isuzu	1992	Rodeo	X				
				ENGINE	X	X	
Isuzu	1992	Stylus	X				
				ENGINE	X	X	
Isuzu	1991	Amigo	X				
				ENGINE	X	X	
Isuzu	1991	Impulse	X				
				ENGINE	X	X	
Isuzu	1991	Pickup	X				
				ENGINE	X	X	
Isuzu	1991	Rodeo	X				
				ENGINE	X	X	
Isuzu	1991	Stylus	X				
				ENGINE	X	X	
Isuzu	1991	Trooper	X				
				ENGINE	X	X	
Isuzu	1990	Amigo	X				
				ENGINE	X	X	
Isuzu	1990	Impulse	X				
				ENGINE	X	X	
Isuzu	1990	Pickup	X				
				ENGINE	X	X	
Isuzu	1990	Stylus	X				
				ENGINE	X	X	
Isuzu	1990	Trooper	X				
				ENGINE	X	X	
Isuzu	1989	Amigo	X				
				ENGINE	X	X	
Isuzu	1989	I-Mark	X				
				ENGINE	X	X	
Isuzu	1989	Impulse	X				
				ENGINE	X	X	
Isuzu	1989	Pickup	X				
				ENGINE	X	X	
Isuzu	1989	Trooper	X				
				ENGINE	X	X	
Isuzu	1988	I-Mark	X				
				ENGINE	X	X	
Isuzu	1988	Impulse	X				
				ENGINE	X	X	
Isuzu	1988	Pup	X				

				ENGINE	X	X	
Isuzu	1988	Trooper	X	ENGINE	X	X	
Isuzu	1987	I-Mark	X	ENGINE	X	X	
Kia	2013	Forte		ENGINE	X	X	
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ELECTRONIC POWER STEERING	X	X	X
				ELECTRONIC STABILITY CONTROL	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				SMART KEY UNIT	X	X	
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Kia	2013	Optima		ABS/ESC	X	X	X
				ACTIVE AIR FLAP	X	X	
				ACTIVE HYDRAULIC BOOSTER	X	X	
				AHLS	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ELECTRIC PARKING BRAKE	X	X	X
				ELECTRONIC POWER STEERING	X	X	X
				ELECTRONIC STABILITY CONTROL	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HEV BATTERY SYSTEM	X	X	X
				HEV CONTROL SYSTEM	X	X	
				HEV MOTOR SYSTEM	X	X	
				IMMOBILIZER	X		
				LOW DC CONVERTER	X	X	
				SMART KEY UNIT	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Kia	2013	Rio		ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				SMART KEY UNIT	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Kia	2013	Sorento		4WD	X	X	
				ABS	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				ELECTRONIC STABILITY CONTROL	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X		
				INSTRUMENT PANEL MODULE	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2013	Soul		ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ELECTRONIC POWER STEERING	X	X	X
				ELECTRONIC STABILITY CONTROL	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X

				POWER DISTRIBUTION MODULE	X			
				SMART KEY UNIT	X	X		
				TPMS	X	X	X	
				TRANSMISSION	X	X	X	
				WEIGHT CLASS MODULE	X	X		
Kia	2013	Sportage						
				4WD	X	X		
				ABS/ESC	X	X	X	
				AIR CONDITIONING	X	X	X	
				AIRBAG	X	X		
				BODY CONTROL MODULE	X	X	X	
				ELECTRONIC POWER STEERING	X	X		
				ENGINE	X	X	X	
				GLOBAL OBDII	X	X	X	
				IMMOBILIZER	X			
				SMART KEY UNIT	X	X	X	
				TPMS	X	X	X	
				TRANSMISSION	X	X	X	
Kia	2012	Forte	X					
				ABS/ESC	X	X	X	
				AIR CONDITIONING	X	X	X	
				AIRBAG	X	X		
				BODY CONTROL MODULE	X		X	
				ELECTRONIC POWER STEERING	X	X	X	
				ENGINE	X	X	X	
				GLOBAL OBDII	X	X	X	
				SMART KEY UNIT	X	X		
				TPMS	X	X	X	
				TRANSMISSION	X	X	X	
				WEIGHT CLASS MODULE	X	X		
Kia	2012	Optima	X					
				ABS/ESC	X	X	X	
				ACTIVE AIR FLAP	X	X		
				ACTIVE HYDRAULIC BOOSTER	X	X		
				AHLS	X	X	X	
				AIR CONDITIONING	X	X	X	
				AIRBAG	X	X		
				BODY CONTROL MODULE	X	X	X	
				ELECTRONIC POWER STEERING	X	X	X	
				ENGINE	X	X	X	
				GLOBAL OBDII	X	X	X	
				HEV BATTERY SYSTEM	X	X	X	
				HEV CONTROL SYSTEM	X	X		
				HEV MOTOR SYSTEM	X	X		
				LOW DC DC CONVERTER	X	X		
				SMART KEY UNIT	X	X	X	
				TPMS	X	X	X	
				TRANSMISSION	X	X	X	
				WEIGHT CLASS MODULE	X	X		
Kia	2012	Rio	X					
				ABS/ESC	X	X	X	
				AIR CONDITIONING	X	X	X	
				AIRBAG	X	X		
				BODY CONTROL MODULE	X	X	X	
				ELECTRONIC POWER STEERING	X	X		
				ENGINE	X	X	X	
				GLOBAL OBDII	X	X	X	
				IMMOBILIZER	X	X		
				SMART KEY UNIT	X	X	X	
				TPMS	X	X	X	
				TRANSMISSION	X	X	X	
				WEIGHT CLASS MODULE	X	X		
Kia	2012	Sedona	X					
				ABS/ESC	X	X	X	
				AIR CONDITIONING	X	X	X	
				AIRBAG	X	X		
				BODY CONTROL MODULE	X	X	X	
				ENGINE	X	X	X	
				GLOBAL OBDII	X	X	X	
				POWER SLIDING DOOR	X	X		
				POWER TAIL GATE	X	X		
				TPMS	X	X	X	
				TRANSMISSION	X	X	X	
				WEIGHT CLASS MODULE	X	X		

Kia	2012	Sorento	X				
				4WD	X	X	
				ABS	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL MODULE	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				Kia	2012	Soul	X
ABS/ESC	X	X	X				
AIR CONDITIONING	X	X	X				
AIRBAG	X	X					
BODY CONTROL MODULE	X		X				
ELECTRONIC POWER STEERING	X	X	X				
ENGINE	X	X	X				
GLOBAL OBDII	X	X	X				
POWER DISTRIBUTION MODULE	X						
SMART KEY UNIT	X	X					
TPMS	X	X	X				
TRANSMISSION	X	X	X				
WEIGHT CLASS MODULE	X	X					
Kia	2012	Sportage	X				
				4WD	X	X	
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				SMART KEY UNIT	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				Kia	2011	Forte	X
ABS/ESC	X	X	X				
AIR CONDITIONING	X	X	X				
AIRBAG	X	X					
BODY CONTROL MODULE	X		X				
ELECTRONIC POWER STEERING	X	X	X				
ENGINE	X	X	X				
GLOBAL OBDII	X	X	X				
POWER DISTRIBUTION MODULE	X						
SMART KEY UNIT	X	X					
TPMS	X	X	X				
TRANSMISSION	X	X	X				
WEIGHT CLASS MODULE	X	X					
Kia	2011	Optima	X				
				ABS/ESC	X	X	X
				ACTIVE AIR FLAP	X	X	
				ACTIVE HYDRAULIC BOOSTER	X	X	
				AHLS	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ELECTRONIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HEV BATTERY SYSTEM	X	X	X
				HEV CONTROL SYSTEM	X	X	
				HEV MOTOR SYSTEM	X	X	
				LOW DC DC CONVERTER	X	X	
				SMART KEY UNIT	X	X	X
				TPMS	X	X	X
TRANSMISSION	X	X	X				
WEIGHT CLASS MODULE	X	X					
Kia	2011	Rio	X				
				ABS	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
GLOBAL OBDII	X	X	X				

				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2011	Rio5	X				
				ABS	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2011	Sedona	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				POWER SLIDING DOOR	X	X	
				POWER TAIL GATE	X	X	
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Kia	2011	Sorento	X				
				4WD	X	X	
				ABS	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL MODULE	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2011	Soul	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ELECTRONIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				POWER DISTRIBUTION MODULE	X		
				SMART KEY UNIT	X	X	
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Kia	2011	Sportage	X				
				4WD	X	X	
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				SMART KEY UNIT	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2010	Borrego	X				
				ABS/ESC	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2010	Forte	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ELECTRONIC POWER STEERING	X	X	

				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Kia	2010	Forte Koup	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Kia	2010	Optima	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ELECTRONIC CONTROL SUSPENSION	X		
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2010	Rio	X				
				ABS	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2010	Rio5	X				
				ABS	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2010	Rondo	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Kia	2010	Sedona	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				PST	X	X	
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Kia	2010	Soul	X				
				ABS/ESC	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	

Kia	2010	Sportage	X				
				4WD	X	X	
				ABS	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	
				ELECTRONIC TIME ALARM CONTROL	X		X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2009	Amanti	X				
				ABS/ESC	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2009	Borrego	X				
				ABS/ESC	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2009	Optima	X				
				ABS	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ELECTRONIC CONTROL SUSPENSION	X		
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
TRANSMISSION	X	X	X				
Kia	2009	Rio	X				
				ABS/ESC	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2009	Rio5	X				
				ABS/ESC	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
TRANSMISSION	X	X	X				
Kia	2009	Rondo	X				
				ABS/ESC	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Kia	2009	Sedona	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
PST	X	X					

				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Kia	2009	Sorento	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2009	Spectra	X				
				ABS	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2009	Spectra5	X				
				ABS	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2009	Sportage	X				
				ABS	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ELECTRONIC TIME ALARM CONTROL	X		X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2008	Amanti (GH)					
				ABS/ESC	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2008	Optima (MG)	X				
				ABS	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		
				ELECTRONIC CONTROL SUSPENSION	X	X	
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2008	Rio (JB)	X				
				ABS/ESC	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2008	Rio5	X				
				ABS/ESC	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X

Kia	2008	Rondo (UN)	X				
				ABS/ESC	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Kia	2008	Sedona (VQ)	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				PST	X	X	
				TPMS	X	X	X
				TRANSMISSION	X	X	X
WEIGHT CLASS MODULE	X	X					
Kia	2008	Sorento (BL)	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2008	Spectra (LD)	X				
				ABS	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2008	Spectra5	X				
				ABS	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
TRANSMISSION	X	X	X				
Kia	2008	Sportage (KM)	X				
				ABS	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
TRANSMISSION	X	X	X				
Kia	2007	Amanti (GH)					
				ABS/ESC	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE	X	X	X
				EPS	X	X	
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
TRANSMISSION	X	X	X				
Kia	2007	Optima (MG)	X				
				ABS	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		
				ELECTRONIC CONTROL SUSPENSION	X	X	
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
TPMS	X	X	X				

				TRANSMISSION	X	X	X
Kia	2007	Rio (JB)	X	ABS/ESC	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2007	Rondo (UN)	X	ABS/ESC	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Kia	2007	Sedona (VQ)	X	ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Kia	2007	Sorento (BL)	X	ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2007	Spectra (LD)	X	ABS	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2007	Sportage (KM)	X	ABS	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2006	Amanti (GH)	X	ABS/ESC	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE	X	X	X
				EPS	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Kia	2006	Optima (MG)	X	ABS/ESC	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				BODY CONTROL MODULE	X		
				ENGINE	X	X	X
				EPS	X	X	
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2006	Optima (MS)	X	ABS	X	X	X

				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Kia	2006	Rio (JB)	X				
				ABS/ESC	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2006	Sedona (VQ)	X				
				ABS/ESC	X	X	X
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
				WEIGHT CLASS MODULE	X	X	
Kia	2006	Sorento (BL)	X				
				ABS	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				EPS	X	X	
				GLOBAL OBDII	X	X	X
Kia	2006	Spectra (LD)	X				
				ABS	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Kia	2006	Sportage (KM)	X				
				ABS	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2005	Amanti (GH)	X				
				ABS/ESC	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE	X	X	X
				EPS	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Kia	2005	Optima (MS)	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Kia	2005	Rio (BC)	X				
				ABS	X	X	X
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Kia	2005	Sedona (GQ)	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Kia	2005	Sorento (BL)	X				
				ABS	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				EPS	X	X	
				GLOBAL OBDII	X	X	X
Kia	2005	Spectra (LD)	X				
				ABS	X	X	

				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Kia	2005	Sportage (KM)	X				
				ABS	X	X	
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TPMS	X	X	X
				TRANSMISSION	X	X	X
Kia	2004	Amanti (GH)					
				ABS/ESC	X	X	X
				AIRBAG	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE	X	X	X
				EPS	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Kia	2004	Optima (MS)	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Kia	2004	Rio (BC)	X				
				ABS	X	X	X
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Kia	2004	Sedona (GQ)	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Kia	2004	Sorento (BL)	X				
				ABS	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				EPS	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Kia	2004	Spectra (LD)	X				
				ABS	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Kia	2004	Spectra (SD)	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Kia	2003	Optima (MS)	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Kia	2003	Rio (BC)	X				
				ABS	X	X	X
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Kia	2003	Sedona (GQ)	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Kia	2003	Sorento (BL)	X				
				ABS	X	X	
				AIRBAG	X	X	

				ENGINE	X	X	X
				EPS	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Kia	2003	Spectra (SD)	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Kia	2002	Optima (MS)	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Kia	2002	Rio (BC)	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Kia	2002	Sedona (GQ)	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Kia	2002	Spectra (SD)	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Kia	2002	Sportage (AL)	X				
				ABS	X	X	
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Kia	2001	Optima (MS)	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Kia	2001	Rio (BC)	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Kia	2001	Sephia (UK)	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Kia	2001	Spectra (SD)	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Kia	2001	Sportage (AL)	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Kia	2000	Sephia (UK)	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Kia	2000	Spectra (SD)	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Kia	2000	Sportage (AL)	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Kia	1999	Sephia (FB)	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Kia	1999	Sportage (AL)	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X

				TRANSMISSION	X	X	
Kia	1998	Sephia (FB)	X	ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Kia	1998	Sportage (AL)	X	ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Kia	1997	Sephia (FB)	X	ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Kia	1997	Sportage (AL)	X	ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Kia	1996	Sephia (FB)	X	ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Kia	1996	Sportage (AL)	X	ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Kia	1995	Sephia (FB)	X	ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Kia	1995	Sportage (AL)	X	ENGINE	X	X	
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Kia	1994	Sephia (FB)	X	ENGINE	X	X	
				TRANSMISSION	X	X	
Lexus	2014	CT200h		ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Lexus	2014	ES300h		ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				REMOTE ENGINE STARTER	X	X	

			SMART KEY	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
Lexus	2014	ES350				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			GATEWAY CAN	X	X	
			GLOBAL OBDII	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			POWER SOURCE CONTROL	X	X	
			PRE-COLLISION	X	X	
			PRE-COLLISION 2	X	X	
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			STARTING CONTROL	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X
Lexus	2014	GS350				
			4WD	X	X	X
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIR SUSPENSION	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			DYNAMIC REAR STEERING	X	X	
			ELECTRIC PARKING BRAKE	X	X	X
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GATEWAY CAN	X	X	
			GLOBAL OBDII	X	X	X
			METER	X	X	X
			MULTI BUS GATEWAY	X	X	
			MULTI BUS MONITOR NO.1	X	X	
			MULTI BUS MONITOR NO.2	X	X	
			OCCUPANT CLASSIFICATION	X	X	X
			POWER SOURCE CONTROL	X	X	
			PRE-COLLISION	X	X	
			PRE-COLLISION 2	X	X	
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			STARTING CONTROL	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X
			VARIABLE GEAR RATIO STEER	X	X	
Lexus	2014	GS450h				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIR SUSPENSION	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			DYNAMIC REAR STEERING	X	X	
			ELECTRIC PARKING BRAKE	X	X	X
			ELECTRIC POWER STEERING	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GATEWAY CAN	X	X	
			GLOBAL OBDII	X	X	X
			HYBRID VEHICLE	X	X	X
			METER	X	X	X
			MULTI BUS GATEWAY	X	X	
			MULTI BUS MONITOR NO.1	X	X	
			MULTI BUS MONITOR NO.2	X	X	
			OCCUPANT CLASSIFICATION	X	X	X
			POWER SOURCE CONTROL	X	X	
			PRE-COLLISION	X	X	
			PRE-COLLISION 2	X	X	
			REMOTE ENGINE STARTER	X	X	

			SMART KEY	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			VARIABLE GEAR RATIO STEER	X	X	
Lexus	2014	GX460				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIR SUSPENSION	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GLOBAL OBDII	X	X	X
			KINETIC DYNAMIC SUSPENSION SYS	X	X	
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			PM1 GATEWAY	X	X	
			PM2 GATEWAY	X	X	
			POWER SOURCE CONTROL	X	X	
			PRE-COLLISION	X	X	
			PRE-COLLISION 2	X	X	
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			STARTING CONTROL	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
Lexus	2014	IS F				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			GATEWAY	X	X	X
			GLOBAL OBDII	X	X	X
			METER	X		X
			OCCUPANT CLASSIFICATION	X	X	X
			POWER SOURCE CONTROL	X	X	
			PRE-COLLISION	X	X	
			SMART KEY	X	X	
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X
Lexus	2014	IS250				
			4WD	X	X	X
			ABS/VSC/TRAC	X	X	X
			ACCESSORY GATEWAY	X	X	
			AIR CONDITIONING	X	X	X
			AIR SUSPENSION	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GATEWAY	X	X	X
			GATEWAY CAN	X	X	
			GLOBAL OBDII	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			POWER SOURCE CONTROL	X	X	
			PRE-COLLISION	X	X	
			PRE-COLLISION 2	X	X	
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			STARTING CONTROL	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X
Lexus	2014	IS350				
			4WD	X	X	X
			ABS/VSC/TRAC	X	X	X
			ACCESSORY GATEWAY	X	X	
			AIR CONDITIONING	X	X	X
			AIR SUSPENSION	X	X	X
			AIRBAG	X	X	X

			BODY CONTROL MODULE	X	X	X
			DYNAMIC REAR STEERING	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GATEWAY	X	X	X
			GATEWAY CAN	X	X	
			GLOBAL OBDII	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			POWER SOURCE CONTROL	X	X	
			PRE-COLLISION	X	X	
			PRE-COLLISION 2	X	X	
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			STARTING CONTROL	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X
			VARIABLE GEAR RATIO STEER	X	X	
Lexus	2014	LS460				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIR SUSPENSION	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			ECB GATEWAY	X	X	
			ECM GATEWAY	X	X	
			ELECTRIC PARKING BRAKE	X	X	X
			ELECTRIC POWER CONTROL	X	X	X
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			PRE-COLLISION	X	X	
			PRE-COLLISION 2	X	X	
			SMART KEY	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X
			VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2014	LS600h				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIR SUSPENSION	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			ECB GATEWAY	X	X	
			ECM GATEWAY	X	X	
			ELECTRIC PARKING BRAKE	X	X	X
			ELECTRIC POWER STEERING	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GLOBAL OBDII	X	X	X
			HYBRID VEHICLE	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			PRE-COLLISION	X	X	
			PRE-COLLISION 2	X	X	
			SMART KEY	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2014	LX570				
			ABS/VSC/TRAC	X	X	X
			ACCESSORY GATEWAY	X	X	
			AIR CONDITIONING	X	X	X
			AIR SUSPENSION	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GATEWAY CAN	X	X	
			GLOBAL OBDII	X	X	X
			METER	X	X	X

			OCCUPANT CLASSIFICATION	X	X	X
			PRE-COLLISION	X	X	
			SMART KEY	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2014	RX350				
			4WD	X	X	X
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			PM1 GATEWAY	X	X	
			PM2 GATEWAY	X	X	
			POWER SOURCE CONTROL	X	X	
			PRE-COLLISION	X	X	
			PRE-COLLISION 2	X	X	
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			STARTING CONTROL	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X
Lexus	2014	RX450h				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			ELECTRIC POWER STEERING	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GLOBAL OBDII	X	X	X
			HYBRID VEHICLE	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			PM1 GATEWAY	X	X	
			PM2 GATEWAY	X	X	
			POWER SOURCE CONTROL	X	X	
			PRE-COLLISION	X	X	
			PRE-COLLISION 2	X	X	
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
Lexus	2013	CT200h				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GLOBAL OBDII	X	X	X
			HYBRID VEHICLE	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			PM1 GATEWAY	X	X	
			PM2 GATEWAY	X	X	
			POWER SOURCE CONTROL	X	X	
			PRE-COLLISION	X	X	
			PRE-COLLISION 2	X	X	
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			TELEMATICS	X	X	
			THEFT DETERRENT	X	X	X
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	
Lexus	2013	ES300h				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X

			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GLOBAL OBDII	X	X	X
			HYBRID VEHICLE	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			PM1 GATEWAY	X	X	
			POWER SOURCE CONTROL	X	X	
			PRE-COLLISION	X	X	
			PRE-COLLISION 2	X	X	
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
Lexus	2013	ES350				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			GATEWAY CAN	X	X	
			GLOBAL OBDII	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			POWER SOURCE CONTROL	X	X	
			PRE-COLLISION	X	X	
			PRE-COLLISION 2	X	X	
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			STARTING CONTROL	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X
Lexus	2013	GS350				
			4WD	X	X	X
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIR SUSPENSION	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			DYNAMIC REAR STEERING	X	X	
			ELECTRIC PARKING BRAKE	X	X	X
			ELECTRIC POWER STEERING	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GATEWAY CAN	X	X	
			GLOBAL OBDII	X	X	X
			METER	X	X	X
			MULTI BUS GATEWAY	X	X	
			MULTI BUS MONITOR NO.1	X	X	
			MULTI BUS MONITOR NO.2	X	X	
			OCCUPANT CLASSIFICATION	X	X	X
			POWER SOURCE CONTROL	X	X	
			PRE-COLLISION	X	X	
			PRE-COLLISION 2	X	X	
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			STARTING CONTROL	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			VARIABLE GEAR RATIO STEER	X	X	
Lexus	2013	GS450h				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIR SUSPENSION	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			DYNAMIC REAR STEERING	X	X	
			ELECTRIC PARKING BRAKE	X	X	X

			ELECTRIC POWER STEERING	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GATEWAY CAN	X	X	
			GLOBAL OBDII	X	X	X
			HYBRID VEHICLE	X	X	X
			METER	X	X	X
			MULTI BUS GATEWAY	X	X	
			MULTI BUS MONITOR NO.1	X	X	
			MULTI BUS MONITOR NO.2	X	X	
			OCCUPANT CLASSIFICATION	X	X	X
			POWER SOURCE CONTROL	X	X	
			PRE-COLLISION	X	X	
			PRE-COLLISION 2	X	X	
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			VARIABLE GEAR RATIO STEER	X	X	
Lexus	2013	GX460				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIR SUSPENSION	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			ENGINE/TRANSMISSION	X	X	X
			GLOBAL OBDII	X	X	X
			KINETIC DYNAMIC SUSPENSION SYS	X	X	
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			PM1 GATEWAY	X	X	
			PM2 GATEWAY	X	X	
			POWER SOURCE CONTROL	X	X	
			PRE-COLLISION	X	X	
			PRE-COLLISION 2	X	X	
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			STARTING CONTROL	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
Lexus	2013	IS F				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			GATEWAY	X	X	X
			GLOBAL OBDII	X	X	X
			METER	X		X
			OCCUPANT CLASSIFICATION	X	X	X
			POWER SOURCE CONTROL	X	X	
			PRE-COLLISION	X	X	
			SMART KEY	X	X	
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X
Lexus	2013	IS250				
			4WD	X	X	X
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			GATEWAY	X	X	X
			GLOBAL OBDII	X	X	X
			METER	X		X
			OCCUPANT CLASSIFICATION	X	X	X
			POWER SOURCE CONTROL	X	X	
			PRE-COLLISION	X	X	
			SMART KEY	X	X	

			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X
Lexus	2013	IS350				
			4WD	X	X	X
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			GATEWAY	X	X	X
			GLOBAL OBDII	X	X	X
			METER	X		X
			OCCUPANT CLASSIFICATION	X	X	X
			POWER SOURCE CONTROL	X	X	
			PRE-COLLISION	X	X	
			SMART KEY	X	X	
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X
Lexus	2013	LFA				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			ELECTRIC PARKING BRAKE	X	X	X
			ELECTRIC POWER CONTROL	X	X	X
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			GATEWAY CAN	X	X	
			GLOBAL OBDII	X	X	X
			IMMOBILIZER	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			TELEMATICS	X	X	
			THEFT DETERRENT	X	X	X
			TIRE PRESSURE MONITOR	X	X	X
Lexus	2013	LS460				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIR SUSPENSION	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			ECB GATEWAY	X	X	
			ECM GATEWAY	X	X	
			ELECTRIC PARKING BRAKE	X	X	X
			ELECTRIC POWER CONTROL	X	X	X
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			PRE-COLLISION	X	X	
			PRE-COLLISION 2	X	X	
			SMART KEY	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X
			VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2013	LS600h				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIR SUSPENSION	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			ECB GATEWAY	X	X	
			ECM GATEWAY	X	X	
			ELECTRIC PARKING BRAKE	X	X	X
			ELECTRIC POWER STEERING	X	X	X
			ENGINE/TRANSMISSION	X	X	X

				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2013	LX570					
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PRE-COLLISION	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2013	RX350					
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				STARTING CONTROL	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2013	RX450h					
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Lexus	2012	CT200h	X				
				ABS/VSC/TRAC	X	X	X

				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Lexus	2012	ES350	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PRE-COLLISION	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2012	GX460	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				KINETIC DYNAMIC SUSPENSION SYS	X	X	
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				STARTING CONTROL	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Lexus	2012	HS250h	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	

				PRE-COLLISION 2	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Lexus	2012	IS F	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				SMART KEY	X	X	
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2012	IS250	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				SMART KEY	X	X	
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2012	IS350	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				SMART KEY	X	X	
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2012	LFA					
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				ELECTRIC PARKING BRAKE	X	X	X
				ELECTRIC POWER CONTROL	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X

				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TELEMATICS	X	X	
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Lexus	2012	LS460	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ECB GATEWAY	X	X	
				ECM GATEWAY	X	X	
				ELECTRIC PARKING BRAKE	X	X	X
				ELECTRIC POWER CONTROL	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2012	LS600h	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ECB GATEWAY	X	X	
				ECM GATEWAY	X	X	
				ELECTRIC PARKING BRAKE	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2012	LX570	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PRE-COLLISION	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2012	RX350	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X

				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				STARTING CONTROL	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2012	RX450h	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Lexus	2011	CT200h	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Lexus	2011	ES350	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X

				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PRE-COLLISION	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2011	GS350	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELEC MODULATED SUSPENSION	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				SMART KEY	X	X	
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2011	GS450h	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELEC MODULATED SUSPENSION	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				SMART KEY	X	X	
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2011	GS460	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELEC MODULATED SUSPENSION	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				SMART KEY	X	X	
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2011	GX460	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X

				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				KINETIC DYNAMIC SUSPENSION SYS	X	X	
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				STARTING CONTROL	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Lexus	2011	HS250h	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Lexus	2011	IS F	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				SMART KEY	X	X	
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2011	IS250	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	

				PRE-COLLISION	X	X	
				SMART KEY	X	X	
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2011	IS350	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				SMART KEY	X	X	
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2011	LS460	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ECB GATEWAY	X	X	
				ECM GATEWAY	X	X	
				ELECTRIC PARKING BRAKE	X	X	X
				ELECTRIC POWER CONTROL	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2011	LS600h	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ECB GATEWAY	X	X	
				ECM GATEWAY	X	X	
				ELECTRIC PARKING BRAKE	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2011	LX570	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	

				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PRE-COLLISION	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2011	RX350	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				STARTING CONTROL	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2011	RX450h	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Lexus	2010	ES350	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PRE-COLLISION	X	X	
				SMART KEY	X	X	X

				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2010	GS350	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELEC MODULATED SUSPENSION	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				SMART KEY	X	X	
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2010	GS450h	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELEC MODULATED SUSPENSION	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				SMART KEY	X	X	
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2010	GS460	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELEC MODULATED SUSPENSION	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				SMART KEY	X	X	
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2010	GX460	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X

				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				SMART KEY	X	X	
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Lexus	2010	HS250h	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Lexus	2010	IS F	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				SMART KEY	X	X	
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2010	IS250	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				SMART KEY	X	X	
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2010	IS350	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X

				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				SMART KEY	X	X	
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2010	LS460	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ECB GATEWAY	X	X	
				ECM GATEWAY	X	X	
				ELECTRIC PARKING BRAKE	X	X	X
				ELECTRIC POWER CONTROL	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2010	LS600h	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ECB GATEWAY	X	X	
				ECM GATEWAY	X	X	
				ELECTRIC PARKING BRAKE	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2010	LX570	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PRE-COLLISION	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2010	RX350	X				
				4WD	X	X	X

				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				STARTING CONTROL	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2010	RX450h	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Lexus	2010	SC430	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2009	ES350	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				SMART KEY	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2009	GS350	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X

				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELEC MODULATED SUSPENSION	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				SMART KEY	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2009	GS450h	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELEC MODULATED SUSPENSION	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				SMART KEY	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2009	GS460	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELEC MODULATED SUSPENSION	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				SMART KEY	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2009	GX470	X				
				ABS/VSC/TRAC	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELEC MODULATED SUSPENSION	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Lexus	2009	IS F	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X

				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				SMART KEY	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2009	IS250	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				SMART KEY	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2009	IS350	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				SMART KEY	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2009	LS460	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ECB GATEWAY	X	X	
				ECM GATEWAY	X	X	
				ELECTRIC PARKING BRAKE	X	X	X
				ELECTRIC POWER CONTROL	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				SMART KEY	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2009	LS600h	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ECB GATEWAY	X	X	
				ECM GATEWAY	X	X	
				ELECTRIC PARKING BRAKE	X	X	X

				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				SMART KEY	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2009	LX570	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PRE-COLLISION	X	X	
				SMART KEY	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2009	RX350	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELEC MODULATED SUSPENSION	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Lexus	2009	SC430	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2008	ES350	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE	X	X	X
				GATEWAY	X	X	
				GLOBAL OBDII	X	X	X
				INTUITIVE P/A	X	X	
				METER	X	X	X
				MIRROR	X		
				OCCUPANT CLASSIFICATION	X	X	X
				SLIDE ROOF	X	X	
				SMART ACCESS	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2008	GS350	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X

				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELEC MODULATED SUSPENSION	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				SMART KEY	X	X	
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2008	GS450h	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELEC MODULATED SUSPENSION	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				SMART KEY	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2008	GS460	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELEC MODULATED SUSPENSION	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				SMART KEY	X	X	
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2008	GX470	X				
				ABS/VSC/TRAC	X	X	X
				AIR SUSPENSION	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Lexus	2008	IS F	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GATEWAY	X	X	X

				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				SMART KEY	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2008	IS250	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				SMART KEY	X	X	
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2008	IS350	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				SMART KEY	X	X	
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2008	LS460	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ECB GATEWAY	X	X	
				ECM GATEWAY	X	X	
				ELECTRIC PARKING BRAKE	X	X	X
				ELECTRIC POWER CONTROL	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				SLIDE ROOF	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2008	LS600h	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ECB GATEWAY	X	X	

				ECM GATEWAY	X	X	
				ELECTRIC PARKING BRAKE	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				SLIDE ROOF	X	X	
				SMART KEY	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2008	LX570	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				ACTIVE HEIGHT CONTROL SYS	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY	X	X	
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PRE-COLLISION	X	X	
				SLIDE ROOF	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2008	RX350	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Lexus	2008	RX400h	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Lexus	2008	SC430	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2007	ES 350	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X

				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTUITIVE P/A	X	X	
				MIRROR	X		
				SLIDE ROOF	X	X	
				SMART ACCESS	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2007	GS 350	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				COMBINATION SWITCH	X		
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTUITIVE P/A	X	X	
				MASTER SW	X		
				PASSENGER DOOR MODULE	X	X	
				PASSENGER SEAT	X		
				SLIDE ROOF	X		
				SMART ACCESS	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2007	GS 430	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				COMBINATION SWITCH	X		
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTUITIVE P/A	X	X	
				MASTER SW	X		
				PASSENGER DOOR MODULE	X	X	
				PASSENGER SEAT	X		
				SLIDE ROOF	X		
				SMART ACCESS	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2007	GS 450h	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				COMBINATION SWITCH	X		
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				INTUITIVE P/A	X	X	
				MASTER SW	X		
				METER	X		X
				PASSENGER DOOR MODULE	X	X	
				PASSENGER SEAT	X		
				SLIDE ROOF	X		
				SMART ACCESS	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Lexus	2007	GX 470	X				
				ABS/VSC/TRAC	X	X	X

				BODY CONTROL MODULE	X	X	X
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				SUB BODY CONTROL	X	X	
				THEFT DETERRENT MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				WIPER	X		
Lexus	2007	IS 250	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				COMBINATION SWITCH	X		
				DRIVER SEAT MODULE	X		
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTUITIVE P/A	X	X	
				LEFT MIRROR	X		
				MASTER SW	X		
				METER	X		X
				PASSENGER SEAT	X		
				RIGHT MIRROR	X		
				SLIDE ROOF	X		
				SMART ACCESS	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2007	IS 350	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				COMBINATION SWITCH	X		
				DRIVER SEAT MODULE	X		
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTUITIVE P/A	X	X	
				LEFT MIRROR	X		
				MASTER SW	X		
				METER	X		X
				MIRROR LEFT	X		
				MIRROR RIGHT	X		
				PASSENGER SEAT	X		
				RIGHT MIRROR	X		
				SLIDE ROOF	X		
				SMART ACCESS	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2007	LS 460	X				
				ABS/VSC/TRAC	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				SLIDE ROOF	X	X	
				SMART ACCESS	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2007	LX 470	X				
				ABS/VSC/TRAC	X	X	X
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				SLIDE ROOF	X		

				SUB BODY CONTROL	X	X	
				THEFT DETERRENT MODULE	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				WIPER	X		
Lexus	2007	RX 350	X				
				ABS/VSC/TRAC	X	X	X
				AIR SUSPENSION	X	X	
				DRIVER SEAT MODULE	X		
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				LEFT MIRROR	X		
				MASTER SW	X		
				RIGHT MIRROR	X		
				SLIDE ROOF	X		
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				WIPER	X		
Lexus	2007	RX 400h	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	
				DRIVER SEAT MODULE	X		
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				IMMOBILIZER	X	X	
				LEFT MIRROR	X		
				MASTER SW	X		
				METER	X		X
				RIGHT MIRROR	X		
				SLIDE ROOF	X		
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				WIPER	X		
Lexus	2007	SC 430	X				
				ABS/VSC/TRAC	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				COMBINATION SWITCH	X		
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X		X
				PASSENGER DOOR MODULE	X	X	
				PASSENGER SEAT	X		
				RETRACTABLE HARDTOP	X	X	
				SUB BODY CONTROL	X	X	
				THEFT DETERRENT MODULE	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2006	ES 330	X				
				ABS/VSC/TRAC	X	X	X
				AIR SUSPENSION	X	X	X
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				OCCUPANT CLASSIFICATION	X	X	X
				SMART KEY SYSTEM	X	X	
Lexus	2006	GS 300	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				ADAPTIVE FRONT LIGHTING SYSTEM	X	X	
				AIR CONDITIONING	X	X	
				AIR SUSPENSION	X	X	X
				BODY CONTROL MODULE	X	X	X
				CLEARANCE SONAR	X	X	
				COMBINATION SWITCH	X		
				CRUISE CONTROL	X	X	
				DRIVER DOOR	X	X	

				DRIVER SEAT MODULE	X		
				DRIVER SEAT SWITCH	X		
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
				INTUITIVE P/A	X	X	
				MASTER SW	X		
				PASSENGER DOOR MODULE	X	X	
				PASSENGER SEAT	X		
				RAIN SENSOR	X		
				SLIDE ROOF	X		
				SMART KEY SYSTEM	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2006	GS 430	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				ADAPTIVE FRONT LIGHTING SYSTEM	X	X	
				AIR CONDITIONING	X	X	
				AIR SUSPENSION	X	X	X
				BODY CONTROL MODULE	X	X	X
				CLEARANCE SONAR	X	X	
				COMBINATION SWITCH	X		
				CRUISE CONTROL	X	X	
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				DRIVER SEAT SWITCH	X		
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
				INTUITIVE P/A	X	X	
				MASTER SW	X		
				PASSENGER DOOR MODULE	X	X	
				PASSENGER SEAT	X		
				RAIN SENSOR	X		
				SLIDE ROOF	X		
				SMART KEY SYSTEM	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
Lexus	2006	GX 470	X				
				ABS/VSC/TRAC	X	X	X
				AIR SUSPENSION	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				DRIVER SEAT SWITCH	X		
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				MIRROR	X		
				OCCUPANT CLASSIFICATION	X	X	X
				RAIN SENSOR	X		
				SMART KEY SYSTEM	X	X	
				THEFT DETERRENT MODULE	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				WIPER	X		
Lexus	2006	IS 250	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				ADAPTIVE FRONT LIGHTING SYSTEM	X	X	
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				CLEARANCE SONAR	X	X	
				COMBINATION SWITCH	X		
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X

				INSTRUMENT PANEL	X		X
				MIRROR LEFT	X		
				MIRROR RIGHT	X		
				PASSENGER SEAT	X		
				RAIN SENSOR	X		
				SMART KEY SYSTEM	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2006	IS 350	X				
				ABS/VSC/TRAC	X	X	X
				ADAPTIVE FRONT LIGHTING SYSTEM	X	X	
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				CLEARANCE SONAR	X	X	
				COMBINATION SWITCH	X		
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
				INTUITIVE P/A	X	X	
				MASTER SW	X		
				MIRROR LEFT	X		
				MIRROR RIGHT	X		
				PASSENGER SEAT	X		
				RAIN SENSOR	X		
				SLIDE ROOF	X		
				SMART KEY SYSTEM	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2006	LS 430	X				
				ABS/VSC/TRAC	X	X	X
				ADAPTIVE FRONT LIGHTING SYSTEM	X	X	
				AIR CONDITIONING	X	X	
				AIR SUSPENSION	X	X	X
				BODY CONTROL MODULE	X	X	X
				CLEARANCE SONAR	X	X	
				COMBINATION SWITCH	X		
				CRUISE CONTROL	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				INSTRUMENT PANEL	X		X
				RAIN SENSOR	X		
				REAR LEFT SEAT	X		
				REAR RIGHT SEAT	X		
				REAR SEAT MODULE	X		
				SMART KEY SYSTEM	X	X	
				STEERING PAD SWITCH	X		
				TILT & TELESCOPE MODULE	X	X	
				TRANSMISSION	X	X	X
Lexus	2006	LX 470	X				
				ABS/VSC/TRAC	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				MIRROR	X		
				RAIN SENSOR	X		
				SLIDE ROOF	X		
				SMART KEY SYSTEM	X	X	
				THEFT DETERRENT MODULE	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				VARIABLE GEAR RATIO STEER	X	X	X
				WIPER	X		
Lexus	2006	RX 400h	X				
				ABS/VSC/TRAC	X	X	X
				ADAPTIVE FRONT LIGHTING SYSTEM	X	X	

				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				DRIVER SEAT MODULE	X		
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				IMMOBILIZER	X	X	
				INSTRUMENT PANEL	X		X
				LEFT MIRROR	X		
				MASTER SW	X		
				MIRROR LEFT	X		
				MIRROR RIGHT	X		
				OCCUPANT CLASSIFICATION	X	X	X
				RAIN SENSOR	X		
				RIGHT MIRROR	X		
				SLIDE ROOF	X		
				TILT & TELESCOPE MODULE	X	X	
				WIPER	X		
Lexus	2006	RX330	X				
				ABS/VSC/TRAC	X	X	X
				ADAPTIVE FRONT LIGHTING SYSTEM	X	X	
				AIR CONDITIONING	X	X	
				AIR SUSPENSION	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				INSTRUMENT PANEL	X		X
				MIRROR LEFT	X		
				MIRROR RIGHT	X		
				OCCUPANT CLASSIFICATION	X	X	X
				RAIN SENSOR	X		
				TILT & TELESCOPE MODULE	X	X	
				WIPER	X		
Lexus	2006	SC 430	X				
				ABS/VSC/TRAC	X	X	X
				ADAPTIVE FRONT LIGHTING SYSTEM	X	X	
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				COMBINATION SWITCH	X		
				CRUISE CONTROL	X	X	
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				INSTRUMENT PANEL	X		X
				PASSENGER DOOR MODULE	X	X	
				PASSENGER SEAT	X		
				RETRACTABLE HARDTOP	X	X	
				SMART KEY SYSTEM	X	X	
				STEERING PAD SWITCH	X		
				THEFT DETERRENT MODULE	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Lexus	2005	ES 330	X				
				ABS/VSC/TRAC	X	X	X
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT MODULE	X	X	
Lexus	2005	GS 300	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
				TILT & TELESCOPE MODULE	X	X	
Lexus	2005	GS 430	X				

				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
				PASSENGER DOOR MODULE	X	X	
				SLIDE ROOF	X		
				TILT & TELESCOPE MODULE	X	X	
Lexus	2005	GX 470	X				
				ABS/VSC/TRAC	X	X	X
				AIR SUSPENSION	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				MIRROR	X		
				OCCUPANT CLASSIFICATION	X	X	X
				RAIN SENSOR	X		
				THEFT DETERRENT MODULE	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				WIPER	X		
Lexus	2005	IS 300	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
				THEFT DETERRENT MODULE	X	X	
Lexus	2005	LS 430	X				
				ABS/VSC/TRAC	X	X	X
				ADAPTIVE FRONT LIGHTING SYSTEM	X	X	
				AIR CONDITIONING	X	X	
				AIR SUSPENSION	X	X	X
				BODY CONTROL MODULE	X	X	X
				COMBINATION SWITCH	X		
				CRUISE CONTROL	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				INSTRUMENT PANEL	X		X
				RAIN SENSOR	X		
				REAR LEFT SEAT	X		
				REAR RIGHT SEAT	X		
				REAR SEAT MODULE	X		
				SMART KEY SYSTEM	X	X	
				STEERING PAD SWITCH	X		
				THEFT DETERRENT MODULE	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TRANSMISSION	X	X	X
Lexus	2005	LX 470	X				
				ABS/VSC/TRAC	X	X	X
				BODY CONTROL MODULE	X	X	X
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				MIRROR	X		
				RAIN SENSOR	X		
				SLIDE ROOF	X		
				THEFT DETERRENT MODULE	X	X	
				TILT & TELESCOPE MODULE	X	X	
				VARIABLE GEAR RATIO STEER	X	X	X
				WIPER	X		
Lexus	2005	RX330	X				
				ABS/VSC/TRAC	X	X	X

				ADAPTIVE FRONT LIGHTING SYSTEM	X	X	
				AIR CONDITIONING	X	X	
				AIR SUSPENSION	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				INSTRUMENT PANEL	X		X
				MIRROR LEFT	X		
				MIRROR RIGHT	X		
				OCCUPANT CLASSIFICATION	X	X	X
				RAIN SENSOR	X		
				TILT & TELESCOPE MODULE	X	X	
				WIPER	X		
Lexus	2005	SC 430	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				COMBINATION SWITCH	X		
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				INSTRUMENT PANEL	X		X
				PASSENGER DOOR MODULE	X	X	
				PASSENGER SEAT	X		
				RETRACTABLE HARDTOP	X	X	
				STEERING PAD SWITCH	X		
				THEFT DETERRENT MODULE	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Lexus	2004	ES 330	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT MODULE	X	X	
Lexus	2004	GS 300	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
				TILT & TELESCOPE MODULE	X	X	
Lexus	2004	GS 430	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
				PASSENGER DOOR MODULE	X	X	
				SLIDE ROOF	X		
				TILT & TELESCOPE MODULE	X	X	
Lexus	2004	GX 470	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				AIR SUSPENSION	X	X	X
				BODY CONTROL MODULE	X	X	X
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				MIRROR	X		
				RAIN SENSOR	X		
				THEFT DETERRENT MODULE	X	X	

				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				WIPER	X		
Lexus	2004	IS 300	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
				THEFT DETERRENT MODULE	X	X	
Lexus	2004	LS 430	X				
				ABS/VSC/TRAC	X	X	X
				ADAPTIVE FRONT LIGHTING SYSTEM	X	X	
				AIR CONDITIONING	X	X	
				AIR SUSPENSION	X	X	X
				BODY CONTROL MODULE	X	X	X
				COMBINATION SWITCH	X		
				CRUISE CONTROL	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				INSTRUMENT PANEL	X		X
				RAIN SENSOR	X		
				REAR LEFT SEAT	X		
				REAR RIGHT SEAT	X		
				REAR SEAT MODULE	X		
				SMART KEY SYSTEM	X	X	
				STEERING PAD SWITCH	X		
				THEFT DETERRENT MODULE	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TRANSMISSION	X	X	X
Lexus	2004	LX 470	X				
				ABS/VSC/TRAC	X	X	X
				ACTIVE HEIGHT CONTROL SYS	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				MIRROR	X		
				RAIN SENSOR	X		
				SLIDE ROOF	X		
				THEFT DETERRENT MODULE	X	X	
				TILT & TELESCOPE MODULE	X	X	
				VARIABLE GEAR RATIO STEER	X	X	X
				WIPER	X		
Lexus	2004	RX330	X				
				ABS/VSC/TRAC	X	X	X
				ADAPTIVE FRONT LIGHTING SYSTEM	X	X	
				AIR CONDITIONING	X	X	
				AIR SUSPENSION	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				INSTRUMENT PANEL	X		X
				MIRROR LEFT	X		
				MIRROR RIGHT	X		
				OCCUPANT CLASSIFICATION	X	X	X
				RAIN SENSOR	X		
				TILT & TELESCOPE MODULE	X	X	
				WIPER	X		
Lexus	2004	SC 430	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				COMBINATION SWITCH	X		
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X

				IMMOBILIZER	X	X	
				INSTRUMENT PANEL	X		X
				PASSENGER DOOR MODULE	X	X	
				PASSENGER SEAT	X		
				RETRACTABLE HARDTOP	X	X	
				STEERING PAD SWITCH	X		
				THEFT DETERRENT MODULE	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Lexus	2003	ES 300	X				
				ABS/VSC/TRAC	X	X	X
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				THEFT DETERRENT MODULE	X	X	
Lexus	2003	GS 300	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
				TILT & TELESCOPE MODULE	X	X	
Lexus	2003	GS 430	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
				PASSENGER DOOR MODULE	X	X	
				SLIDE ROOF	X		
				TILT & TELESCOPE MODULE	X	X	
Lexus	2003	GX 470	X				
				ABS/VSC/TRAC	X	X	X
				AIR SUSPENSION	X	X	X
				BODY CONTROL MODULE	X	X	X
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				MIRROR	X		
				RAIN SENSOR	X		
				THEFT DETERRENT MODULE	X	X	
				TILT & TELESCOPE MODULE	X	X	
				WIPER	X		
Lexus	2003	IS 300	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
				THEFT DETERRENT MODULE	X	X	
Lexus	2003	LS 430	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				AIR SUSPENSION	X	X	X
				BODY CONTROL MODULE	X	X	X
				COMBINATION SWITCH	X		
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				INSTRUMENT PANEL	X		X
				RAIN SENSOR	X		
				REAR LEFT SEAT	X		
				REAR RIGHT SEAT	X		
				REAR SEAT MODULE	X		
				STEERING PAD SWITCH	X		
				THEFT DETERRENT MODULE	X	X	
				TILT & TELESCOPE MODULE	X	X	

Lexus	2003	LX 470	X				
				ABS/VSC/TRAC	X	X	X
				ACTIVE HEIGHT CONTROL SYS	X	X	X
				BODY CONTROL MODULE	X	X	X
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				MIRROR	X		
				RAIN SENSOR	X		
				SLIDE ROOF	X		
				THEFT DETERRENT MODULE	X	X	
				TILT & TELESCOPE MODULE	X	X	
				VARIABLE GEAR RATIO STEER	X	X	X
				WIPER	X		
Lexus	2003	RX 300	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
Lexus	2003	SC 430	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				COMBINATION SWITCH	X		
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				INSTRUMENT PANEL	X		X
				PASSENGER DOOR MODULE	X	X	
				PASSENGER SEAT	X		
				RETRACTABLE HARDTOP	X	X	
				STEERING PAD SWITCH	X		
				THEFT DETERRENT MODULE	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Lexus	2002	ES 300	X				
				ABS/VSC/TRAC	X	X	X
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				THEFT DETERRENT MODULE	X	X	
Lexus	2002	GS 300	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
				TILT & TELESCOPE MODULE	X	X	
Lexus	2002	GS 430	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
				PASSENGER DOOR MODULE	X	X	
				SLIDE ROOF	X		
				TILT & TELESCOPE MODULE	X	X	
Lexus	2002	IS 300	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X

				THEFT DETERRENT MODULE	X	X	
Lexus	2002	LS 430	X	ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				AIR SUSPENSION	X	X	X
				BODY CONTROL MODULE	X	X	X
				COMBINATION SWITCH	X		
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				INSTRUMENT PANEL	X		X
				RAIN SENSOR	X		
				REAR LEFT SEAT	X		
				REAR RIGHT SEAT	X		
				REAR SEAT MODULE	X		
				STEERING PAD SWITCH	X		
				THEFT DETERRENT MODULE	X	X	
				TILT & TELESCOPE MODULE	X	X	
Lexus	2002	LX 470	X	ABS/VSC/TRAC	X	X	X
				ACTIVE HEIGHT CONTROL SYS	X	X	X
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				MIRROR	X		
				TILT & TELESCOPE MODULE	X	X	
Lexus	2002	RX 300	X	ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
Lexus	2002	SC 430	X	ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				COMBINATION SWITCH	X		
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				INSTRUMENT PANEL	X		X
				PASSENGER DOOR MODULE	X	X	
				PASSENGER SEAT	X		
				RETRACTABLE HARDTOP	X	X	
				STEERING PAD SWITCH	X		
				THEFT DETERRENT MODULE	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Lexus	2001	ES 300	X	ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	2001	GS 300	X	ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
				TILT & TELESCOPE MODULE	X	X	
Lexus	2001	GS 430	X	ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
				PASSENGER DOOR MODULE	X	X	
				SLIDE ROOF	X		

				TILT & TELESCOPE MODULE	X	X	
Lexus	2001	IS 300	X	ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
				THEFT DETERRENT MODULE	X	X	
Lexus	2001	LS 430	X	ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				AIR SUSPENSION	X	X	X
				BODY CONTROL MODULE	X	X	X
				COMBINATION SWITCH	X		
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				INSTRUMENT PANEL	X		X
				RAIN SENSOR	X		
				REAR LEFT SEAT	X		
				REAR RIGHT SEAT	X		
				REAR SEAT MODULE	X		
				STEERING PAD SWITCH	X		
				THEFT DETERRENT MODULE	X	X	
				TILT & TELESCOPE MODULE	X	X	
Lexus	2001	LX 470	X	ABS	X	X	X
				ACTIVE HEIGHT CONTROL SYS	X	X	X
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				MIRROR	X		
Lexus	2001	RX 300	X	ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
Lexus	2000	ES300	X	ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	2000	GS300	X	ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	2000	GS400	X	ABS/VSC/TRAC	X	X	X
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	2000	LS400	X	ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	2000	LX470	X	ABS	X	X	X
				ACTIVE HEIGHT CONTROL SYS	X	X	X
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				MIRROR	X		
Lexus	2000	RX300	X	AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	2000	SC300	X				

				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	2000	SC400	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1999	ES300	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1999	GS300	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1999	GS400	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1999	LS400	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1999	LX470	X				
				ABS	X	X	X
				ACTIVE HEIGHT CONTROL SYS	X	X	X
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1999	RX300	X				
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1999	SC300	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1999	SC400	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1998	ES300	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1998	GS300	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1998	GS400	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1998	LS400	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1998	LX470	X				
				ABS	X	X	X
				ACTIVE HEIGHT CONTROL SYS	X	X	X
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1998	SC300	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X

Lexus	1998	SC400	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1997	ES300	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1997	GS300	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1997	LS400	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1997	LX450	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1997	SC300	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1997	SC400	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1996	ES300	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1996	GS300	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1996	LS400	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1996	LX450	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1996	SC300	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1996	SC400	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Lexus	1995	ES300	X				
				ENGINE/TRANS	X	X	X
Lexus	1995	GS300	X				
				ENGINE (DATA)	X		
Lexus	1995	LS400	X				
				ENGINE/TRANS	X	X	X
Lexus	1995	SC300	X				
				ENGINE (DATA)	X		
Lexus	1995	SC400	X				
				ENGINE (DATA)	X		
Lexus	1994	ES300	X				
				ENGINE/TRANS	X	X	X
Lexus	1994	GS300	X				
				ENGINE (DATA)	X		
Lexus	1994	LS400	X				
				ENGINE (DATA)	X		
Lexus	1994	SC300	X				
				ENGINE (DATA)	X		
Lexus	1994	SC400	X				
				ENGINE (DATA)	X		
Lexus	1993	ES300	X				
				ENGINE (DATA)	X		
Lexus	1993	GS300	X				
				ENGINE (DATA)	X		
Lexus	1993	LS400	X				
				ENGINE (DATA)	X		
Lexus	1993	SC300	X				
				ENGINE (DATA)	X		
Lexus	1993	SC400	X				
				ENGINE (DATA)	X		
Lexus	1992	ES300	X				
				ENGINE (DATA)	X		
Lexus	1992	LS400	X				
				ENGINE (DATA)	X		
Lexus	1992	SC300	X				
				ENGINE (DATA)	X		

				ENGINE (DATA)	X		
Lexus	1992	SC400	X	ENGINE (DATA)	X		
Lexus	1991	ES250	X	ENGINE (DATA)	X		
Lexus	1991	LS400	X	ENGINE (DATA)	X		
Lexus	1990	ES250	X	ENGINE (DATA)	X		
Lexus	1990	LS400	X	ENGINE (DATA)	X		
Mazda	2014	CX-5		ENGINE (DATA)	X		
				4X4 CONTROL	X	X	X
				ABS / TRACTION CONTROL	X	X	X
				AIRBAG	X	X	X
				DC to DC CONVERTER CONTROL	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				FRONT BODY CONTROL MODULE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	X
				PCM	X	X	X
				REAR BODY CONTROL MODULE	X	X	X
				TRANSMISSION	X	X	X
Mazda	2014	CX-9		4X4 CONTROL	X	X	
				ABS / TRACTION CONTROL	X	X	X
				AIRBAG	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	X
				PCM	X	X	X
				TRANSMISSION	X	X	
Mazda	2014	Mazda2		ABS / TRACTION CONTROL	X	X	
				AIRBAG	X	X	X
				AUTO LEVELING MODULE	X	X	X
				BODY CONTROL MODULE	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	X
				PCM	X	X	X
				Vehicle Security Module	X	X	X
Mazda	2014	Mazda3		ABS / TRACTION CONTROL	X	X	
				AIRBAG	X	X	X
				AUTO LEVELING MODULE	X	X	X
				DC to DC CONVERTER CONTROL	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				FRONT BODY CONTROL MODULE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	X
				PCM	X	X	X
				REAR BODY CONTROL MODULE	X	X	X
				TRANSMISSION	X	X	X
Mazda	2014	Mazda5		ABS / TRACTION CONTROL	X	X	
				AIRBAG	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	X
				PCM	X	X	X
				TRANSMISSION	X	X	
Mazda	2014	Mazda6	X	ABS / TRACTION CONTROL	X	X	X
				AIRBAG	X	X	X
				DC to DC CONVERTER CONTROL	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				FRONT BODY CONTROL MODULE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	X
				PCM	X	X	X
				REAR BODY CONTROL MODULE	X	X	X
				TRANSMISSION	X	X	X
Mazda	2014	MX-5 Miata		ABS / TRACTION CONTROL	X	X	X
				AIRBAG	X	X	

				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	X
				PCM	X	X	X
				TRANSMISSION	X	X	
Mazda	2013	CX-5		4X4 CONTROL	X	X	X
				ABS / TRACTION CONTROL	X	X	X
				AIRBAG	X	X	X
				DC to DC CONVERTER CONTROL	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				FRONT BODY CONTROL MODULE	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	X
				PCM	X	X	X
				REAR BODY CONTROL MODULE	X	X	X
				TRANSMISSION	X	X	X
Mazda	2013	CX-9		4X4 CONTROL	X	X	
				ABS / TRACTION CONTROL	X	X	X
				AIRBAG	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	X
				PCM	X	X	X
				TRANSMISSION	X	X	
Mazda	2013	Mazda2		ABS / TRACTION CONTROL	X	X	
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	X
				PCM	X	X	X
Mazda	2013	Mazda3		ABS / TRACTION CONTROL	X	X	
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	X
				PCM	X	X	X
				TRANSMISSION	X	X	X
Mazda	2013	Mazda5		ABS / TRACTION CONTROL	X	X	
				AIRBAG	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	X
				PCM	X	X	X
				TRANSMISSION	X	X	
Mazda	2013	Mazda6		ABS / TRACTION CONTROL	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	X
				PCM	X	X	X
				TRANSMISSION	X	X	X
Mazda	2013	MX-5 Miata		ABS / TRACTION CONTROL	X	X	X
				AIRBAG	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	X
				PCM	X	X	X
				TRANSMISSION	X	X	
Mazda	2012	CX-7	X	4WD	X	X	X
				ABS / TRACTION CONTROL	X	X	X
				AIRBAG	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	X
				PCM	X	X	X
				TRANSMISSION	X	X	X
Mazda	2012	CX-9	X	4X4 CONTROL	X	X	
				ABS / TRACTION CONTROL	X	X	X
				AIRBAG	X	X	X

				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	X
				PCM	X	X	X
				TRANSMISSION	X	X	
Mazda	2012	Mazda2	X				
				ABS / TRACTION CONTROL	X	X	
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	X
				PCM	X	X	X
Mazda	2012	Mazda3	X				
				ABS / TRACTION CONTROL	X	X	
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	X
				PCM	X	X	X
				TRANSMISSION	X	X	X
Mazda	2012	Mazda5					
				AIRBAG	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	X
				PCM	X	X	X
				TRANSMISSION	X	X	
Mazda	2012	Mazda6	X				
				ABS / TRACTION CONTROL	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	X
				PCM	X	X	X
				TRANSMISSION	X	X	X
Mazda	2012	MX-5 Miata	X				
				ABS / TRACTION CONTROL	X	X	X
				AIRBAG	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	X
				PCM	X	X	X
				TRANSMISSION	X	X	
Mazda	2011	CX-7	X				
				4WD	X	X	X
				ABS / TRACTION CONTROL	X	X	X
				AIRBAG	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	X
				PCM	X	X	X
				TRANSMISSION	X	X	X
Mazda	2011	CX-9	X				
				4X4 CONTROL	X	X	
				ABS / TRACTION CONTROL	X	X	X
				AIRBAG	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	X
				PCM	X	X	X
				TRANSMISSION	X	X	
Mazda	2011	Mazda2	X				
				ABS / TRACTION CONTROL	X	X	
				BODY CONTROL MODULE	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	X
				PCM	X	X	X
Mazda	2011	Mazda3	X				
				ABS / TRACTION CONTROL	X	X	
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	X
				PCM	X	X	X
				TRANSMISSION	X		
Mazda	2011	Mazda6	X				
				ABS / TRACTION CONTROL	X	X	X

				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	X
				PCM	X	X	X
				TRANSMISSION	X	X	X
Mazda	2011	MX-5 Miata	X				
				ABS / TRACTION CONTROL	X	X	X
				AIRBAG	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	X
				PCM	X	X	X
				TRANSMISSION	X	X	
Mazda	2011	RX-8	X				
				ABS / TRACTION CONTROL	X	X	X
				AIRBAG	X	X	
				GLOBAL OBDII	X	X	X
				PCM	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	
Mazda	2011	Tribute	X				
				4X4 CONTROL	X	X	X
				ABS / TRACTION CONTROL	X	X	X
				AIRBAG	X	X	X
				GEM MODULE / TPMS	X	X	X
				GLOBAL OBDII	X	X	X
				HEAT VENT A/C	X	X	X
				INSTRUMENT CLUSTER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PCM	X	X	X
Mazda	2010	CX-7	X				
				4WD	X	X	X
				AIRBAG	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	
				PCM	X	X	X
				TRANSMISSION	X	X	X
Mazda	2010	Mazda3	X				
				ABS / TRACTION CONTROL	X	X	
				AIRBAG	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	X
				PCM	X	X	X
				TRANSMISSION	X		
Mazda	2010	Mazda6	X				
				AIRBAG	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	
				PCM	X	X	X
				TRANSMISSION	X	X	X
Mazda	2010	MX-5 Miata	X				
				AIRBAG	X	X	
				GLOBAL OBDII	X	X	X
				PCM	X	X	X
				TRANSMISSION	X	X	
Mazda	2010	RX-8	X				
				ABS / TRACTION CONTROL	X	X	
				AIRBAG	X	X	
				GLOBAL OBDII	X	X	X
				PCM	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	
Mazda	2010	Tribute	X				
				4X4 CONTROL	X	X	X
				ABS / TRACTION CONTROL	X	X	X
				AIR CONDITIONING CONTROL	X	X	
				AIRBAG	X	X	X
				BATTERY CONTROL MODULE	X	X	
				GEM MODULE / TPMS	X	X	X
				GLOBAL OBDII	X	X	X
				HEAT VENT A/C	X	X	X
				INSTRUMENT CLUSTER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PCM	X	X	X

				TRANSMISSION	X	X	X
Mazda	2009	B2300	X	ABS / TRACTION CONTROL	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GEM MODULE / TPMS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
Mazda	2009	B4000	X	4X4 CONTROL	X	X	X
				ABS / TRACTION CONTROL	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GEM MODULE / TPMS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
Mazda	2009	CX-7	X	4WD	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	
				TRANSMISSION	X	X	
Mazda	2009	CX-9	X	AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Mazda	2009	Mazda3	X	ABS	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	
Mazda	2009	Mazda5	X	ABS	X	X	
				AIRBAG	X	X	X
				ELECTRIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	
Mazda	2009	Mazda6	X	ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	
				TRANSMISSION	X	X	X
Mazda	2009	MX-5 Miata	X	AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Mazda	2009	RX-8	X	ABS / TRACTION CONTROL	X	X	
				AIRBAG	X	X	
				GLOBAL OBDII	X	X	X
				PCM	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	
Mazda	2009	Tribute	X	4X4 CONTROL	X	X	X
				ABS / TRACTION CONTROL	X	X	X
				AIRBAG	X	X	X
				BATTERY CONTROL MODULE	X	X	X
				ENGINE	X	X	X
				GEM MODULE / TPMS	X	X	X
				GLOBAL OBDII	X	X	X

				HEAT VENT A/C	X	X	X
				INSTRUMENT CLUSTER	X	X	
				OCCUPANT CLASSIFICATION	X	X	X
				TRANSMISSION	X	X	X
Mazda	2008	B2300	X				
				ABS	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GEM MODULE / TPMS	X	X	X
				GLOBAL OBDII	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
Mazda	2008	B4000	X				
				ABS	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GEM MODULE / TPMS	X	X	X
				GLOBAL OBDII	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
Mazda	2008	CX-7	X				
				ABS / TCS	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	
				TRANSMISSION	X	X	
Mazda	2008	CX-9	X				
				AIRBAG	X	X	
				GLOBAL OBDII	X	X	X
				PCM	X	X	X
				TRANSMISSION	X	X	
Mazda	2008	Mazda3	X				
				ABS	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	
Mazda	2008	Mazda5	X				
				ABS	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	
Mazda	2008	Mazda6	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	
Mazda	2008	MX-5 Miata	X				
				ABS	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	
				TRANSMISSION	X	X	
Mazda	2008	RX-8	X				
				ABS / TRACTION CONTROL	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	X
				TRANSMISSION	X	X	
Mazda	2008	Tribute	X				
				ABS	X	X	X
				AIRBAG	X	X	X
				BATTERY CONTROL MODULE	X	X	X
				ENGINE	X	X	X
				GEM MODULE / TPMS	X	X	X
				GLOBAL OBDII	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TRANSMISSION_CVT	X	X	X

Mazda	2007	B-2300	X								
				ABS	X	X	X				
				AIRBAG	X	X	X				
				ENGINE	X	X	X				
				GEM MODULE / TPMS	X	X	X				
				GLOBAL OBDII	X	X	X				
				INSTRUMENT CLUSTER	X	X	X				
				OCCUPANT CLASSIFICATION	X	X	X				
				SATELLITE SYSTEM	X	X	X				
Mazda	2007	B-3000	X								
				ABS	X	X	X				
				AIRBAG	X	X	X				
				ENGINE	X	X	X				
				GEM MODULE / TPMS	X	X	X				
				GLOBAL OBDII	X	X	X				
				INSTRUMENT CLUSTER	X	X	X				
				OCCUPANT CLASSIFICATION	X	X	X				
				SATELLITE SYSTEM	X	X	X				
Mazda	2007	B-4000	X								
				4X4 CONTROL	X	X	X				
				ABS	X	X	X				
				AIRBAG	X	X	X				
				ENGINE	X	X	X				
				GEM MODULE / TPMS	X	X	X				
				GLOBAL OBDII	X	X	X				
				INSTRUMENT CLUSTER	X	X	X				
				OCCUPANT CLASSIFICATION	X	X	X				
SATELLITE SYSTEM	X	X	X								
Mazda	2007	CX-7	X								
				ABS / TCS	X	X					
				AIRBAG	X	X					
				CLIMATE CONTROL	X	X					
				ENGINE	X	X	X				
				GLOBAL OBDII	X	X	X				
				INSTRUMENT CLUSTER / TPMS	X	X					
				TRANSMISSION	X	X					
Mazda	2007	CX-9									
				AIRBAG	X	X					
				GLOBAL OBDII	X	X	X				
				PCM	X	X	X				
Mazda	2007	Mazda3	X								
				ABS	X	X					
				AIRBAG	X	X					
				CLIMATE CONTROL	X	X					
				ENGINE	X	X	X				
				GEM/CTM	X	X					
				GLOBAL OBDII	X	X	X				
				INSTRUMENT CLUSTER	X	X					
				REMOTE KEYLESS ENTRY	X						
				STEERING	X	X					
				TIRE PRESSURE MONITOR	X	X					
				TRANSMISSION	X	X					
				Mazda	2007	Mazda5	X				
ABS	X	X									
AIRBAG	X	X									
CLIMATE CONTROL	X	X									
ENGINE	X	X	X								
GEM/CTM	X	X									
GLOBAL OBDII	X	X	X								
INSTRUMENT CLUSTER	X	X									
STEERING	X	X									
TIRE PRESSURE MONITOR	X	X									
Mazda	2007	Mazda6	X								
								ABS	X	X	X
								AIRBAG	X	X	
				ENGINE	X	X	X				
				GEM/CTM	X	X					
				GLOBAL OBDII	X	X	X				
				INSTRUMENT CLUSTER	X	X					
				REMOTE KEYLESS ENTRY	X						
TRANSMISSION	X	X									
Mazda	2007	MX-5 Miata	X								
				ABS	X	X					

				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	
				REMOTE KEYLESS ENTRY	X		
				TRANSMISSION	X	X	
Mazda	2007	RX-8	X				
				ABS / TRACTION CONTROL	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	X
				REMOTE KEYLESS ENTRY	X		
				TRANSMISSION	X	X	
Mazda	2006	B-2300	X				
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GEM/CTM	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	X
Mazda	2006	B-3000	X				
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GEM/CTM	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	X
Mazda	2006	B-4000	X				
				4X4 CONTROL	X	X	X
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GEM/CTM	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	X
Mazda	2006	Mazda3	X				
				ABS	X	X	
				AIRBAG	X	X	
				CLIMATE CONTROL	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	
				STEERING	X	X	
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	
Mazda	2006	Mazda5	X				
				ABS	X	X	
				AIRBAG	X	X	
				CLIMATE CONTROL	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	
				STEERING	X	X	
				TIRE PRESSURE MONITOR	X	X	
Mazda	2006	Mazda6	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	
				REMOTE KEYLESS ENTRY	X		
				TRANSMISSION	X	X	
Mazda	2006	MPV	X				
				ABS	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Mazda	2006	MX-5 Miata	X				
				ABS	X	X	

				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER / TPMS	X	X	
				REMOTE KEYLESS ENTRY	X		
				TRANSMISSION	X	X	
Mazda	2006	RX-8	X				
				ABS / TRACTION CONTROL	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	X
				REMOTE KEYLESS ENTRY	X		
				TRANSMISSION	X	X	
Mazda	2006	Tribute	X				
				4X4 CONTROL	X	X	
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GEM MODULE / TPMS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	X
				PARKING AID MOD	X	X	X
Mazda	2005	B-2300	X				
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GEM/CTM	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	X
Mazda	2005	B-3000	X				
				4X4 CONTROL	X	X	X
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GEM/CTM	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	X
Mazda	2005	B-4000	X				
				4X4 CONTROL	X	X	X
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GEM/CTM	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	X
Mazda	2005	Mazda3	X				
				ABS	X	X	
				AIRBAG	X	X	
				CLIMATE CONTROL	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	
				STEERING	X	X	
				TIRE PRESSURE MONITOR	X	X	
Mazda	2005	Mazda6	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	
Mazda	2005	Miata	X				
				ABS	X	X	
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Mazda	2005	MPV	X				
				ABS	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	

Mazda	2005	RX-8	X				
				ABS / TRACTION CONTROL	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	
Mazda	2005	Tribute	X				
				4X4 CONTROL	X	X	
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GEM/CTM	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	X
Mazda	2004	B-2300	X				
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	X
				PARKING AID MOD	X	X	X
Mazda	2004	B-3000	X				
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	X
Mazda	2004	B-4000	X				
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	X
Mazda	2004	Mazda3	X				
				ABS	X	X	
				AIRBAG	X	X	
				CLIMATE CONTROL	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	
Mazda	2004	Mazda6	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	
Mazda	2004	Miata	X				
				ABS	X	X	
				ENGINE	X	X	
Mazda	2004	MPV	X				
				GLOBAL OBDII	X	X	X
Mazda	2004	RX-8	X				
				ABS	X	X	
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	

Mazda	2004	Tribute	X				
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	
				PARKING AID MOD	X	X	X
Mazda	2003	B-2300	X				
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				REMT ANTI-THEFT	X	X	
Mazda	2003	B-3000	X				
				4X4 CONTROL	X	X	
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
REMT ANTI-THEFT	X	X					
Mazda	2003	B-4000	X				
				4X4 CONTROL	X	X	
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
REMT ANTI-THEFT	X	X					
Mazda	2003	Mazda6	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	
TRANSMISSION	X	X					
Mazda	2003	Miata	X				
				ABS	X	X	
				ENGINE	X	X	
Mazda	2003	MPV	X				
				GLOBAL OBDII	X	X	X
				ABS	X	X	
				ENGINE	X	X	
Mazda	2003	Protege	X				
				GLOBAL OBDII	X	X	X
				ABS	X	X	
Mazda	2003	Protege5	X				
				GLOBAL OBDII	X	X	X
				ENGINE	X	X	
Mazda	2003	Tribute	X				
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	
PARKING AID MOD	X	X					
Mazda	2002	626	X				
				ABS (4WABS)	X	X	
				ENGINE	X	X	X
Mazda	2002	B-2300	X				
				GLOBAL OBDII	X	X	X
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
Mazda	2002	B-2300	X				
				GLOBAL OBDII	X	X	X
				REMT ANTI-THEFT	X	X	
				GEM/CTM	X	X	
				ENGINE	X	X	X

Mazda	2002	B-3000	X				
				4X4 CONTROL	X	X	
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				REMT ANTI-THEFT	X	X	
Mazda	2002	B-4000	X				
				4X4 CONTROL	X	X	
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				REMT ANTI-THEFT	X	X	
Mazda	2002	Miata	X				
				ABS	X	X	
				ENGINE	X	X	
Mazda	2002	Millenia	X				
				GLOBAL OBDII	X	X	X
				ABS	X	X	
Mazda	2002	MPV	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Mazda	2002	Protege	X				
				ABS	X	X	
				ENGINE	X	X	
Mazda	2002	Protege5	X				
				GLOBAL OBDII	X	X	X
				ABS	X	X	
Mazda	2002	Tribute	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Mazda	2002	Tribute	X				
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	
Mazda	2001	626	X				
				ABS (4WABS)	X	X	
				ENGINE	X	X	X
Mazda	2001	B-2300	X				
				GLOBAL OBDII	X	X	X
				ABS (4WABS)	X	X	X
Mazda	2001	B-2300	X				
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				REMT ANTI-THEFT	X	X	
Mazda	2001	B-2500	X				
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
REMT ANTI-THEFT	X	X					
Mazda	2001	B-3000	X				
				4X4 CONTROL	X	X	
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				REMT ANTI-THEFT	X	X	
Mazda	2001	B-4000	X				
				4X4 CONTROL	X	X	
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	
Mazda	2001	B-4000	X				
				ENGINE	X	X	X

				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				REMT ANTI-THEFT	X	X	
Mazda	2001	Miata	X				
				ABS	X	X	
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Mazda	2001	Millenia	X				
				ABS	X	X	
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Mazda	2001	MPV	X				
				ABS	X	X	
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Mazda	2001	Protege	X				
				ABS	X	X	
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Mazda	2001	Tribute	X				
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				INSTRUMENT CLUSTER	X	X	
Mazda	2000	626	X				
				ABS (4WABS)	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Mazda	2000	B-2500	X				
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				PASSIVE ANTI-THEFT	X	X	
				REMT ANTI-THEFT	X	X	
Mazda	2000	B-3000	X				
				4X4 CONTROL	X	X	
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				PASSIVE ANTI-THEFT	X	X	
				REMT ANTI-THEFT	X	X	
Mazda	2000	B-4000	X				
				4X4 CONTROL	X	X	
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				PASSIVE ANTI-THEFT	X	X	
				REMT ANTI-THEFT	X	X	
Mazda	2000	Miata	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Mazda	2000	Millenia	X				
				ABS	X	X	
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Mazda	2000	MPV	X				
				ABS	X	X	
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Mazda	2000	Protege	X				
				ABS	X	X	
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Mazda	1999	626	X				
				ABS (4WABS)	X	X	
				ENGINE	X	X	X

				GLOBAL OBDII	X	X	X
Mazda	1999	B-2500	X	ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				PASSIVE ANTI-THEFT	X	X	
				REMT ANTI-THEFT	X	X	
Mazda	1999	B-3000	X	ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				PASSIVE ANTI-THEFT	X	X	
				REMT ANTI-THEFT	X	X	
Mazda	1999	B-4000	X	ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				PASSIVE ANTI-THEFT	X	X	
				REMT ANTI-THEFT	X	X	
Mazda	1999	Miata	X	ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Mazda	1999	Millenia	X	ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Mazda	1999	MPV	X	ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Mazda	1999	Protege	X	ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Mazda	1998	626	X	ABS (4WABS)	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Mazda	1998	B-2500	X	ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				REMT ANTI-THEFT	X	X	
Mazda	1998	B-3000	X	ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				REMT ANTI-THEFT	X	X	
Mazda	1998	B-4000	X	ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				REMT ANTI-THEFT	X	X	
Mazda	1998	Miata	X	ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Mazda	1998	Millenia	X	ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Mazda	1998	MPV	X	ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Mazda	1998	Protege	X	ENGINE	X	X	
				GLOBAL OBDII	X	X	X

Mazda	1997	626	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Mazda	1997	B-2300	X				
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				REMT ANTI-THEFT	X	X	
Mazda	1997	B-4000	X				
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				REMT ANTI-THEFT	X	X	
Mazda	1997	Miata	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Mazda	1997	Millenia	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Mazda	1997	MPV	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Mazda	1997	MX-6	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Mazda	1997	Protege	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Mazda	1996	626	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Mazda	1996	B-2300	X				
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				REMT ANTI-THEFT	X	X	
Mazda	1996	B-3000	X				
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				REMT ANTI-THEFT	X	X	
Mazda	1996	B-4000	X				
				ABS (4WABS)	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				GLOBAL OBDII	X	X	X
				REMT ANTI-THEFT	X	X	
Mazda	1996	Miata	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Mazda	1996	Millenia	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Mazda	1996	MPV	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Mazda	1996	MX-6	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Mazda	1996	Protege	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Mazda	1995	626	X				
				ENGINE	X	X	X
Mazda	1995	B-2300	X				
				ENGINE	X	X	X

				ABS (4WABS)	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				REMT ANTI-THEFT	X	X	
Mazda	1995	B-3000	X				
				ABS (4WABS)	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				REMT ANTI-THEFT	X	X	
Mazda	1995	B-4000	X				
				ABS (4WABS)	X	X	
				ENGINE	X	X	X
				GEM/CTM	X	X	
				REMT ANTI-THEFT	X	X	
Mazda	1995	Millenia	X				
				GLOBAL OBDII	X	X	X
Mazda	1995	Protege	X				
				GLOBAL OBDII	X	X	X
Mazda	1994	626	X				
				ENGINE	X	X	X
Mazda	1994	B-2300	X				
				ENGINE	X	X	X
Mazda	1994	B-3000	X				
				ENGINE	X	X	X
Mazda	1994	B-4000	X				
				ENGINE	X	X	X
Mitsubishi	2013	Lancer					
				ABS	X	X	X
				AIRBAG	X	X	X
				ASC	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				OCM	X	X	
				SHIFT LEVER	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRACTION CONTROL	X	X	X
				TRANSMISSION	X	X	
Mitsubishi	2013	Outlander					
				4WD	X	X	X
				ABS	X	X	X
				AIRBAG	X	X	X
				ASC	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				OCM	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Mitsubishi	2013	Outlander Sport					
				4WD	X	X	X
				4WS/EPS	X	X	
				AIRBAG	X	X	X
				ASC	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				OCM	X	X	
				OSS	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Mitsubishi	2012	Eclipse	X				
				AIRBAG	X	X	X
				ASC	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2012	Galant	X				
				AIRBAG	X	X	X
				ASC	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2012	Lancer	X				
				ABS	X	X	X

				AIRBAG	X	X	X
				ASC	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				OCM	X	X	
				SHIFT LEVER	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRACTION CONTROL	X	X	X
				TRANSMISSION	X	X	
Mitsubishi	2012	Outlander	X				
				4WD	X	X	X
				ABS	X	X	X
				AIRBAG	X	X	X
				ASC	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				OCM	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Mitsubishi	2012	Outlander Sport	X				
				4WD	X	X	X
				4WS/EPS	X	X	
				AIRBAG	X	X	X
				ASC	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				OCM	X	X	
				OSS	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Mitsubishi	2011	Eclipse	X				
				AIRBAG	X	X	X
				ASC	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2011	Endeavor	X				
				AIRBAG	X	X	X
				ASC	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2011	Galant	X				
				AIRBAG	X	X	X
				ASC	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2011	Lancer	X				
				ABS	X	X	X
				AIRBAG	X	X	X
				ASC	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				OCM	X	X	
				SHIFT LEVER	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRACTION CONTROL	X	X	X
				TRANSMISSION	X	X	
Mitsubishi	2011	Outlander	X				
				4WD	X	X	X
				ABS	X	X	X
				AIRBAG	X	X	X
				ASC	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				OCM	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Mitsubishi	2011	Outlander Sport	X				
				4WD	X	X	X

				4WS/EPS	X	X	
				AIRBAG	X	X	X
				ASC	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				OCM	X	X	
				OSS	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Mitsubishi	2010	Eclipse	X				
				AIRBAG	X	X	X
				ASC	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2010	Endeavor	X				
				AIRBAG	X	X	X
				ASC	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2010	Galant	X				
				AIRBAG	X	X	X
				ASC	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2010	Lancer	X				
				ABS	X	X	X
				AIRBAG	X	X	X
				ASC	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				OCM	X	X	
				SHIFT LEVER	X	X	
				TIRE PRESSURE MONITOR	X	X	
				TRACTION CONTROL	X	X	X
				TRANSMISSION	X	X	
Mitsubishi	2010	Outlander	X				
				4WD	X	X	X
				ABS	X	X	X
				AIRBAG	X	X	X
				ASC	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				OCM	X	X	
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	
Mitsubishi	2009	Eclipse	X				
				ABS	X	X	X
				AIRBAG	X	X	X
				ASC	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRACTION CONTROL	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	2009	Galant	X				
				ABS	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRACTION CONTROL	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	2009	Lancer	X				
				ABS	X	X	X
				AIRBAG	X	X	X
				ASC	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X

				IMMOBILIZER/KOS/TPMS	X	X	
				OCM	X	X	
				SHIFT LEVER	X	X	
				TRACTION CONTROL	X	X	X
				TRANSMISSION	X	X	
Mitsubishi	2009	Outlander	X				
				4WD	X	X	X
				ABS	X	X	X
				AIRBAG	X	X	X
				ASC	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER/KOS/TPMS	X	X	
				OCM	X	X	
				TRANSMISSION	X	X	
Mitsubishi	2009	Raider	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				OCCUPANT CLASS MODULE	X	X	X
				OCCUPANT RESTRAINT CTRL	X	X	X
				TRANSMISSION	X	X	X
				WIRELESS CTRL MODULE (TPMS)	X	X	X
Mitsubishi	2008	Eclipse	X				
				ABS	X	X	X
				AIRBAG	X	X	X
				ASC	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRACTION CONTROL	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	2008	Endeavor	X				
				ABS	X	X	X
				AIRBAG	X	X	X
				ASC	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRACTION CONTROL	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	2008	Galant	X				
				ABS	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRACTION CONTROL	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	2008	Lancer	X				
				ABS	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER/KOS/TPMS	X	X	
				OCM	X	X	
				TRANSMISSION	X	X	
Mitsubishi	2008	Outlander	X				
				4WD	X	X	
				ABS	X	X	X
				AIRBAG	X	X	X
				ASC	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER/KOS/TPMS	X	X	
				OCM	X	X	
				TRANSMISSION	X	X	
Mitsubishi	2008	Raider	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				OCCUPANT CLASS MODULE	X	X	X
				OCCUPANT RESTRAINT CTRL	X	X	X
				TRANSMISSION	X	X	X

				WIRELESS CTRL MODULE (TPMS)	X	X	X
Mitsubishi	2007	Eclipse	X	ABS	X	X	X
				AIRBAG	X	X	X
				CLIMATE (HVAC)	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				SUN ROOF	X	X	
				TIRE PRESSURE MONITOR	X	X	
				TRACTION CONTROL	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	2007	Endeavor	X	ABS	X	X	X
				ABS with ASC	X	X	X
				ABS/TCL	X	X	X
				AIRBAG	X	X	X
				CLIMATE (HVAC)	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2007	Galant	X	ABS	X	X	X
				AIRBAG	X	X	X
				CLIMATE (HVAC)	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRACTION CONTROL	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	2007	Lancer	X	ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	2007	Outlander	X	ABS	X	X	X
				ABS/ASC	X	X	X
				AIRBAG	X	X	X
				ALL WHEEL DRIVE	X	X	
				AUDIO CONTROL	X	X	
				CLIMATE (HVAC)	X	X	
				CRUISE CONTROL	X	X	
				ELEC TIME ALRM CTRL SYS	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HANDS FREE MODULE	X	X	
				IMMOBILIZER/KOS/TPMS	X	X	
				METER	X	X	
				OCCUPANT CLASSIFICATION	X	X	
				TRANSMISSION	X	X	
Mitsubishi	2007	Raider	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				OCCUPANT CLASS MODULE	X	X	X
				OCCUPANT RESTRAINT CTRL	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	2006	Eclipse	X	ABS	X	X	
				AIRBAG	X	X	
				CLIMATE (HVAC)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				METER	X	X	X
				TRACTION CONTROL	X	X	X

				TRANSMISSION	X	X	X
Mitsubishi	2006	Endeavor	X	ABS	X	X	X
				CLIMATE (HVAC)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				METER	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	2006	Galant	X	ABS	X	X	
				AIRBAG	X	X	
				CLIMATE (HVAC)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				METER	X	X	X
				TRACTION CONTROL	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	2006	Lancer	X	ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				SS4/4WD	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2006	Montero	X	ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				SS4/4WD	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	2006	Outlander	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2006	Raider	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				OCCUPANT RESTRAINT CTRL	X	X	X
				OCM	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	2005	Eclipse	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2005	Endeavor	X	ABS	X	X	X
				AIRBAG	X	X	
				CLIMATE (HVAC)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				METER	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	2005	Galant	X	ABS	X	X	X
				AIRBAG	X	X	
				CLIMATE (HVAC)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				METER	X	X	X
				TRANSMISSION	X	X	X

Mitsubishi	2005	Lancer	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2005	Montero	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				SS4/4WD	X	X	
				TIRE PRESSURE MONITOR	X	X	X
TRANSMISSION	X	X	X				
Mitsubishi	2005	Outlander	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	2004	Diamante	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2004	Eclipse	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2004	Endeavor	X				
				ABS	X	X	X
				CLIMATE (HVAC)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				TIRE PRESSURE MONITOR	X	X	X
TRANSMISSION	X	X	X				
Mitsubishi	2004	Galant	X				
				ABS	X	X	X
				AIRBAG	X	X	
				CLIMATE (HVAC)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				METER	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
TRANSMISSION	X	X	X				
Mitsubishi	2004	Lancer	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2004	Montero	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				SS4/4WD	X	X	
				TIRE PRESSURE MONITOR	X	X	X
TRANSMISSION	X	X	X				
Mitsubishi	2004	Montero Sport	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Mitsubishi	2004	Outlander	X				
				TRANSMISSION	X	X	X
Mitsubishi	2004	Outlander	X				
				ABS	X	X	X

				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2003	Diamante	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2003	Eclipse	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2003	Galant	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2003	Lancer	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2003	Montero	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				SS4/4WD	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2003	Montero Sport	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2003	Outlander	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	2002	Diamante	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2002	Eclipse	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2002	Galant	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2002	Lancer	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	2002	Mirage	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X

				TRANSMISSION	X	X	X
Mitsubishi	2002	Montero	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				SS4/4WD	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2002	Montero Sport	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	2001	Diamante	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
Mitsubishi	2001	Eclipse	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2001	Galant	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2001	Mirage	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	2001	Montero	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				SS4/4WD	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2001	Montero Sport	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2000	Diamante	X	ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
Mitsubishi	2000	Eclipse	X	ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2000	Galant	X	ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	2000	Mirage	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	2000	Montero	X	ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X

				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	2000	Montero Sport	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				TRANSMISSION	X	X	X
Mitsubishi	1999	3000GT	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Mitsubishi	1999	Diamante	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Mitsubishi	1999	Eclipse	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Mitsubishi	1999	Galant	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	1999	Mirage	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	1999	Montero	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	1999	Montero Sport	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	1998	3000GT	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Mitsubishi	1998	Diamante	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	1998	Eclipse	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Mitsubishi	1998	Galant	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Mitsubishi	1998	Mirage	X				
				ABS	X	X	X

				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	1998	Montero	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	1998	Montero Sport	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	1997	3000GT	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Mitsubishi	1997	Diamante	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	1997	Eclipse	X				
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Mitsubishi	1997	Galant	X				
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Mitsubishi	1997	Mirage	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	1997	Montero	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	1997	Montero Sport	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	1996	3000GT	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Mitsubishi	1996	Diamante	X				
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Mitsubishi	1996	Eclipse	X				
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Mitsubishi	1996	Galant	X				
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X

				TRANSMISSION	X	X	
Mitsubishi	1996	Mirage	X				
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Mitsubishi	1996	Montero	X				
				ABS	X	X	X
				AIRBAG	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	X
Mitsubishi	1995	3000GT	X				
				GLOBAL OBDII	X	X	X
Mitsubishi	1995	Eclipse	X				
				ENGINE	X	X	X
Mitsubishi	1995	Expo	X				
				ENGINE	X	X	X
Mitsubishi	1995	Mighty Max	X				
				ENGINE	X	X	
Mitsubishi	1995	Mirage	X				
				ENGINE	X	X	X
Mitsubishi	1994	3000GT	X				
				GLOBAL OBDII	X	X	X
Mitsubishi	1994	Expo	X				
				ENGINE	X	X	X
Mitsubishi	1994	Mighty Max	X				
				ENGINE	X	X	
Mitsubishi	1994	Mirage	X				
				ENGINE	X	X	X
Mitsubishi	1994	Precis	X				
				ENGINE	X	X	
Mitsubishi	1993	3000GT	X				
				ENGINE	X	X	
Mitsubishi	1993	Diamante	X				
				ENGINE	X	X	
Mitsubishi	1993	Eclipse	X				
				ENGINE	X	X	
Mitsubishi	1993	Expo	X				
				ENGINE	X	X	
Mitsubishi	1993	Expo LRV	X				
				ENGINE	X	X	
Mitsubishi	1993	Galant	X				
				ENGINE	X	X	
Mitsubishi	1993	Mighty Max	X				
				ENGINE	X	X	
Mitsubishi	1993	Mirage	X				
				ENGINE	X	X	
Mitsubishi	1993	Montero	X				
				ENGINE	X	X	
Mitsubishi	1993	Precis	X				
				ENGINE	X	X	
Mitsubishi	1992	3000GT	X				
				ENGINE	X	X	
Mitsubishi	1992	Diamante	X				
				ENGINE	X	X	
Mitsubishi	1992	Eclipse	X				
				ENGINE	X	X	
Mitsubishi	1992	Expo	X				
				ENGINE	X	X	
Mitsubishi	1992	Galant	X				
				ENGINE	X	X	
Mitsubishi	1992	Mighty Max	X				
				ENGINE	X	X	
Mitsubishi	1992	Mirage	X				
				ENGINE	X	X	
Mitsubishi	1992	Montero	X				
				ENGINE	X	X	
Mitsubishi	1992	Precis	X				
				ENGINE	X	X	
Mitsubishi	1991	3000GT	X				
				ENGINE	X	X	
Mitsubishi	1991	Eclipse	X				
				ENGINE	X	X	

Mitsubishi	1991	Galant	X				
				ENGINE	X	X	
Mitsubishi	1991	Mighty Max	X				
				ENGINE	X	X	
Mitsubishi	1991	Mirage	X				
				ENGINE	X	X	
Mitsubishi	1991	Montero	X				
				ENGINE	X	X	
Mitsubishi	1991	Precis	X				
				ENGINE	X	X	
Nissan	2013	370Z					
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2013	Altima					
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2013	Armada					
				4WD	X	X	X
				ABS	X	X	X
				Air Level Suspension	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2013	Cube					
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2013	Frontier	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2013	GT-R					
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2013	Juke					
				4WD	X	X	X
				ABS	X	X	X

			BODY CONTROL (TPMS)	X	X	X
			ELECTRONIC POWER STEERING	X	X	
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			HVAC	X	X	X
			INTEGRATED POWER DIST MOD	X	X	X
			METER	X	X	
			TRANSMISSION	X	X	
Nissan	2013	Leaf				
			ABS	X	X	X
			BODY CONTROL (TPMS)	X	X	X
			ELECTRIC PARKING BRAKE	X	X	
			ELECTRONIC POWER STEERING	X	X	
			HVAC	X	X	X
			INTEGRATED POWER DIST MOD	X	X	X
			LI-ION BATTERY CONTROLLER	X		
			METER	X	X	
			MOTOR CONTROLLER	X	X	
			ON BOARD CHARGER	X	X	
			VEHICLE CONTROL MODULE	X	X	
Nissan	2013	Maxima				
			ABS	X	X	X
			BODY CONTROL (TPMS)	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			HVAC	X	X	X
			INTEGRATED POWER DIST MOD	X	X	X
			METER	X	X	
			TRANSMISSION	X	X	
Nissan	2013	Murano				
			4WD	X	X	X
			ABS	X	X	X
			BODY CONTROL (TPMS)	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			HVAC	X	X	X
			INTEGRATED POWER DIST MOD	X	X	X
			METER	X	X	
			TRANSMISSION	X	X	
Nissan	2013	NV1500				
			ABS	X	X	X
			BODY CONTROL (TPMS)	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			HVAC	X	X	X
			INTEGRATED POWER DIST MOD	X	X	X
			METER	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	
Nissan	2013	NV2500				
			ABS	X	X	X
			BODY CONTROL (TPMS)	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			HVAC	X	X	X
			INTEGRATED POWER DIST MOD	X	X	X
			METER	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	
Nissan	2013	NV3500				
			ABS	X	X	X
			BODY CONTROL (TPMS)	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			HVAC	X	X	X
			INTEGRATED POWER DIST MOD	X	X	X
			METER	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	
Nissan	2013	Pathfinder				
			4WD	X	X	X
			ABS	X	X	X
			BODY CONTROL (TPMS)	X	X	X
			ELECTRONIC POWER STEERING	X	X	

				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2013	Quest					
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2013	Rogue					
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2013	Sentra					
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2013	Titan					
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2013	Versa					
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2013	Xterra	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2012	370Z	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2012	Altima	X				

				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2012	Armada	X				
				4WD	X	X	X
				ABS	X	X	X
				Air Level Suspension	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2012	Cube	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2012	Frontier	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2012	Juke	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2012	Leaf					
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRIC PARKING BRAKE	X	X	
				ELECTRONIC POWER STEERING	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				LI-ION BATTERY CONTROLLER	X		
				METER	X	X	
				MOTOR CONTROLLER	X	X	
				ON BOARD CHARGER	X	X	
				VEHICLE CONTROL MODULE	X	X	
Nissan	2012	Maxima	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2012	Murano	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X

				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2012	NV1500					
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Nissan	2012	NV2500	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Nissan	2012	NV3500	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Nissan	2012	Pathfinder	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2012	Quest	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2012	Rogue	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2012	Sentra	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2012	Titan	X				
				4WD	X	X	X

				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2012	Versa	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2012	Xterra	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2011	370Z	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2011	Altima	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				HYBRID	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2011	Armada	X				
				4WD	X	X	X
				ABS	X	X	X
				Air Level Suspension	X	X	X
				ALL MODE 4WD	X	X	
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2011	Cube	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2011	Frontier	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X

				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2011	GT-R					
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
Nissan	2011	Juke	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2011	Leaf					
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRIC PARKING BRAKE	X	X	
				ELECTRONIC POWER STEERING	X	X	
				HVAC	X	X	X
				LI-ION BATTERY CONTROLLER	X		
				METER	X	X	
				MOTOR CONTROLLER	X	X	
				ON BOARD CHARGER	X	X	
				VEHICLE CONTROL MODULE	X	X	
Nissan	2011	Maxima	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2011	Murano	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2011	Pathfinder	X				
				4WD	X	X	X
				ABS	X	X	X
				ALL MODE 4WD	X	X	
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2011	Quest	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2011	Rogue	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X

				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2011	Sentra	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2011	Titan	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2011	Versa	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2011	Xterra	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2010	370Z	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2010	Altima	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				HYBRID	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2010	Armada	X				
				4WD	X	X	X
				ABS	X	X	X
				Air Level Suspension	X	X	X
				ALL MODE 4WD	X	X	
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2010	Cube	X				
				ABS	X	X	X

				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2010	Frontier	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2010	GT-R	X				
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
Nissan	2010	Maxima	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2010	Murano	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2010	Pathfinder	X				
				4WD	X	X	X
				ABS	X	X	X
				ALL MODE 4WD	X	X	
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2010	Rogue	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2010	Sentra	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2010	Titan	X				
				4WD	X	X	X
				ABS	X	X	X
				ALL MODE 4WD	X	X	
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X

				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2010	Versa	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2010	Xterra	X				
				4WD	X	X	X
				ABS	X	X	X
				ALL MODE 4WD	X	X	
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2009	350Z	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Nissan	2009	370Z	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Nissan	2009	Altima	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				HYBRID	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2009	Armada	X				
				ABS	X	X	X
				Air Level Suspension	X	X	X
				ALL MODE 4WD	X	X	
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2009	Cube					
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2009	Frontier	X				

				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2009	GT-R					
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
Nissan	2009	Maxima	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2009	Murano	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2009	Pathfinder	X				
				4WD	X	X	X
				ABS	X	X	X
				ALL MODE 4WD	X	X	
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2009	Quest	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2009	Rogue	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2009	Sentra	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2009	Titan	X				
				ABS	X	X	X
				ALL MODE 4WD	X	X	
				BODY CONTROL (TPMS)	X	X	X

				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2009	Versa	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2009	Xterra	X				
				4WD	X	X	X
				ABS	X	X	X
				ALL MODE 4WD	X	X	
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2008	350Z	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Nissan	2008	Altima	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				HYBRID	X	X	
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2008	Armada	X				
				4WD	X	X	X
				ABS	X	X	X
				Air Level Suspension	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Nissan	2008	Frontier	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2008	Maxima	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Nissan	2008	Pathfinder	X				
				ABS	X	X	X
				ALL MODE 4WD	X	X	
				BODY CONTROL (TPMS)	X	X	X

				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2008	Quest	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2008	Rogue	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2008	Sentra	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2008	Titan	X				
				4WD	X	X	X
				ABS	X	X	X
				ALL MODE 4WD	X	X	
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Nissan	2008	Versa	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2008	Xterra	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Nissan	2007	350Z	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Nissan	2007	Altima	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				HVAC	X	X	X
				HYBRID	X	X	
				INTEGRATED POWER DIST MOD	X	X	X

				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2007	Armada	X				
				4WD	X	X	X
				ABS	X	X	X
				Air Level Suspension	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Nissan	2007	Frontier	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2007	Maxima	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Nissan	2007	Murano	X				
				4WD	X	X	X
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Nissan	2007	Pathfinder	X				
				ABS	X	X	X
				ALL MODE 4WD	X	X	
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2007	Quest	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Nissan	2007	Sentra	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2007	Titan	X				
				4WD	X	X	X
				ABS	X	X	X
				ALL MODE 4WD	X	X	
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Nissan	2007	Versa	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ELECTRONIC POWER STEERING	X	X	
				ENGINE	X	X	X

				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2007	Xterra	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				INTEGRATED POWER DIST MOD	X	X	X
				TRANSMISSION	X	X	
Nissan	2006	350Z	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2006	Altima	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2006	Armada	X				
				4WD	X	X	X
				ABS	X	X	X
				Air Level Suspension	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2006	Frontier	X				
				4WD	X	X	X
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2006	Maxima	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2006	Murano	X				
				4WD	X	X	X
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Nissan	2006	Pathfinder	X				
				ABS	X	X	X
				ALL MODE 4WD	X	X	
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	
				TRANSMISSION	X	X	
Nissan	2006	Quest	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2006	Sentra	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2006	Titan	X				
				4WD	X	X	X
				ABS	X	X	X

				ALL MODE 4WD	X	X	
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2006	Xterra	X				
				ABS	X	X	X
				BODY CONTROL (TPMS)	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2005	350Z	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Nissan	2005	Altima	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2005	Frontier	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Nissan	2005	Maxima	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2005	Murano	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Nissan	2005	Pathfinder	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Nissan	2005	Pathfinder Armada	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2005	Quest	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Nissan	2005	Sentra	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2005	Titan	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Nissan	2005	Xterra	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Nissan	2004	350Z	X				

				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Nissan	2004	Altima	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2004	Frontier	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	
Nissan	2004	Maxima	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2004	Murano	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Nissan	2004	Pathfinder	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	
Nissan	2004	Quest	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Nissan	2004	Sentra	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2004	Titan	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Nissan	2004	Xterra	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	
Nissan	2003	350Z	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Nissan	2003	Altima	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2003	Frontier	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	
Nissan	2003	Maxima	X				

				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2003	Murano	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Nissan	2003	Pathfinder	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	
Nissan	2003	Sentra	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2003	Xterra	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITOR	X	X	
				TRANSMISSION	X	X	
Nissan	2002	Altima	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2002	Frontier	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2002	Maxima	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2002	Pathfinder	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2002	Quest	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2002	Sentra	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2002	Xterra	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2001	Altima	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2001	Frontier	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2001	Maxima	X				
				ABS	X	X	X

				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2001	Pathfinder	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2001	Quest	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2001	Sentra	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2001	Xterra	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2000	Altima	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2000	Frontier	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2000	Maxima	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2000	Pathfinder	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2000	Quest	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2000	Sentra	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	2000	Xterra	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1999	Altima	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1999	Frontier	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1999	Maxima	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1999	Pathfinder	X				

				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1999	Quest	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1999	Sentra	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1998	200SX	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1998	240SX	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1998	Altima	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1998	Frontier	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1998	Maxima	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1998	Pathfinder	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1998	Quest	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1998	Sentra	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1997	200SX	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1997	240SX	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1997	Altima	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1997	Maxima	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1997	Pathfinder	X				
				ABS	X	X	X

				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1997	Pickup	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1997	Quest	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1997	Sentra	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1996	200SX	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1996	240SX	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1996	300ZX	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1996	Altima	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1996	Maxima	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1996	Pathfinder 2WD	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1996	Pathfinder 4WD	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1996	Quest	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Nissan	1996	Sentra	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Nissan	1996	Truck	X				
				ABS	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
Nissan	1995	200SX	X				
				ABS	X	X	X
				ENGINE	X	X	X
				TRANSMISSION	X	X	
Nissan	1995	240SX	X				
				ABS	X	X	X
				ENGINE	X	X	X
				TRANSMISSION	X	X	

Nissan	1995	300ZX	X				
				ABS	X	X	X
				ENGINE	X	X	X
				TRANSMISSION	X	X	
Nissan	1995	Altima	X				
				ABS	X	X	X
				ENGINE	X	X	X
				TRANSMISSION	X	X	
Nissan	1995	Maxima	X				
				ABS	X	X	X
				ENGINE	X	X	X
				TRANSMISSION	X	X	
Nissan	1995	Pathfinder	X				
				ABS	X	X	X
Nissan	1995	Quest	X				
				ABS	X	X	X
				ENGINE	X	X	X
				TRANSMISSION	X	X	
Nissan	1995	Sentra	X				
				ABS	X	X	X
				ENGINE	X	X	X
				TRANSMISSION	X	X	
Nissan	1995	Truck 2WD	X				
				ABS	X	X	X
Nissan	1995	Truck 4WD	X				
				ABS	X	X	X
Nissan	1994	240SX	X				
				ABS	X	X	X
				ENGINE	X	X	X
				TRANSMISSION	X	X	
Nissan	1994	300ZX	X				
				ABS	X	X	X
				ENGINE	X	X	X
				TRANSMISSION	X	X	
Nissan	1994	Altima	X				
				ABS	X	X	X
				ENGINE	X	X	X
				TRANSMISSION	X	X	
Nissan	1994	D21	X				
				ABS	X	X	X
Nissan	1994	Maxima	X				
				ABS	X	X	X
				ENGINE (VG30DE)	X	X	X
				TRANSMISSION	X	X	
Nissan	1994	Pathfinder	X				
				ABS	X	X	X
Nissan	1994	Quest	X				
				ABS	X	X	X
				ENGINE	X	X	X
				TRANSMISSION	X	X	
Nissan	1994	Sentra	X				
				ABS	X	X	X
				ENGINE	X	X	X
				TRANSMISSION	X	X	
Nissan	1993	240SX	X				
				ENGINE	X	X	X
				TRANSMISSION	X	X	
Nissan	1993	300ZX	X				
				ENGINE	X	X	X
				TRANSMISSION	X	X	
Nissan	1993	Altima	X				
				ENGINE	X	X	X
				TRANSMISSION	X	X	
Nissan	1993	Maxima	X				
				ENGINE (VG30DE)	X	X	X
				TRANSMISSION	X	X	
Nissan	1993	NX	X				
				ENGINE	X	X	X
				TRANSMISSION	X	X	
Nissan	1993	Quest	X				
				ENGINE	X	X	X
				TRANSMISSION	X	X	
Nissan	1993	Sentra	X				
				ENGINE	X	X	X

				TRANSMISSION	X	X	
Nissan	1992	240SX	X	ENGINE	X	X	X
				TRANSMISSION	X	X	
Nissan	1992	300ZX	X	ENGINE	X	X	X
				TRANSMISSION	X	X	
Nissan	1992	Maxima	X	ENGINE (VG30DE)	X	X	X
				TRANSMISSION	X	X	
Nissan	1992	NX	X	ENGINE	X	X	X
Nissan	1992	Sentra	X	ENGINE	X	X	X
Nissan	1992	Stanza	X	ENGINE	X	X	X
				TRANSMISSION	X	X	
Nissan	1991	240SX	X	ENGINE	X	X	X
				TRANSMISSION	X	X	
Nissan	1991	300ZX	X	ENGINE	X	X	X
				TRANSMISSION	X	X	
Nissan	1991	NX	X	ENGINE	X	X	X
Nissan	1991	Sentra	X	ENGINE	X	X	X
Nissan	1991	Stanza	X	ENGINE	X	X	X
				TRANSMISSION	X	X	
Nissan	1990	300ZX	X	ENGINE	X	X	X
				TRANSMISSION	X	X	
Nissan	1990	Stanza	X	ENGINE	X	X	X
				TRANSMISSION	X	X	
Scion	2014	FR-S		ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT POSITION DETECT	X	X	
				POWER SOURCE CONTROL	X	X	
				SMART KEY	X	X	
				THEFT DETERRENT	X		
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Scion	2014	iQ		ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				STARTING CONTROL	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Scion	2014	TC		ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X

			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			POWER SOURCE CONTROL	X	X	
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			STARTING CONTROL	X	X	X
			THEFT DETERRENT	X	X	X
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X
Scion	2014	xB				
			ABS/VSC/TRAC	X	X	X
			ACCESSORY GATEWAY	X	X	
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GLOBAL OBDII	X	X	X
			IMMOBILIZER	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			THEFT DETERRENT	X	X	X
			TIRE PRESSURE MONITOR	X	X	X
Scion	2014	xD				
			ABS/VSC/TRAC	X	X	X
			ACCESSORY GATEWAY	X	X	
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GLOBAL OBDII	X	X	X
			IMMOBILIZER	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			THEFT DETERRENT	X	X	X
			TIRE PRESSURE MONITOR	X	X	X
Scion	2013	FR-S				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			METER	X	X	X
			OCCUPANT POSITION DETECT	X	X	
			POWER SOURCE CONTROL	X	X	
			SMART KEY	X	X	
			THEFT DETERRENT	X		
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X
Scion	2013	iQ				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			ELECTRIC POWER STEERING	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GLOBAL OBDII	X	X	X
			IMMOBILIZER	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			THEFT DETERRENT	X	X	X
			TIRE PRESSURE MONITOR	X	X	X
Scion	2013	TC				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X

				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				STARTING CONTROL	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Scion	2013	xB					
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Scion	2013	xD					
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Scion	2012	iQ	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Scion	2012	TC	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				STARTING CONTROL	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Scion	2012	xB	X				
				ABS/VSC/TRAC	X	X	X

				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Scion	2012	xD	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Scion	2011	TC	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				STARTING CONTROL	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Scion	2011	xB	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Scion	2011	xD	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X

Scion	2010	TC	X				
				ABS/VSC/TRAC	X	X	X
				AIRBAG	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				REMOTE ENGINE STARTER	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Scion	2010	xB	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Scion	2010	xD	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Scion	2009	TC	X				
				ABS/VSC/TRAC	X	X	X
				AIRBAG	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Scion	2009	xB	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Scion	2009	xD	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X

Scion	2008	TC	X				
				ABS/VSC/TRAC	X	X	X
				AIRBAG	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Scion	2008	xB	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Scion	2008	xD	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Scion	2007	TC	X				
				ABS/VSC/TRAC	X	X	X
				AIRBAG	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Scion	2006	TC	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
Scion	2006	xA	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
Scion	2006	xB	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
Scion	2005	TC	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
Scion	2005	xA	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Scion	2005	xB	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Scion	2004	xA	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X

Scion	2004	xB	X			
				ABS/VSC/TRAC	X	X X
				ENGINE/TRANS	X	X X
				GLOBAL OBDII	X	X X
Subaru	2013	BRZ				
				ABS/VSC/TRAC	X	X X
				AIR CONDITIONING	X	X X
				AIRBAG	X	X X
				BODY CONTROL MODULE	X	X X
				COMBINATION METER	X	X X
				CRUISE CONTROL	X	X
				ELECTRIC POWER STEERING	X	X X
				ENGINE	X	X X
				GLOBAL OBDII	X	X X
				OCCUPANT POSITION DETECT	X	X
				TIRE PRESSURE MONITOR	X	X
				TRANSMISSION	X	X X
Subaru	2013	Forester				
				AIRBAG SYSTEM	X	X
				BODY INTEG MOD AND CAN DIAG	X	X X
				BRAKE CONTROL SYSTEM	X	X X
				ENGINE	X	X X
				GLOBAL OBDII	X	X X
				TIRE PRESSURE MONITORING SYSTEM	X	X X
				TRANSMISSION	X	X
Subaru	2013	Impreza				
				AIRBAG SYSTEM	X	X
				BODY INTEG MOD AND CAN DIAG	X	X X
				BRAKE CONTROL SYSTEM	X	X X
				COMBINATION METER	X	X
				ENGINE	X	X X
				GLOBAL OBDII	X	X X
				OCCUPANT DETECTION SYSTEM	X	X
				TIRE PRESSURE MONITORING SYSTEM	X	X X
Subaru	2013	Legacy				
				AIR CONDITIONER	X	X
				AIRBAG SYSTEM	X	X
				BODY INTEG MOD AND CAN DIAG	X	X X
				BRAKE CONTROL SYSTEM	X	X X
				ELECTRIC PARKING BRAKE	X	X
				ENGINE	X	X X
				GLOBAL OBDII	X	X X
				TIRE PRESSURE MONITORING SYSTEM	X	X X
Subaru	2013	Outback				
				AIR CONDITIONER	X	X
				AIRBAG SYSTEM	X	X
				BODY INTEG MOD AND CAN DIAG	X	X X
				BRAKE CONTROL SYSTEM	X	X X
				ELECTRIC PARKING BRAKE	X	X
				ENGINE	X	X X
				GLOBAL OBDII	X	X X
				TIRE PRESSURE MONITORING SYSTEM	X	X X
Subaru	2013	Tribeca				
				AIRBAG SYSTEM	X	X
				BODY INTEG MOD AND CAN DIAG	X	X X
				BRAKE CONTROL SYSTEM	X	X X
				ENGINE	X	X X
				GLOBAL OBDII	X	X X
				TIRE PRESSURE MONITORING SYSTEM	X	X X
				TRANSMISSION	X	X
Subaru	2013	XV Crosstrek				
				AIRBAG SYSTEM	X	X
				BODY INTEG MOD AND CAN DIAG	X	X X
				BRAKE CONTROL SYSTEM	X	X X
				COMBINATION METER	X	X
				ENGINE	X	X X
				GLOBAL OBDII	X	X X
				OCCUPANT DETECTION SYSTEM	X	X
				TIRE PRESSURE MONITORING SYSTEM	X	X X
Subaru	2012	Forester				
				AIRBAG SYSTEM	X	X
				BODY INTEG MOD AND CAN DIAG	X	X X
				BRAKE CONTROL SYSTEM	X	X X
				ENGINE	X	X X

			GLOBAL OBDII	X	X	X
			TIRE PRESSURE MONITORING SYSTEM	X	X	X
			TRANSMISSION	X	X	
Subaru	2012	Impreza				
			AIRBAG SYSTEM	X	X	
			BODY INTEG MOD AND CAN DIAG	X	X	X
			BRAKE CONTROL SYSTEM	X	X	X
			COMBINATION METER	X	X	
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			OCCUPANT DETECTION SYSTEM	X	X	
			TIRE PRESSURE MONITORING SYSTEM	X	X	X
Subaru	2012	Legacy				
			AIR CONDITIONER	X	X	
			AIRBAG SYSTEM	X	X	
			BODY INTEG MOD AND CAN DIAG	X	X	X
			BRAKE CONTROL SYSTEM	X	X	X
			ELECTRIC PARKING BRAKE	X	X	
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			TIRE PRESSURE MONITORING SYSTEM	X	X	X
			TRANSMISSION	X	X	
Subaru	2012	Outback				
			AIR CONDITIONER	X	X	
			AIRBAG SYSTEM	X	X	
			BODY INTEG MOD AND CAN DIAG	X	X	X
			BRAKE CONTROL SYSTEM	X	X	X
			ELECTRIC PARKING BRAKE	X	X	
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			TIRE PRESSURE MONITORING SYSTEM	X	X	X
			TRANSMISSION	X	X	
Subaru	2012	Tribeca				
			AIRBAG SYSTEM	X	X	
			BODY INTEG MOD AND CAN DIAG	X	X	X
			BRAKE CONTROL SYSTEM	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			TIRE PRESSURE MONITORING SYSTEM	X	X	X
			TRANSMISSION	X	X	
Subaru	2011	Forester				
			AIRBAG SYSTEM	X	X	
			BODY INTEG MOD AND CAN DIAG	X	X	X
			BRAKE CONTROL SYSTEM	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			TIRE PRESSURE MONITORING SYSTEM	X	X	X
			TRANSMISSION	X	X	
Subaru	2011	Impreza				
			AIRBAG SYSTEM	X	X	
			BODY INTEG MOD AND CAN DIAG	X	X	X
			BRAKE CONTROL SYSTEM	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			TIRE PRESSURE MONITORING SYSTEM	X	X	X
			TRANSMISSION	X	X	
Subaru	2011	Legacy				
			AIR CONDITIONER	X	X	
			AIRBAG SYSTEM	X	X	
			BODY INTEG MOD AND CAN DIAG	X	X	X
			BRAKE CONTROL SYSTEM	X	X	X
			ELECTRIC PARKING BRAKE	X	X	
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			TIRE PRESSURE MONITORING SYSTEM	X	X	X
			TRANSMISSION	X	X	
Subaru	2011	Outback				
			AIR CONDITIONER	X	X	
			AIRBAG SYSTEM	X	X	
			BODY INTEG MOD AND CAN DIAG	X	X	X
			BRAKE CONTROL SYSTEM	X	X	X
			ELECTRIC PARKING BRAKE	X	X	
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X

			TIRE PRESSURE MONITORING SYSTEM	X	X	X
			TRANSMISSION	X	X	
Subaru	2011	Tribeca				
			AIRBAG SYSTEM	X	X	
			BODY INTEG MOD AND CAN DIAG	X	X	X
			BRAKE CONTROL SYSTEM	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			TIRE PRESSURE MONITORING SYSTEM	X	X	X
			TRANSMISSION	X	X	
Subaru	2010	Forester				
			AIRBAG SYSTEM	X	X	
			BODY INTEG MOD AND CAN DIAG	X	X	X
			BRAKE CONTROL SYSTEM	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			TIRE PRESSURE MONITORING SYSTEM	X	X	X
			TRANSMISSION	X	X	
Subaru	2010	Impreza				
			AIRBAG SYSTEM	X	X	
			BODY INTEG MOD AND CAN DIAG	X	X	X
			BRAKE CONTROL SYSTEM	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			TIRE PRESSURE MONITORING SYSTEM	X	X	X
			TRANSMISSION	X	X	
Subaru	2010	Legacy				
			AIR CONDITIONER	X	X	
			AIRBAG SYSTEM	X	X	
			BODY INTEG MOD AND CAN DIAG	X	X	X
			BRAKE CONTROL SYSTEM	X	X	X
			ELECTRIC PARKING BRAKE	X	X	
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			TIRE PRESSURE MONITORING SYSTEM	X	X	X
			TRANSMISSION	X	X	
Subaru	2010	Outback				
			AIR CONDITIONER	X	X	
			AIRBAG SYSTEM	X	X	
			BODY INTEG MOD AND CAN DIAG	X	X	X
			BRAKE CONTROL SYSTEM	X	X	X
			ELECTRIC PARKING BRAKE	X	X	
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			TIRE PRESSURE MONITORING SYSTEM	X	X	X
			TRANSMISSION	X	X	
Subaru	2010	Tribeca				
			AIRBAG SYSTEM	X	X	
			BODY INTEG MOD AND CAN DIAG	X	X	X
			BRAKE CONTROL SYSTEM	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			TIRE PRESSURE MONITORING SYSTEM	X	X	X
			TRANSMISSION	X	X	
Subaru	2009	Forester				
			AIRBAG SYSTEM	X	X	
			BODY INTEG MOD AND CAN DIAG	X	X	X
			BRAKE CONTROL SYSTEM	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			TIRE PRESSURE MONITORING SYSTEM	X	X	X
			TRANSMISSION	X	X	
Subaru	2009	Impreza				
			AIRBAG SYSTEM	X	X	
			BODY INTEG MOD AND CAN DIAG	X	X	X
			BRAKE CONTROL SYSTEM	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			TIRE PRESSURE MONITORING SYSTEM	X	X	X
			TRANSMISSION	X	X	
Subaru	2009	Legacy				
			AIRBAG SYSTEM	X	X	
			BRAKE CONTROL SYSTEM	X	X	X
			ENGINE	X	X	X

				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITORING SYSTEM	X	X	X
				TRANSMISSION	X	X	
Subaru	2009	Outback		AIRBAG SYSTEM	X	X	
				BRAKE CONTROL SYSTEM	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITORING SYSTEM	X	X	X
				TRANSMISSION	X	X	
Subaru	2009	Tribeca		AIRBAG SYSTEM	X	X	
				BODY INTEG MOD AND CAN DIAG	X	X	X
				BRAKE CONTROL SYSTEM	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITORING SYSTEM	X	X	X
				TRANSMISSION	X	X	
Subaru	2008	Forester		AIRBAG SYSTEM	X	X	
				BRAKE CONTROL SYSTEM	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITORING SYSTEM	X	X	X
				TRANSMISSION	X	X	
Subaru	2008	Impreza		AIRBAG SYSTEM	X	X	
				BRAKE CONTROL SYSTEM	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITORING SYSTEM	X	X	X
				TRANSMISSION	X	X	
Subaru	2008	Impreza		AIRBAG SYSTEM	X	X	
				BRAKE CONTROL SYSTEM	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITORING SYSTEM	X	X	X
				TRANSMISSION	X	X	
Subaru	2008	Legacy		AIRBAG SYSTEM	X	X	
				BRAKE CONTROL SYSTEM	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITORING SYSTEM	X	X	X
				TRANSMISSION	X	X	
Subaru	2008	Outback		AIRBAG SYSTEM	X	X	
				BRAKE CONTROL SYSTEM	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITORING SYSTEM	X	X	X
				TRANSMISSION	X	X	
Subaru	2008	Tribeca		AIRBAG SYSTEM	X	X	
				BODY INTEG MOD AND CAN DIAG	X	X	X
				BRAKE CONTROL SYSTEM	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITORING SYSTEM	X	X	X
				TRANSMISSION	X	X	
Subaru	2007	B9 Tribeca		AIRBAG SYSTEM	X	X	
				BODY INTEG MOD AND CAN DIAG	X	X	X
				BRAKE CONTROL SYSTEM	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITORING SYSTEM	X	X	X
				TRANSMISSION	X	X	
Subaru	2007	Forester	X	AIRBAG SYSTEM	X	X	
				BRAKE CONTROL SYSTEM	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Subaru	2007	Impreza	X	AIRBAG SYSTEM	X	X	
				BRAKE CONTROL SYSTEM	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	

Subaru	2007	Legacy	X				
				AIRBAG SYSTEM	X	X	
				BRAKE CONTROL SYSTEM	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITORING SYSTEM	X	X	X
				TRANSMISSION	X	X	
Subaru	2007	Outback	X				
				AIRBAG SYSTEM	X	X	
				BRAKE CONTROL SYSTEM	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITORING SYSTEM	X	X	X
				TRANSMISSION	X	X	
Subaru	2006	B9 Tribeca	X				
				AIRBAG SYSTEM	X	X	
				BODY INTEG MOD AND CAN DIAG	X	X	X
				BRAKE CONTROL SYSTEM	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITORING SYSTEM	X	X	X
				TRANSMISSION	X	X	
Subaru	2006	Baja	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Subaru	2006	Forester	X				
				AIRBAG SYSTEM	X	X	
				BRAKE CONTROL SYSTEM	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Subaru	2006	Impreza	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Subaru	2006	Legacy	X				
				AIRBAG SYSTEM	X	X	
				BRAKE CONTROL SYSTEM	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITORING SYSTEM	X	X	X
				TRANSMISSION	X	X	
Subaru	2006	Outback	X				
				AIRBAG SYSTEM	X	X	
				BRAKE CONTROL SYSTEM	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITORING SYSTEM	X	X	X
				TRANSMISSION	X	X	
Subaru	2005	Baja	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Subaru	2005	Forester	X				
				BRAKE CONTROL SYSTEM	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Subaru	2005	Impreza	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Subaru	2005	Legacy	X				
				AIRBAG SYSTEM	X	X	
				BRAKE CONTROL SYSTEM	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITORING SYSTEM	X	X	X
				TRANSMISSION	X	X	
Subaru	2005	Outback	X				
				AIRBAG SYSTEM	X	X	
				BRAKE CONTROL SYSTEM	X	X	X
				ENGINE	X	X	X

				GLOBAL OBDII	X	X	X
				TIRE PRESSURE MONITORING SYSTEM	X	X	X
				TRANSMISSION	X	X	
Subaru	2004	Baja	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Subaru	2004	Forester	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Subaru	2004	Impreza	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Subaru	2004	Legacy	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Subaru	2004	Outback	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Subaru	2003	Baja	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Subaru	2003	Forester	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Subaru	2003	Impreza	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Subaru	2003	Legacy	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Subaru	2003	Outback	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Subaru	2002	Forester	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Subaru	2002	Impreza	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Subaru	2002	Legacy	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Subaru	2002	Outback	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Subaru	2001	Forester	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Subaru	2001	Impreza	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Subaru	2001	Legacy	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Subaru	2001	Outback	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X

				TRANSMISSION	X	X	
Subaru	2000	Forester	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Subaru	2000	Impreza	X				
				GLOBAL OBDII	X	X	X
Subaru	2000	Legacy	X				
				GLOBAL OBDII	X	X	X
Subaru	2000	Outback	X				
				GLOBAL OBDII	X	X	X
Subaru	1999	Forester	X				
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				TRANSMISSION	X	X	
Subaru	1999	Impreza	X				
				GLOBAL OBDII	X	X	X
Subaru	1999	Legacy	X				
				GLOBAL OBDII	X	X	X
Subaru	1998	Forester	X				
				GLOBAL OBDII	X	X	X
Subaru	1998	Impreza	X				
				GLOBAL OBDII	X	X	X
Subaru	1998	Legacy	X				
				GLOBAL OBDII	X	X	X
Subaru	1997	Impreza	X				
				GLOBAL OBDII	X	X	X
Subaru	1997	Legacy	X				
				GLOBAL OBDII	X	X	X
Subaru	1997	SVX	X				
				GLOBAL OBDII	X	X	X
Subaru	1996	Impreza	X				
				GLOBAL OBDII	X	X	X
Subaru	1996	Legacy	X				
				GLOBAL OBDII	X	X	X
Subaru	1996	SVX	X				
				GLOBAL OBDII	X	X	X
Subaru	1995	Impreza	X				
				ENGINE	X	X	
				GLOBAL OBDII	X	X	X
Subaru	1995	Legacy	X				
				GLOBAL OBDII	X	X	X
Subaru	1994	Impreza	X				
				ENGINE	X	X	
Subaru	1994	Legacy	X				
				ENGINE	X	X	
Subaru	1994	Loyale	X				
				ENGINE	X	X	
Subaru	1993	Impreza	X				
				ENGINE	X	X	
Subaru	1993	Legacy	X				
				ENGINE	X	X	
Subaru	1993	Loyale	X				
				ENGINE	X	X	
Subaru	1993	SVX	X				
				ENGINE	X	X	
Subaru	1992	Legacy	X				
				ENGINE	X	X	
Subaru	1992	Loyale	X				
				ENGINE	X	X	
Subaru	1991	Legacy	X				
				ENGINE	X	X	
Subaru	1991	Loyale	X				
				ENGINE	X	X	
Subaru	1991	XT	X				
				ENGINE	X	X	
Subaru	1990	Justy	X				
				ENGINE	X	X	
Subaru	1990	Legacy	X				
				ENGINE	X	X	
Subaru	1990	Loyale	X				
				ENGINE	X	X	
Subaru	1990	XT	X				
				ENGINE	X	X	

USA Asian Vehicle Applications Guide - August 2014

Subaru	1990	XT6	X				
				ENGINE	X	X	
Subaru	1989	3 Door	X				
				ENGINE	X	X	
Subaru	1989	DL	X				
				ENGINE	X	X	
Subaru	1989	GL	X				
				ENGINE	X	X	
Subaru	1989	GL-10	X				
				ENGINE	X	X	
Subaru	1989	Justy	X				
				ENGINE	X	X	
Subaru	1989	Sedan	X				
				ENGINE	X	X	
Subaru	1989	Station Wagon	X				
				ENGINE	X	X	
Subaru	1989	Touring Wagon	X				
				ENGINE	X	X	
Subaru	1989	XT	X				
				ENGINE	X	X	
Subaru	1989	XT6	X				
				ENGINE	X	X	
Subaru	1988	3 Door	X				
				ENGINE	X	X	
Subaru	1988	GL	X				
				ENGINE	X	X	
Subaru	1988	Justy	X				
				ENGINE	X	X	
Subaru	1988	Sedan	X				
				ENGINE	X	X	
Subaru	1988	Station Wagon	X				
				ENGINE	X	X	
Subaru	1988	XT	X				
				ENGINE	X	X	
Subaru	1988	XT6	X				
				ENGINE	X	X	
Subaru	1987	3 Door	X				
				ENGINE	X	X	
Subaru	1987	DL	X				
				ENGINE	X	X	
Subaru	1987	GL	X				
				ENGINE	X	X	
Subaru	1987	Sedan	X				
				ENGINE	X	X	
Subaru	1987	Station Wagon	X				
				ENGINE	X	X	
Suzuki	2013	Grand Vitara					
				GLOBAL OBDII	X	X	X
Suzuki	2013	Kizashi					
				GLOBAL OBDII	X	X	X
Suzuki	2013	SX4					
				GLOBAL OBDII	X	X	X
Suzuki	2012	Grand Vitara					
				GLOBAL OBDII	X	X	X
Suzuki	2012	Kizashi					
				GLOBAL OBDII	X	X	X
Suzuki	2012	SX4					
				GLOBAL OBDII	X	X	X
Suzuki	2011	Equator					
				GLOBAL OBDII	X	X	X
Suzuki	2011	Grand Vitara					
				GLOBAL OBDII	X	X	X
Suzuki	2011	Kizashi					
				GLOBAL OBDII	X	X	X
Suzuki	2011	SX4					
				GLOBAL OBDII	X	X	X
Suzuki	2010	SX4					
				GLOBAL OBDII	X	X	X
Suzuki	2009	Equator					
				GLOBAL OBDII	X	X	X
Suzuki	2009	Grand Vitara					
				GLOBAL OBDII	X	X	X
Suzuki	2009	SX4					
				GLOBAL OBDII	X	X	X

Suzuki	2009	XL-7		GLOBAL OBDII	X	X	X
Suzuki	2008	Forenza		GLOBAL OBDII	X	X	X
Suzuki	2008	Grand Vitara		GLOBAL OBDII	X	X	X
Suzuki	2008	Reno		GLOBAL OBDII	X	X	X
Suzuki	2008	SX4		GLOBAL OBDII	X	X	X
Suzuki	2008	XL-7		GLOBAL OBDII	X	X	X
Suzuki	2007	Aerio		GLOBAL OBDII	X	X	X
Suzuki	2007	Forenza	X	GLOBAL OBDII	X	X	X
Suzuki	2007	Grand Vitara		GLOBAL OBDII	X	X	X
Suzuki	2007	Reno		GLOBAL OBDII	X	X	X
Suzuki	2007	SX4		GLOBAL OBDII	X	X	X
Suzuki	2007	XL7		GLOBAL OBDII	X	X	X
Suzuki	2006	Aerio	X	GLOBAL OBDII	X	X	X
Suzuki	2006	Forenza	X	GLOBAL OBDII	X	X	X
Suzuki	2006	Grand Vitara	X	GLOBAL OBDII	X	X	X
Suzuki	2006	Reno	X	GLOBAL OBDII	X	X	X
Suzuki	2006	Verona	X	GLOBAL OBDII	X	X	X
Suzuki	2006	Vitara		GLOBAL OBDII	X	X	X
Suzuki	2006	XL-7	X	GLOBAL OBDII	X	X	X
Suzuki	2005	Aerio		GLOBAL OBDII	X	X	X
Suzuki	2005	Forenza	X	GLOBAL OBDII	X	X	X
Suzuki	2005	Grand Vitara	X	GLOBAL OBDII	X	X	X
Suzuki	2005	Verona	X	GLOBAL OBDII	X	X	X
Suzuki	2005	Vitara		GLOBAL OBDII	X	X	X
Suzuki	2005	XL-7	X	GLOBAL OBDII	X	X	X
Suzuki	2004	Aerio		GLOBAL OBDII	X	X	X
Suzuki	2004	Forenza	X	GLOBAL OBDII	X	X	X
Suzuki	2004	Grand Vitara	X	GLOBAL OBDII	X	X	X
Suzuki	2004	Verona	X	GLOBAL OBDII	X	X	X
Suzuki	2004	Vitara	X	GLOBAL OBDII	X	X	X
Suzuki	2004	XL-7	X	GLOBAL OBDII	X	X	X
Suzuki	2003	Aerio	X	GLOBAL OBDII	X	X	X
Suzuki	2003	Grand Vitara	X	GLOBAL OBDII	X	X	X
Suzuki	2003	Vitara	X	GLOBAL OBDII	X	X	X
Suzuki	2003	XL-7	X	GLOBAL OBDII	X	X	X
Suzuki	2002	Aerio	X	GLOBAL OBDII	X	X	X
Suzuki	2002	Esteem	X	GLOBAL OBDII	X	X	X

USA Asian Vehicle Applications Guide - August 2014

Suzuki	2002	Grand Vitara	X				
				GLOBAL OBDII	X	X	X
Suzuki	2002	Vitara	X				
				GLOBAL OBDII	X	X	X
Suzuki	2002	XL-7	X				
				GLOBAL OBDII	X	X	X
Suzuki	2001	Esteem	X				
				GLOBAL OBDII	X	X	X
Suzuki	2001	Grand Vitara	X				
				GLOBAL OBDII	X	X	X
Suzuki	2001	Swift	X				
				GLOBAL OBDII	X	X	X
Suzuki	2001	Vitara	X				
				GLOBAL OBDII	X	X	X
Suzuki	2000	Esteem	X				
				GLOBAL OBDII	X	X	X
Suzuki	2000	Grand Vitara	X				
				GLOBAL OBDII	X	X	X
Suzuki	2000	Swift	X				
				GLOBAL OBDII	X	X	X
Suzuki	2000	Vitara	X				
				GLOBAL OBDII	X	X	X
Suzuki	1999	Esteem	X				
				GLOBAL OBDII	X	X	X
Suzuki	1999	Grand Vitara	X				
				GLOBAL OBDII	X	X	X
Suzuki	1999	Swift	X				
				GLOBAL OBDII	X	X	X
Suzuki	1999	Vitara	X				
				GLOBAL OBDII	X	X	X
Suzuki	1998	Esteem	X				
				GLOBAL OBDII	X	X	X
Suzuki	1998	Sidekick	X				
				GLOBAL OBDII	X	X	X
Suzuki	1998	Swift	X				
				GLOBAL OBDII	X	X	X
Suzuki	1998	X-90	X				
				GLOBAL OBDII	X	X	X
Suzuki	1997	Esteem	X				
				GLOBAL OBDII	X	X	X
Suzuki	1997	Sidekick	X				
				GLOBAL OBDII	X	X	X
Suzuki	1997	Swift	X				
				GLOBAL OBDII	X	X	X
Suzuki	1997	X-90	X				
				GLOBAL OBDII	X	X	X
Suzuki	1996	Esteem	X				
				GLOBAL OBDII	X	X	X
Suzuki	1996	Sidekick	X				
				GLOBAL OBDII	X	X	X
Suzuki	1996	Swift	X				
				GLOBAL OBDII	X	X	X
Suzuki	1996	X-90	X				
				GLOBAL OBDII	X	X	X
Toyota	2014	4Runner					
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				KINETIC DYNAMIC SUSPENSION SYS	X	X	
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				STARTING CONTROL	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2014	Avalon					

			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GATEWAY CAN	X	X	
			GLOBAL OBDII	X	X	X
			HYBRID VEHICLE	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			PM1 GATEWAY	X	X	
			POWER SOURCE CONTROL	X	X	
			PRE-COLLISION	X	X	
			PRE-COLLISION 2	X	X	
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			STARTING CONTROL	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X
Toyota	2014	Camry				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GATEWAY CAN	X	X	
			GLOBAL OBDII	X	X	X
			HYBRID VEHICLE	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			PM1 GATEWAY	X	X	
			POWER SOURCE CONTROL	X	X	
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			STARTING CONTROL	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X
Toyota	2014	Corolla				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CHARGING CONTROL	X	X	
			CRUISE CONTROL	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GLOBAL OBDII	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			POWER SOURCE CONTROL	X	X	
			SMART KEY	X	X	X
			STARTING CONTROL	X	X	X
			TIRE PRESSURE MONITOR	X	X	X
Toyota	2014	FJ Cruiser				
			ABS/VSC/TRAC	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			ENGINE/TRANSMISSION	X	X	X
			GLOBAL OBDII	X	X	X
			IMMOBILIZER	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			TIRE PRESSURE MONITOR	X	X	X
Toyota	2014	Highlander				
			4WD	X	X	X
			ABS/VSC/TRAC	X	X	X

			ACCESSORY GATEWAY	X	X	
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GATEWAY CAN	X	X	
			GLOBAL OBDII	X	X	X
			HYBRID VEHICLE	X	X	X
			IMMOBILIZER	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			PM1 GATEWAY	X	X	
			POWER SOURCE CONTROL	X	X	
			PRE-COLLISION 2	X	X	
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			STARTING CONTROL	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X
Toyota	2014	Land Cruiser				
			ABS/VSC/TRAC	X	X	X
			ACCESSORY GATEWAY	X	X	
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GATEWAY CAN	X	X	
			GLOBAL OBDII	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			PRE-COLLISION	X	X	
			SMART KEY	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			VARIABLE GEAR RATIO STEER	X	X	X
Toyota	2014	Prius				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			ELECTRIC POWER STEERING	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GLOBAL OBDII	X	X	X
			HYBRID VEHICLE	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			PLUG IN CONTROL	X	X	
			PM1 GATEWAY	X	X	
			PM2 GATEWAY	X	X	
			POWER SOURCE CONTROL	X	X	
			PRE-COLLISION	X	X	
			PRE-COLLISION 2	X	X	
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			TELEMATICS	X	X	
			THEFT DETERRENT	X	X	X
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	
Toyota	2014	Prius C				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GLOBAL OBDII	X	X	X
			HYBRID VEHICLE	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X

			POWER SOURCE CONTROL	X	X	
			SMART KEY	X	X	X
			THEFT DETERRENT	X	X	X
			TIRE PRESSURE MONITOR	X	X	X
Toyota	2014	Prius V				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			ELECTRIC POWER STEERING	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GLOBAL OBDII	X	X	X
			HYBRID VEHICLE	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			PM1 GATEWAY	X	X	
			PM2 GATEWAY	X	X	
			POWER SOURCE CONTROL	X	X	
			PRE-COLLISION	X	X	
			PRE-COLLISION 2	X	X	
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			TELEMATICS	X	X	
			THEFT DETERRENT	X	X	X
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	
Toyota	2014	Rav4				
			4WD	X	X	X
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CHARGING CONTROL	X	X	
			CRUISE CONTROL	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ELECTRIC VEHICLE	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GLOBAL OBDII	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			PM1 GATEWAY	X	X	
			POWER SOURCE CONTROL	X	X	
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			STARTING CONTROL	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	
Toyota	2014	Sequoia				
			ABS/VSC/TRAC	X	X	X
			ACCESSORY GATEWAY	X	X	
			AIR CONDITIONING	X	X	X
			AIR SUSPENSION	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			ELECTRIC POWER STEERING	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GATEWAY V	X	X	
			GLOBAL OBDII	X	X	X
			IMMOBILIZER	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			TIRE PRESSURE MONITOR	X	X	X
Toyota	2014	Sienna				
			4WD	X	X	X
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X

			PM1 GATEWAY	X	X	
			PM2 GATEWAY	X	X	
			POWER SOURCE CONTROL	X	X	
			PRE-COLLISION	X	X	
			PRE-COLLISION 2	X	X	
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			STARTING CONTROL	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X
Toyota	2014	Tacoma				
			ABS/VSC/TRAC	X	X	X
			AIRBAG	X	X	X
			CRUISE CONTROL	X	X	
			ENGINE/TRANSMISSION	X	X	X
			GLOBAL OBDII	X	X	X
			IMMOBILIZER	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			TIRE PRESSURE MONITOR	X	X	X
Toyota	2014	Tundra				
			ABS/VSC/TRAC	X	X	X
			ACCESSORY GATEWAY	X	X	
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			ENGINE/TRANSMISSION	X	X	X
			GATEWAY CAN	X	X	
			GLOBAL OBDII	X	X	X
			IMMOBILIZER	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			TIRE PRESSURE MONITOR	X	X	X
Toyota	2014	Venza				
			4WD	X	X	X
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			GLOBAL OBDII	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			PM1 GATEWAY	X	X	
			PM2 GATEWAY	X	X	
			POWER SOURCE CONTROL	X	X	
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			STARTING CONTROL	X	X	X
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X
Toyota	2014	Yaris				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GLOBAL OBDII	X	X	X
			IMMOBILIZER	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			THEFT DETERRENT	X	X	X
			TIRE PRESSURE MONITOR	X	X	X
Toyota	2013	4Runner				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X

			CRUISE CONTROL	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GLOBAL OBDII	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			PM2 GATEWAY	X	X	
			POWER SOURCE CONTROL	X	X	
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			STARTING CONTROL	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
Toyota	2013	Avalon				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GATEWAY CAN	X	X	
			GLOBAL OBDII	X	X	X
			HYBRID VEHICLE	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			PM1 GATEWAY	X	X	
			POWER SOURCE CONTROL	X	X	
			PRE-COLLISION	X	X	
			PRE-COLLISION 2	X	X	
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			STARTING CONTROL	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X
Toyota	2013	Camry				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GATEWAY CAN	X	X	
			GLOBAL OBDII	X	X	X
			HYBRID VEHICLE	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			PM1 GATEWAY	X	X	
			POWER SOURCE CONTROL	X	X	
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			STARTING CONTROL	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X
Toyota	2013	Corolla				
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GLOBAL OBDII	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			THEFT DETERRENT	X	X	X
			TIRE PRESSURE MONITOR	X	X	X

Toyota	2013	FJ Cruiser	ABS/VSC/TRAC	X	X	X			
			AIRBAG	X	X	X			
			BODY CONTROL MODULE	X	X	X			
			CRUISE CONTROL	X	X				
			ENGINE/TRANSMISSION	X	X	X			
			GLOBAL OBDII	X	X	X			
			IMMOBILIZER	X	X	X			
			METER	X	X	X			
			OCCUPANT CLASSIFICATION	X	X	X			
			TIRE PRESSURE MONITOR	X	X	X			
			Toyota	2013	Highlander	4WD	X	X	X
ABS/VSC/TRAC	X	X				X			
ACCESSORY GATEWAY	X	X							
AIR CONDITIONING	X	X				X			
AIRBAG	X	X				X			
BODY CONTROL MODULE	X	X				X			
CRUISE CONTROL	X	X							
ELECTRIC POWER STEERING	X	X				X			
ENGINE	X	X				X			
ENGINE/TRANSMISSION	X	X				X			
GLOBAL OBDII	X	X				X			
HYBRID VEHICLE	X	X				X			
IMMOBILIZER	X	X				X			
METER	X	X				X			
OCCUPANT CLASSIFICATION	X	X				X			
SMART KEY	X	X				X			
THEFT DETERRENT	X	X				X			
TIRE PRESSURE MONITOR	X	X				X			
TRANSMISSION	X	X				X			
Toyota	2013	Land Cruiser				ABS/VSC/TRAC	X	X	X
						ACCESSORY GATEWAY	X	X	
			AIR CONDITIONING	X	X	X			
			AIRBAG	X	X	X			
			BODY CONTROL MODULE	X	X	X			
			CRUISE CONTROL	X	X				
			ENGINE/TRANSMISSION	X	X	X			
			GATEWAY CAN	X	X				
			GLOBAL OBDII	X	X	X			
			METER	X	X	X			
			OCCUPANT CLASSIFICATION	X	X	X			
			PRE-COLLISION	X	X				
			SMART KEY	X	X	X			
			TELEMATICS	X	X				
			TIRE PRESSURE MONITOR	X	X	X			
			VARIABLE GEAR RATIO STEER	X	X	X			
			Toyota	2013	Matrix	4WD	X	X	X
ABS/VSC/TRAC	X	X				X			
ACCESSORY GATEWAY	X	X							
AIR CONDITIONING	X	X				X			
AIRBAG	X	X				X			
BODY CONTROL MODULE	X	X				X			
CRUISE CONTROL	X	X							
ELECTRIC POWER STEERING	X	X				X			
ENGINE/TRANSMISSION	X	X				X			
GLOBAL OBDII	X	X				X			
IMMOBILIZER	X	X				X			
METER	X	X				X			
OCCUPANT CLASSIFICATION	X	X				X			
THEFT DETERRENT	X	X				X			
TIRE PRESSURE MONITOR	X	X				X			
Toyota	2013	Prius	ABS/VSC/TRAC	X	X	X			
			AIR CONDITIONING	X	X	X			
			AIRBAG	X	X	X			
			BODY CONTROL MODULE	X	X	X			
			CRUISE CONTROL	X	X				
			ELECTRIC POWER STEERING	X	X	X			
			ENGINE/TRANSMISSION	X	X	X			
			GLOBAL OBDII	X	X	X			
			HYBRID VEHICLE	X	X	X			

				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PLUG IN CONTROL	X	X	
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Toyota	2013	Prius C					
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				SMART KEY	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2013	Prius V					
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Toyota	2013	Rav4	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CHARGING CONTROL	X	X	
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ELECTRIC VEHICLE	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				STARTING CONTROL	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X

			TRANSMISSION	X	X	
Toyota	2013	Sequoia	ABS/VSC/TRAC	X	X	X
			ACCESSORY GATEWAY	X	X	
			AIR CONDITIONING	X	X	X
			AIR SUSPENSION	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GATEWAY V	X	X	
			GLOBAL OBDII	X	X	X
			IMMOBILIZER	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			TIRE PRESSURE MONITOR	X	X	X
Toyota	2013	Sienna	4WD	X	X	X
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X
			GATEWAY CAN	X	X	
			GLOBAL OBDII	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			PM1 GATEWAY	X	X	
			PM2 GATEWAY	X	X	
			POWER SOURCE CONTROL	X	X	
			PRE-COLLISION	X	X	
			PRE-COLLISION 2	X	X	
			REMOTE ENGINE STARTER	X	X	
			SMART KEY	X	X	X
			STARTING CONTROL	X	X	X
			TELEMATICS	X	X	
			TIRE PRESSURE MONITOR	X	X	X
			TRANSMISSION	X	X	X
Toyota	2013	Tacoma	ABS/VSC/TRAC	X	X	X
			AIRBAG	X	X	X
			CRUISE CONTROL	X	X	
			ENGINE/TRANSMISSION	X	X	X
			GLOBAL OBDII	X	X	X
			IMMOBILIZER	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			TIRE PRESSURE MONITOR	X	X	X
Toyota	2013	Tundra	ABS/VSC/TRAC	X	X	X
			ACCESSORY GATEWAY	X	X	
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE/TRANSMISSION	X	X	X
			GLOBAL OBDII	X	X	X
			IMMOBILIZER	X	X	X
			METER	X	X	X
			OCCUPANT CLASSIFICATION	X	X	X
			TIRE PRESSURE MONITOR	X	X	X
Toyota	2013	Venza	4WD	X	X	X
			ABS/VSC/TRAC	X	X	X
			AIR CONDITIONING	X	X	X
			AIRBAG	X	X	X
			BODY CONTROL MODULE	X	X	X
			CRUISE CONTROL	X	X	
			ELECTRIC POWER STEERING	X	X	X
			ENGINE	X	X	X

				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				STARTING CONTROL	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Toyota	2013	Yaris					
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2012	4Runner	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				KINETIC DYNAMIC SUSPENSION SYS	X	X	
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				STARTING CONTROL	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2012	Avalon	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Toyota	2012	Camry	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	

				POWER SOURCE CONTROL	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				STARTING CONTROL	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Toyota	2012	Corolla	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				SMART KEY	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2012	FJ Cruiser	X				
				ABS/VSC/TRAC	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2012	Highlander	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				SMART KEY	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Toyota	2012	Land Cruiser	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PRE-COLLISION	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2012	Matrix	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X

				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2012	Prius	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PLUG IN CONTROL	X	X	
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Toyota	2012	Prius C	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				SMART KEY	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2012	Prius V	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X

				TRANSMISSION	X	X	
Toyota	2012	Rav4	X	4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				SMART KEY	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2012	Sequoia	X	ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY V	X	X	
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2012	Sienna	X	4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				STARTING CONTROL	X	X	X
				TELEMATICS	X	X	
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Toyota	2012	Tacoma	X	ABS/VSC/TRAC	X	X	X
				AIRBAG	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2012	Tundra	X	ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X

				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2012	Venza	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				STARTING CONTROL	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Toyota	2012	Yaris	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				REMOTE ENGINE STARTER	X	X	
				STARTING CONTROL	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2011	4Runner	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				KINETIC DYNAMIC SUSPENSION SYS	X	X	
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				STARTING CONTROL	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2011	Avalon	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE	X	X	X
				GATEWAY	X	X	X

				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Toyota	2011	Camry	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				SMART KEY	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Toyota	2011	Corolla	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				SMART KEY	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2011	FJ Cruiser	X				
				ABS/VSC/TRAC	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2011	Highlander	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				SMART KEY	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Toyota	2011	Land Cruiser	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X

				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PRE-COLLISION	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2011	Matrix	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2011	Prius	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Toyota	2011	Rav4	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				SMART KEY	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2011	Sequoia	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X

				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2011	Sienna	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				STARTING CONTROL	X	X	X
				TELEMATICS	X	X	
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Toyota	2011	Tacoma	X				
				ABS/VSC/TRAC	X	X	X
				AIRBAG	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2011	Tundra	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2011	Venza	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				REMOTE ENGINE STARTER	X	X	

				SMART KEY	X	X	X
				STARTING CONTROL	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Toyota	2011	Yaris	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2010	4Runner	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				STARTING CONTROL	X	X	X
				TELEMATICS	X	X	
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2010	Avalon	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Toyota	2010	Camry	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				SMART KEY	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Toyota	2010	Corolla	X				

				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				SMART KEY	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2010	FJ Cruiser	X				
				ABS/VSC/TRAC	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2010	Highlander	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				SMART KEY	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Toyota	2010	Land Cruiser	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PRE-COLLISION	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2010	Matrix	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X

				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2010	Prius	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				PM2 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				PRE-COLLISION	X	X	
				PRE-COLLISION 2	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				TELEMATICS	X	X	
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	
Toyota	2010	Rav4	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				SMART KEY	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2010	Sequoia	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2010	Sienna	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				REMOTE ENGINE STARTER	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2010	Tacoma	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIRBAG	X	X	X
				CRUISE CONTROL	X	X	

				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2010	Tundra	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2010	Venza	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				STARTING CONTROL	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Toyota	2010	Yaris	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2009	4Runner	X				
				ABS/VSC/TRAC	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELEC MODULATED SUSPENSION	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2009	Avalon	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				TIRE PRESSURE MONITOR	X	X	X

				TRANSMISSION	X	X	X
Toyota	2009	Camry	X	ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				SMART KEY	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Toyota	2009	Corolla	X	ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				SMART KEY	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2009	FJ Cruiser	X	ABS/VSC/TRAC	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2009	Highlander	X	4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				SMART KEY	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Toyota	2009	Land Cruiser	X	ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PRE-COLLISION	X	X	
				SMART KEY	X	X	X

				TIRE PRESSURE MONITOR	X	X	X
Toyota	2009	Matrix	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY CAN	X	X	
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2009	Prius	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				HYBRID VEHICLE BATTERY	X	X	
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				REMOTE ENGINE STARTER	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION CONTROL	X	X	
Toyota	2009	Rav4	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				SMART KEY	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2009	Sequoia	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Toyota	2009	Sienna	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X		X

				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2009	Tacoma	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIRBAG	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2009	Tundra	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Toyota	2009	Venza	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				PM1 GATEWAY	X	X	
				POWER SOURCE CONTROL	X	X	
				REMOTE ENGINE STARTER	X	X	
				SMART KEY	X	X	X
				STARTING CONTROL	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Toyota	2009	Yaris	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2008	4Runner	X				
				ABS/VSC/TRAC	X	X	X
				AIR SUSPENSION	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2008	Avalon	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE	X	X	X
				GATEWAY	X	X	X

				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Toyota	2008	Camry	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				SLIDE ROOF	X	X	
				SMART KEY	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Toyota	2008	Corolla	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2008	FJ Cruiser	X				
				ABS/VSC/TRAC	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2008	Highlander	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				SLIDE ROOF	X	X	
				SMART KEY	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2008	Land Cruiser	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY	X	X	
				GLOBAL OBDII	X	X	X
				METER	X	X	X

				OCCUPANT CLASSIFICATION	X	X	X
				PRE-COLLISION	X	X	
				SLIDE ROOF	X	X	
				SMART KEY	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2008	Matrix	X				
				ABS/VSC/TRAC	X	X	X
				AIRBAG	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2008	Prius	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				HYBRID VEHICLE BATTERY	X	X	
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION CONTROL	X	X	
Toyota	2008	Rav4	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				SLIDE ROOF	X	X	
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2008	Sequoia	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIR SUSPENSION	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				SLIDE ROOF	X	X	
				THEFT DETERRENT	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Toyota	2008	Sienna	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				TELEMATICS	X	X	

				TIRE PRESSURE MONITOR	X	X	X
Toyota	2008	Solara	X	ABS/VSC/TRAC	X	X	X
				AIRBAG	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2008	Tacoma	X	ABS/VSC/TRAC	X	X	X
				AIRBAG	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2008	Tundra	X	ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ENGINE	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				SLIDE ROOF	X	X	
				THEFT DETERRENT	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION	X	X	X
Toyota	2008	Yaris	X	ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				METER	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2007	4Runner	X	ABS/VSC/TRAC	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				THEFT DETERRENT MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2007	Avalon	X	ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				COMBINATION SWITCH	X		
				DRIVER SEAT MODULE	X		
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				LEFT MIRROR	X		
				MIRROR LEFT	X		
				MIRROR RIGHT	X		
				POWER SOURCE CONTROL	X	X	
				SMART KEY SYSTEM	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2007	Camry	X	ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	

				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				IMMOBILIZER	X	X	
				SLIDE ROOF	X	X	
				SMART KEY	X	X	X
				SMART KEY SYSTEM	X	X	
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION 2GR-FE	X	X	X
Toyota	2007	Camry HV	X				
				ACCESSORY GATEWAY	X	X	
				SMART KEY	X	X	X
				THEFT DETERRENT	X	X	X
Toyota	2007	Camry Solara	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIRBAG	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				METER	X	X	X
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2007	Corolla	X				
				ABS/VSC/TRAC	X	X	X
				AIRBAG	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
Toyota	2007	FJ Cruiser	X				
				ABS/VSC/TRAC	X	X	X
				AIRBAG	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2007	Highlander	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				DRIVER DOOR	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				THEFT DETERRENT MODULE	X	X	
Toyota	2007	Highlander HV	X				
				GATEWAY	X	X	X
Toyota	2007	Land Cruiser	X				
				ABS/VSC/TRAC	X	X	X
				DRIVER DOOR	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				THEFT DETERRENT MODULE	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2007	Matrix	X				
				ABS/VSC/TRAC	X	X	X
				AIRBAG	X	X	X
				ENGINE	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
Toyota	2007	Prius	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				ELECTRIC POWER STEERING	X	X	X

				ENGINE/TRANSMISSION	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				HYBRID VEHICLE BATTERY	X	X	
				POWER SOURCE CONTROL	X	X	
				SMART KEY SYSTEM	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2007	Rav4	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				SLIDE ROOF	X	X	
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2007	Sequoia	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				SLIDE ROOF	X		
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2007	Sienna	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	
				DRIVER SEAT MODULE	X		
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				LEFT MIRROR	X		
				METER	X		X
				MIRROR LEFT	X		
				MIRROR RIGHT	X		
				RIGHT MIRROR	X		
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2007	Tacoma	X				
				ABS/VSC/TRAC	X	X	X
				AIRBAG	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2007	Tundra	X				
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				ENGINE	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				SLIDE ROOF	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2007	Yaris	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	X
				AIRBAG	X	X	X
				BODY CONTROL MODULE	X	X	X
				ELECTRIC POWER STEERING	X	X	X

				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				THEFT DETERRENT	X	X	X
				THEFT DETERRENT MODULE	X	X	
Toyota	2006	4Runner	X				
				ABS/VSC/TRAC	X	X	X
				AIR SUSPENSION	X	X	X
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				OCCUPANT CLASSIFICATION	X	X	X
				SMART KEY SYSTEM	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2006	Avalon	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				COMBINATION SWITCH	X		
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				INSTRUMENT PANEL	X		X
				MIRROR LEFT	X		
				MIRROR RIGHT	X		
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				RAIN SENSOR	X		
				SMART KEY SYSTEM	X	X	
Toyota	2006	Camry	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				OCCUPANT CLASSIFICATION	X	X	X
Toyota	2006	Camry Solara	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				OCCUPANT CLASSIFICATION	X	X	X
Toyota	2006	Corolla	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				OCCUPANT CLASSIFICATION	X	X	X
Toyota	2006	Highlander	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				DRIVER DOOR	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANS	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				IMMOBILIZER	X	X	
				INSTRUMENT PANEL	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT MODULE	X	X	
Toyota	2006	Highlander Hyb	X				
				GATEWAY	X	X	X
Toyota	2006	Land Cruiser	X				
				ABS/VSC/TRAC	X	X	X
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				DRIVER DOOR	X	X	
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	

				SMART KEY SYSTEM	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2006	Matrix	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				OCCUPANT CLASSIFICATION	X	X	X
Toyota	2006	Prius	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				HYBRID VEHICLE BATTERY	X	X	
				IMMOBILIZER	X	X	
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				SMART KEY SYSTEM	X	X	
				TIRE PRESSURE MONITOR	X	X	X
				TRANSMISSION CONTROL	X	X	
Toyota	2006	Rav4	X				
				4WD	X	X	X
				ABS/VSC/TRAC	X	X	X
				ACCESSORY GATEWAY	X	X	
				AIR CONDITIONING	X	X	X
				BODY CONTROL MODULE	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				OCCUPANT CLASSIFICATION	X	X	X
				SLIDE ROOF	X	X	
				THEFT DETERRENT	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2006	Sequoia	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				AIR SUSPENSION	X	X	X
				BODY CONTROL MODULE	X	X	X
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				SLIDE ROOF	X		
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2006	Sienna	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				DRIVER SEAT MODULE	X		
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
Toyota	2006	Tacoma	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2006	Tundra	X				
				ABS/VSC/TRAC	X	X	X
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X

				TIRE PRESSURE MONITOR	X	X	X
Toyota	2005	4Runner	X	ABS/VSC/TRAC	X	X	X
				AIR SUSPENSION	X	X	X
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2005	Avalon	X	ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				COMBINATION SWITCH	X		
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				INSTRUMENT PANEL	X		X
				MIRROR LEFT	X		
				MIRROR RIGHT	X		
				OCCUPANT CLASSIFICATION	X	X	X
				POWER SOURCE CONTROL	X	X	
				RAIN SENSOR	X		
				SMART KEY SYSTEM	X	X	
Toyota	2005	Camry	X	ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				OCCUPANT CLASSIFICATION	X	X	X
Toyota	2005	Camry Solara	X	ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				OCCUPANT CLASSIFICATION	X	X	X
Toyota	2005	Celica	X	ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2005	Corolla	X	ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				OCCUPANT CLASSIFICATION	X	X	X
Toyota	2005	Echo	X	ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2005	Highlander	X	ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				DRIVER DOOR	X	X	
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				INSTRUMENT PANEL	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT MODULE	X	X	
Toyota	2005	Land Cruiser	X	ABS/VSC/TRAC	X	X	X
				BODY CONTROL MODULE	X	X	X
				DRIVER DOOR	X	X	
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				THEFT DETERRENT MODULE	X	X	
				TILT & TELESCOPE MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X

Toyota	2005	Matrix	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				OCCUPANT CLASSIFICATION	X	X	X
Toyota	2005	MR2 Spyder	X				
				ABS/VSC/TRAC	X	X	X
				ELEC HYD POWER STEERING	X	X	
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				SEQ MANUAL TRANS	X	X	
Toyota	2005	Prius	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				HYBRID VEHICLE BATTERY	X	X	
				IMMOBILIZER	X	X	
				POWER SOURCE CONTROL	X	X	
				SMART KEY SYSTEM	X	X	
				TRANSMISSION CONTROL	X	X	
Toyota	2005	Rav4	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
Toyota	2005	Sequoia	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				AIR SUSPENSION	X	X	X
				BODY CONTROL MODULE	X	X	X
				DRIVER DOOR	X	X	
				DRIVER SEAT MODULE	X		
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				SLIDE ROOF	X		
Toyota	2005	Sienna	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
				OCCUPANT CLASSIFICATION	X	X	X
Toyota	2005	Tacoma	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2005	Tundra	X				
				ABS/VSC/TRAC	X	X	X
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GLOBAL OBDII	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2004	4Runner	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				AIR SUSPENSION	X	X	X
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X

				IMMOBILIZER	X	X	
				THEFT DETERRENT MODULE	X	X	
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2004	Avalon	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2004	Camry	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				OCCUPANT CLASSIFICATION	X	X	X
Toyota	2004	Camry Solara	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				OCCUPANT CLASSIFICATION	X	X	X
Toyota	2004	Celica	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2004	Corolla	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2004	Echo	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2004	Highlander	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				INSTRUMENT PANEL	X		X
				OCCUPANT CLASSIFICATION	X	X	X
				THEFT DETERRENT MODULE	X	X	
Toyota	2004	Land Cruiser	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				DRIVER DOOR	X	X	
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				THEFT DETERRENT MODULE	X	X	
				TILT & TELESCOPE MODULE	X	X	
Toyota	2004	Matrix	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2004	MR2 Spyder	X				
				ABS/VSC/TRAC	X	X	X
				ELEC HYD POWER STEERING	X	X	
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				SEQ MANUAL TRANS	X	X	
Toyota	2004	Prius	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				CRUISE CONTROL	X	X	
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANSMISSION	X	X	X
				GATEWAY	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	X
				HYBRID VEHICLE BATTERY	X	X	
				IMMOBILIZER	X	X	
				POWER SOURCE CONTROL	X	X	
				SMART KEY SYSTEM	X	X	

				TRANSMISSION CONTROL	X	X	
Toyota	2004	Rav4	X	ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
Toyota	2004	Sequoia	X	ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				DRIVER DOOR	X	X	
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				SLIDE ROOF	X		
				TIRE PRESSURE MONITOR	X	X	X
Toyota	2004	Sienna	X	ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
Toyota	2004	Tacoma	X	ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2004	Tundra	X	ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2003	4Runner	X	ABS/VSC/TRAC	X	X	X
				AIR SUSPENSION	X	X	X
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				THEFT DETERRENT MODULE	X	X	
Toyota	2003	Avalon	X	ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2003	Camry	X	ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2003	Camry Solara	X	ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2003	Celica	X	ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2003	Corolla	X	ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2003	Echo	X	ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2003	Highlander	X	ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
				THEFT DETERRENT MODULE	X	X	
Toyota	2003	Land Cruiser	X	ABS/VSC/TRAC	X	X	X

				BODY CONTROL MODULE	X	X	X
				DRIVER DOOR	X	X	
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				IMMOBILIZER	X	X	
				THEFT DETERRENT MODULE	X	X	
				TILT & TELESCOPE MODULE	X	X	
Toyota	2003	Matrix	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2003	MR2 Spyder	X				
				ABS/VSC/TRAC	X	X	X
				ELEC HYD POWER STEERING	X	X	
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				SEQ MANUAL TRANS	X	X	
Toyota	2003	Prius	X				
				ABS/VSC/TRAC	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	
				HYBRID VEHICLE BATTERY	X	X	
Toyota	2003	Rav4	X				
				ABS/VSC/TRAC	X	X	X
				ELECTRIC VEHICLE	X	X	
				ELECTRIC VEHICLE BATTERY	X	X	
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2003	Sequoia	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				DRIVER DOOR	X	X	
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				SLIDE ROOF	X		
Toyota	2003	Sienna	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2003	Tacoma	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2003	Tundra	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2002	4Runner	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2002	Avalon	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2002	Camry	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2002	Camry Solara	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2002	Celica	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2002	Corolla	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2002	Echo	X				

				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2002	Highlander	X				
				ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
				THEFT DETERRENT MODULE	X	X	
Toyota	2002	Land Cruiser	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2002	MR2 Spyder	X				
				ABS/VSC/TRAC	X	X	X
				ELEC HYD POWER STEERING	X	X	
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				SEQ MANUAL TRANS	X	X	
Toyota	2002	Prius	X				
				ABS/VSC/TRAC	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	
				HYBRID VEHICLE BATTERY	X	X	
Toyota	2002	Rav4	X				
				ABS/VSC/TRAC	X	X	X
				ELECTRIC VEHICLE	X	X	
				ELECTRIC VEHICLE BATTERY	X	X	
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2002	Sequoia	X				
				ABS/VSC/TRAC	X	X	X
				BODY CONTROL MODULE	X	X	X
				DRIVER DOOR	X	X	
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				SLIDE ROOF	X		
Toyota	2002	Sienna	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2002	Tacoma	X				
				ABS	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2002	Tundra	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2001	4Runner	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2001	Avalon	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2001	Camry	X				
				ABS (ND)	X	X	X
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2001	Camry Solara	X				
				ABS (ND)	X	X	X
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2001	Celica	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X

				GLOBAL OBDII	X	X	X
Toyota	2001	Corolla	X	ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2001	Echo	X	ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2001	Highlander	X	ABS/VSC/TRAC	X	X	X
				AIR CONDITIONING	X	X	
				BODY CONTROL MODULE	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				INSTRUMENT PANEL	X		X
Toyota	2001	Land Cruiser	X	ABS	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2001	MR2 Spyder	X	ABS/VSC/TRAC	X	X	X
				ELEC HYD POWER STEERING	X	X	
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				SEQ MANUAL TRANS	X	X	
Toyota	2001	Prius	X	ABS/VSC/TRAC	X	X	X
				ELECTRIC POWER STEERING	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				HYBRID VEHICLE	X	X	
				HYBRID VEHICLE BATTERY	X	X	
Toyota	2001	Rav4	X	ABS/VSC/TRAC	X	X	X
				ELECTRIC VEHICLE	X	X	
				ELECTRIC VEHICLE BATTERY	X	X	
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2001	Sequoia	X	ABS/VSC/TRAC	X	X	X
				BODY CONTROL MODULE	X	X	X
				DRIVER DOOR	X	X	
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
				SLIDE ROOF	X		
Toyota	2001	Sienna	X	ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2001	Tacoma	X	ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2001	Tundra	X	ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2000	4Runner	X	ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2000	Avalon	X	ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2000	Camry	X	ABS (ND)	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2000	Camry Solara	X	ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2000	Celica	X	ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X

Toyota	2000	Corolla	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2000	Echo	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2000	Land Cruiser	X				
				ABS	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2000	MR2 Spyder	X				
				ABS/VSC/TRAC	X	X	X
				ELEC HYD POWER STEERING	X	X	
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2000	Rav4	X				
				ELECTRIC VEHICLE BATTERY	X	X	
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2000	Sienna	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2000	Tacoma	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	2000	Tundra	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1999	4Runner	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1999	Avalon	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1999	Camry	X				
				ABS (ND)	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1999	Camry Solara	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1999	Celica	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1999	Corolla	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1999	Land Cruiser	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1999	Rav4	X				
				ELECTRIC VEHICLE BATTERY	X	X	
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1999	Sienna	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1999	Tacoma	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1998	4Runner	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1998	Avalon	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1998	Camry	X				
				ABS (ND)	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1998	Celica	X				

				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1998	Corolla	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1998	Land Cruiser	X				
				ABS/VSC/TRAC	X	X	X
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1998	Rav4	X				
				ELECTRIC VEHICLE BATTERY	X	X	
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1998	Sienna	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1998	Supra	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1998	T-100	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1998	Tacoma	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1998	Tercel	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1997	4Runner	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1997	Avalon	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1997	Camry	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1997	Celica	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1997	Corolla	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1997	Land Cruiser	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1997	Paseo	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1997	Previa	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1997	Rav4	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1997	Supra	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1997	T-100	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1997	Tacoma	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1997	Tercel	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1996	4Runner	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1996	Avalon	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1996	Camry	X				

				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1996	Celica	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1996	Corolla	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1996	Land Cruiser	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1996	Paseo	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1996	Previa	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1996	Rav4	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1996	Supra	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1996	T-100	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1996	Tacoma	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1996	Tercel	X				
				ENGINE/TRANS	X	X	X
				GLOBAL OBDII	X	X	X
Toyota	1995	4Runner	X				
				ENGINE (DATA)	X		
Toyota	1995	Avalon	X				
				ENGINE/TRANS	X	X	X
Toyota	1995	Camry	X				
				ENGINE (DATA)	X		
				ENGINE/TRANS	X	X	X
Toyota	1995	Celica	X				
				ENGINE (DATA)	X		
Toyota	1995	Corolla	X				
				ENGINE (DATA)	X		
Toyota	1995	Land Cruiser	X				
				ENGINE/TRANS	X	X	X
Toyota	1995	MR2	X				
				ENGINE (DATA)	X		
Toyota	1995	Paseo	X				
				ENGINE (DATA)	X		
Toyota	1995	Pickup	X				
				ENGINE (DATA)	X		
Toyota	1995	Previa	X				
				ENGINE/TRANS	X	X	X
Toyota	1995	Supra	X				
				ENGINE (DATA)	X		
Toyota	1995	T-100	X				
				ENGINE/TRANS	X	X	X
Toyota	1995	Tacoma	X				
				ENGINE/TRANS	X	X	X
Toyota	1995	Tercel	X				
				ENGINE/TRANS	X	X	X
Toyota	1994	4Runner	X				
				ENGINE (DATA)	X		
Toyota	1994	Camry	X				
				ENGINE (DATA)	X		
				ENGINE/TRANS	X	X	X
Toyota	1994	Celica	X				
				ENGINE (DATA)	X		
Toyota	1994	Corolla	X				
				ENGINE (DATA)	X		
Toyota	1994	Land Cruiser	X				
				ENGINE (DATA)	X		
Toyota	1994	Pickup	X				
				ENGINE (DATA)	X		

Toyota	1994	Supra	X		
				ENGINE (DATA)	X
Toyota	1994	T-100	X		
				ENGINE (DATA)	X
Toyota	1993	4Runner	X		
				ENGINE (DATA)	X
Toyota	1993	4-Runner	X		
				ENGINE (DATA)	X
Toyota	1993	Camry	X		
				ENGINE (DATA)	X
Toyota	1993	Celica	X		
				ENGINE (DATA)	X
Toyota	1993	Corolla	X		
				ENGINE (DATA)	X
Toyota	1993	Landcruiser	X		
				ENGINE (DATA)	X
Toyota	1993	MR2	X		
				ENGINE (DATA)	X
Toyota	1993	Pickup	X		
				ENGINE (DATA)	X
Toyota	1993	T-100	X		
				ENGINE (DATA)	X
Toyota	1992	4-Runner	X		
				ENGINE (DATA)	X
Toyota	1992	Camry	X		
				ENGINE (DATA)	X
Toyota	1992	Celica	X		
				ENGINE (DATA)	X
Toyota	1992	Cressida	X		
				ENGINE (DATA)	X
Toyota	1992	Pickup	X		
				ENGINE (DATA)	X
Toyota	1991	Cressida	X		
				ENGINE (DATA)	X
Toyota	1990	Cressida	X		
				ENGINE (DATA)	X
Toyota	1989	Cressida	X		
				ENGINE (DATA)	X