



655 EISENHOWER DRIVE
 OWATONNA, MN 55060-0995 USA
 PHONE: (507) 455-7000
 TECH. SERV.: (800) 533-6127
 FAX: (800) 955-8329
 ORDER ENTRY: (800) 533-6127
 FAX: (800) 283-8665
 INTERNATIONAL SALES: (507) 455-7223
 FAX: (507) 455-7063

Form No. 528966

Parts List & Operating Instructions
 for: **528859**
205466
D05223ST



Original Instructions

Component for OTC No. 1750 or No. 1750A

Engine Mounting Adapter

Maximum Capacity: 1360 kg (3000 lbs.)


Tool Weight: 56 kg (123 lbs.)

Description: Engine mounting adapter designed for mounting John Deere 400-Series and 500-Series engines to the OTC 1750 and 1750A Heavy-Duty Engine Repair Stands.

Attach No. 51400 Adapter to No. 60581 Engine Mounting Adapter

Use the four hex head cap screws (No. 19654) provided. Torque to 136 N•m (100 ft. lbs.)

Note: No. 51400 is needed in all setups except the 400 Series 4-cylinder engines, which require only the No. 60581.



Parts List

Item No.	Part No.	No. Req'd	Description
1	19654	4	Hex Head Cap Screw— 5/8-11 x 38.1 mm (1-1/2 in.) lg.
2	51400	1	End Adapter
3	60581	1	Engine Mounting Adapter
4	19656	5	Hex Head Cap Screw— 5/8-11 x 69.9 mm (2-3/4 in.) lg.
5	19657	5	Hex Head Cap Screw— 3/4-10 x 69.9 mm (2-3/4 in.) lg.

Note: No. D05223ST Engine Repair Stand consists of No. 205466 Engine Mounting Adapter and No. 1750 Engine Repair Stand. Refer to Form No. 100300 for information regarding the engine repair stand.

Sheet No. 1 of 3

Issue Date: Rev. C October 15, 2013

Explanation of Safety Signal Words

The safety signal word designates the degree or level of hazard seriousness.



DANGER: Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



WARNING: Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION: Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

CAUTION: Used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, may result in property damage.

Safety Precautions



CAUTION: To prevent personal injury and/ or property damage,



- Study, understand, and follow all safety precautions and operating instructions before using this engine mounting adapter. If the operator cannot read instructions, operating instructions and safety precautions must be read and discussed in the operator's native language.
- Only qualified operators may install, operate, adjust, maintain, clean, repair, inspect, or transport this engine mounting adapter.



- Wear eye protection that meets ANSI Z87.1, CE EN166, AS/NZS 1337, and OSHA standards.
- Do not exceed the rated capacity shown on the engine mounting adapter.
- To maintain shear strength specifications, use SAE grade 8 or property class 10.9 hex head cap screws to mount components or engines.
- Use this engine mounting adapter with OTC No. 1750 or No. 1750A Heavy-Duty Engine Repair Stand only.
- Do not use this engine mounting adapter for anything other than its intended purpose.
- No alteration shall be made to this product.
- Inspect the condition of the engine mounting adapter before each use; do not use if damaged, altered, or in poor condition.
- Use only those repair parts called out in the parts list in this document. Items found in the parts list have been carefully tested and selected by Bosch.

Preventive Maintenance




CAUTION: To prevent personal injury,

- Only qualified personnel shall perform inspections and repairs to this engine mounting adapter.
- Before each use, an approved inspector must inspect the engine mounting adapter for bends, cracks, dents, elongated holes, or missing hardware. If damage is found, discontinue use.
- Use only those repair parts called out in the parts list in this document. Items found in the parts list have been carefully tested and selected by Bosch.

Operating Instructions

1. Mount the engine adapter to OTC No. 1750 or 1750A Heavy-Duty Engine Repair Stand using the three 1–8 UNC socket head cap screws included with the engine repair stand.
 2. Torque cap screws to 610 N•m (450 ft. lbs.) using the hex adapter included with the engine repair stand.
- Refer to Form No. 102302, and the decal on the engine repair stand, for information regarding load ratings and other specifications when mounting engines or components to the engine repair stand.




Mount the Engine to an Adapter and/or Engine Stand


Choose one of the following setups to attach the engine mounting adapter to a 400 or 500 Series engine.

400 Series (4-270) 4-Cylinder Engines

NOTE: Some 400 series 4-cylinder short blocks use 3/4-10 UNC x 69.9 mm (2-3/4 in.) hex head cap screws.




Mount No. 60581 to the starter side of the engine **without** No. 51400 end adapter.




- Use four 5/8-11 UNC x 69.9 mm (2-3/4 in.) lg. hex head cap screws as shown.
- Minimum thread engagement required: 31.75 mm (1-1/4 in.)
- Torque to 136 N•m (100 ft. lbs.).

400 Series (6-404) 6-Cylinder Engines




Mount No. 60581 to the starter side of the engine **with** No. 51400 end adapter in place.




- Use five 5/8-11 UNC x 69.9 mm (2-3/4 in.) lg. hex head cap screws as shown.
- Minimum thread engagement required: 31.75 mm (1-1/4 in.)
- Torque to 136 N•m (100 ft. lbs.).

400 Series (6-466) 6-Cylinder Engines




Mount No. 60581 to the starter side of the engine **with** No. 51400 end adapter in place.




- Use one 3/4-10 x 69.9 mm (2-3/4 in.) lg. hex head cap screw as shown.
- Minimum thread engagement required: 38 mm (1-1/2 in.)
- Torque to 203 N•m (150 ft. lbs.).
- Use four 5/8-11 UNC x 69.9 mm (2-3/4 in.) lg. hex head cap screws as shown.
- Minimum thread engagement required: 31.75 mm (1-1/4 in.)
- Torque to 203 N•m (150 ft. lbs.).

500 Series 6-Cylinder Engines



Mount No. 60581 to the starter side of the engine **with** No. 51400 end adapter in place.



- Use five 3/4-10 x 69.9 mm (2-3/4 in.) lg. hex head cap screws as shown.
- Minimum thread engagement required: 31.75 mm (1-1/4 in.)
- Torque to 203 N•m (150 ft. lbs.).

English

EC Declaration of Conformity

We Bosch Automotive Service Solutions LLC
of 655 Eisenhower Drive
Owatonna, Minnesota 55060 USA

in accordance with the following Directive(s):
2006/42/EC The Machinery Directive

hereby declare that:


Equipment Engine Mounting Adapter
Model Number 205466, 528859

is in conformity with the applicable requirements of the following documents:

Ref. No.	Title	Edition / Date
N/A	N/A	N/A

I hereby declare that the equipment named here has been designed to comply with the relevant sections of the above referenced specifications and is in accordance with the requirements of the Directive(s).

Signed by:


Name: Mike Schoenoff
Position: Director of Engineering, AA-AS
Location: Owatonna, Minnesota
Date: 10/15/2013

The technical documentation for the machinery is available from

Name: Bosch Automotive Service Solutions GmbH
Address: Am Dörrenhof 1
85131 Pollenfeld / Preith, Germany
represented by Gary Palmer, Geschäftsführer

Spanish

French

German