# Oil Light Reset Tool Kit, 2010

3596H

- Oil changes are the #1 service your shop will perform each year. Enhance your service with this complete electronic tool and manual kit, No. 3596H.
- This 3596H kit eliminates the need to take the vehicle to the dealer or use an OEM scan tool to reset oil service lights.
- Electronic tool set includes the adapters and interface module required to reset the oil service lights on Volkswagen, Audi, Mercedes Benz, BMW, and Volvo.
- The included manual details Oil Light Reset tool procedures as well as the manual reset procedures for domestic and import vehicles.
- Newly designed Oil Light Reset tool has added European coverage.
- Added functionality to reset additional service lights (maintenance cycle, service interval).
- The new Oil Light Reset tool now gives you the ability to update the tool vehicle coverage by connecting to a PC with future update kits.

No. 3596H – Oil light reset tool kit, 2010.

Kit Includes:
No. 3596H-1 – Main unit cable.
No. 3596H-2 – BMW Connector.
No. 3596H-3 – Mercedes-Benz Connector.
No. 3596H-4 – OBD II Connector.
No. 3596H-5 – Volvo cable.
No. 3596H-6 – Transfer plug.
No. 3596H-7 – VW and Audi cable.
No. 3596H-8 – Power cable.
No. 3596H-9 – Reset Procedure Manual.

3596H

BMW
Vehicle Adapters / Data Link Connector Locations for BMW

There are two vehicle adapters for BMW vehicles. The illustrations below show the adapters and their data link connector (DLC) / socket locations.

BMW-OBD II 16-pin Vehicle Adapter (for the 3596E Oil Reset Tools only)

16-pin DLC (under dash on driver side)

Dash on Driver side

Reset Procedures for BMW

Manufacturer	Model	Year	Reset Tool	Procedure
BMW	5-Series (E39, E53)	2000-2005	X	Oil Reset Tool: Use the BMW-OBD II 16-pin Vehicle Adapter. Select BMW then E46 (OBDII). **Sample of manual contents** Manual Reset: 1 Turn off the ignition. 2 Press and hold the TRIP ODOMETER button in the instrument cluster and turn the ignition to Accessory (1). 3 Keep the button pressed for approximately 5 more seconds until OIL SERVICE RESET (RE) or INSPECTION RESET (RE) appears in the display. Then release the button. 4 Press and hold the button again for approx. 5 seconds until RE or RESET flashes in the display. Then release the button. 5 With the display flashing, press the button briefly to reset and display the new Service Interval. After this, END SIA appears in the display for approximately 2 seconds.

800-533-6127   www.otctools.com   SPX SERVICE SOLUTIONS